# **FR-A7NP** – PROFIBUS-DP communication function Plug-in option frequency inverter





## Instruction manual



Distributor for:



**EPA Drives** 



### Thank you for choosing to work with EPA!

EPA - your competent partner for Mitsubishi Electric when it comes to **individual service** & **comprehensive services**.

If you have any questions about the product, please feel free to call us: Tel: +49 (0)6181 - 9704 - 0

You can find the latest information about us and our products at **www.epa.de**.

#### Sales department:

### EPA GmbH

Fliederstraße 8, D-63486 Bruchköbel Deutschland / Germany Telefon / Phone: +49(0)6181 9704-0 Telefax / Fax: +49(0)6181 9704-99 E-Mail: info@epa.de

Internet: www.epa.de

## Author: MITSUBISHI ELECTRIC

Release:

11.2004

Article: FR-A7NP



Thank you for choosing this Mitsubishi Inverter plug-in option. This instruction manual gives handling information and precautions for use of this equipment. Incorrect handling might cause an unexpected fault. Before using the equipment, please read this manual carefully to use the equipment to its optimum. Please forward this manual to the end user.

# This section is specifically about safety matters

Do not attempt to install, operate, maintain or inspect this product until you have read through this instruction manual and appended documents carefully and can use the equipment correctly. Do not use this product until you have a full knowledge of the equipment, safety information and instructions.

In this instruction manual, the safety instruction levels are classified into "WARNING" and "CAUTION".

## 

Assumes that incorrect handling may cause hazardous conditions, resulting in death or severe injury.

Assumes that incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause physical damage only.

Note that even the <u>A</u>CAUTION level may lead to a serious consequence according to conditions. Please follow the instructions of both levels because they are important to personnel safety.

### SAFETY INSTRUCTIONS

**1. Electric Shock Prevention** 

### 

- While power is on or when the inverter is running, do not open the front cover. You may get an electric shock.
- Do not run the inverter with the front cover or wiring cover removed. Otherwise, you may access the exposed highvoltage terminals and charging part and get an electric shock.
- If power is off, do not remove the front cover except for wiring or periodic inspection. You may access the charged inverter circuits and get an electric shock.
- Before starting wiring or inspection, check to make sure that the inverter power indicator lamp is off, wait for at least 10 minutes after the power supply has been switched off, and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power off and it is dangerous.
- Any person who is involved in the wiring or inspection of this equipment should be fully competent to do the work.
- Always install the plug-in option before wiring. Otherwise, you may get an electric shock or be injured.
- Do not touch the plug-in option with wet hands. Otherwise you may get an electric shock.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Otherwise you may get an electric shock.

#### 2. Injury Prevention

### 

- Apply only the voltage specified in the instruction manual to each terminal. Otherwise, burst, damage, etc. may occur.
- Ensure that the cables are connected to the correct terminals. Otherwise, burst, damage, etc. may occur.
- Always make sure that polarity is correct to prevent damage, etc. Otherwise, burst, damage may occur.
- While power is on or for some time after power-off, do not touch the inverter as it is hot and you may get burnt.

#### 3. Additional Instructions

Also note the following points to prevent an accidental failure, injury, electric shock, etc.

1) Transportation and mounting

### 

- Do not install or operate the plug-in option if it is damaged or has parts missing.
- Do not stand or rest heavy objects on the product.
- Check that the mounting orientation is correct.
- Prevent other conductive bodies such as screws and metal fragments or other flammable substance such as oil from entering the inverter.

#### 2) Trial run

### 

• Before starting operation, confirm and adjust the parameters. A failure to do so may cause some machines to make unexpected motions.

#### 3) Usage

### 

- Do not modify the equipment.
- Do not perform parts removal which is not instructed in this manual. Doing so may lead to fault or damage of the inverter.

### 

- When parameter clear or all parameter clear is performed, reset the required parameters before starting operations. Each parameter returns to the initial value.
- For prevention of damage due to static electricity, touch nearby metal before touching this product to eliminate static electricity from your body.
- 4) Maintenance, inspection and parts replacement

### 

- Do not test the equipment with a megger (measure insulation resistance).
- 5) Disposal

### 

• Treat as industrial waste.

#### 6) General instruction

All illustrations given in this manual may have been drawn with covers or safety guards removed to provide in-depth description. Before starting operation of the product, always return the covers and guards into original positions as specified and operate the equipment in accordance with the manual.

### - CONTENTS -

1

I

1	<b>PRE-OPERATION INSTRUCTIONS</b>
	FRE-OFERATION INSTRUCTION

1.1 Unpacking and Product Confirmation	1
1.1.1 Packing confirmation	1
1.1.2 Parts	2
1.2 Node Address Setting	3
1.3 Specifications	4
<ul><li>1.3.1 Inverter option specifications</li><li>1.3.2 Communication specifications</li></ul>	4 4
2 INSTALLATION	5
2.1 Pre-Installation Instructions	5
2.2 Installation of the Communication Option LED Display Cover	5
2.3 Installation Procedure	6
2.3 Installation Procedure	6 7
2.3 Installation Procedure     3 WIRING     3.1 Terminal Block	6 7 7
<ul> <li>2.3 Installation Procedure</li></ul>	6 7 7 
<ul> <li>2.3 Installation Procedure</li></ul>	6 7 7 8 11
<ul> <li>2.3 Installation Procedure</li></ul>	6 7 7 8 11 11
<ul> <li>2.3 Installation Procedure</li></ul>	6 7 7 8 11 11 11
<ul> <li>2.3 Installation Procedure</li></ul>	6 7 7 8 11 11 12 12
<ul> <li>2.3 Installation Procedure</li></ul>	
<ul> <li>2.3 Installation Procedure</li></ul>	

4.4	Operation at Communication Error Occurrence	20
4.	.4.1 Operation selection at communication error occurrence (Pr. 500 to Pr. 502)	20
4.	.4.2 Alarm and measures	24
4.5	Inverter Reset	25
5	FUNCTIONS	27
5.1	Output from the Inverter to the Network	27
5.2	Input to the Inverter from the Network	28
6	PROFIBUS DEVICE DATA	29
6.1	Device Data (GSD file)	29
6.2	Slave User Parameter	33
7		25
	FFO TIFE SUFFORT SPECIFICATION	35
7.1	Profibus Profiles	35
7.1	Profibus Profiles	
7.1 7.2 7.3	Profibus Profiles ID Definitions Buffer Memory Map	35 35 
7.1 7.2 7.3 7.4	Profibus Profiles ID Definitions Buffer Memory Map Buffer Memory Configuration	35 35 36 37 38
7.1 7.2 7.3 7.4 7.5	Profibus Profiles ID Definitions Buffer Memory Map Buffer Memory Configuration Buffer Memory Details	35 35 36 37 38 38 39
7.1 7.2 7.3 7.4 7.5 7.6	Profibus Profiles ID Definitions Buffer Memory Map Buffer Memory Configuration Buffer Memory Details Qutline of PNU	35 35 36 37 38 39 39 39
7.1 7.2 7.3 7.4 7.5 7.6 7.7	Profibus Profiles ID Definitions Buffer Memory Map Buffer Memory Configuration Buffer Memory Details Outline of PNU Profibus PNU	35 
7.1 7.2 7.3 7.4 7.5 7.6 7.7	Profibus Profiles ID Definitions Buffer Memory Map Buffer Memory Configuration Buffer Memory Details Outline of PNU Profibus PNU	35 
7.1 7.2 7.3 7.4 7.5 7.6 7.7 7.7	Profibus Profiles ID Definitions Buffer Memory Map Buffer Memory Configuration Buffer Memory Details Outline of PNU Profibus PNU	35 
7.1 7.2 7.3 7.4 7.5 7.6 7.7 7.7 7.7	Profibus Profiles	35 
7.1 7.2 7.3 7.4 7.5 7.6 7.7 7. 7. 7. 7. 7. 7.	Profibus Profiles         ID Definitions         Buffer Memory Map         Buffer Memory Configuration         Buffer Memory Details         Outline of PNU         Profibus PNU         7.1       Real-time monitor         7.2       Parameter clear         7.3       Operation mode read/write         7.4       Set frequency read	33 35 36 37 38 39 46 47 47 47 49 49 49 49
7.1 7.2 7.3 7.4 7.5 7.6 7.7 7. 7. 7. 7. 7. 7. 7.	Profibus Profiles         ID Definitions         Buffer Memory Map         Buffer Memory Configuration         Buffer Memory Details         Outline of PNU         Profibus PNU         7.1       Real-time monitor         7.2       Parameter clear         7.3       Operation mode read/write         7.4       Set frequency read         7.5       Terminal input read	35 
7.1 7.2 7.3 7.4 7.5 7.6 7.7 7. 7. 7. 7. 7. 7. 7. 7. 7. 7. 7. 7.	Profibus Profiles         ID Definitions         Buffer Memory Map         Buffer Memory Configuration         Buffer Memory Details         Outline of PNU         Profibus PNU         7.1       Real-time monitor         7.2       Parameter clear         7.3       Operation mode read/write         7.4       Set frequency read         7.5       Terminal input read         7.6       Inverter reset	35 

7.7.8 Alarm definition read	51
7.8 Standard Parameters	
8 PPO TYPE NON SUPPORT SPECIFICATION	59
8.1 Profibus Profiles	59
8.2 ID definitions	60
8.3 Buffer memory map	60
8.4 Buffer Memory Configuration	61
8.5 Buffer Memory Details	62
8.6 Outline of PNU	67
8.7 Profibus PNU (Module Type A5NP)	68
<ul> <li>8.7.1 Real time monitor area (IND=0000H)</li> <li>8.7.2 System environment variable (sev) area (IND = 01PPH)</li> </ul>	68 69
8.8 Standard Parameters	73
<ul> <li>8.8.1 Normal parameter area (IND = 0200H)</li> <li>8.8.2 Pr. 900 to calibration parameter (frequency) area (IND=0300H)</li> <li>8.8.3 Pr. 900 to calibration parameter (%) area (IND=0400H)</li> <li>8.8.4 Terminal input read (IND=0500H)</li> </ul>	
9 TROUBLESHOOTING	77

## **PRE-OPERATION INSTRUCTIONS**

### **1.1 Unpacking and Product Confirmation**

Take the plug-in option out of the package, check the unit name, and confirm that the product is as you ordered and intact.

This product is a plug-in option dedicated for the FR-F700 series.

### 1.1.1 Packing confirmation

Check the enclosed items.





### 1.1.2 Parts



### **1.2 Node Address Setting**

#### •Setting with node address switch

Set the node address between "OH to 7DH" using node address switches on the FR-A7NP (*refer to page 2*). The setting is reflected at the next power-on or inverter reset.

Set the arrow ( $\hat{u}$ ) of the corresponding switches to the number and alphabet to set a desired address. •Setting example

Node address 1: Set the "企 " of x16(SW3) to "0" and the

"① " of x1(SW1) to "1".

- Set the node address switch to the switch number (alphabet) position correctly. If the switch is set between numbers, normal data communication can not be made.
- 2. Do not set the node address to 7EH through FFH.
- 3. Depending on the master module, 0H, 1H, 2H, 7CH, 7DH of node address may not be used.
- 4. You cannot set the same node address to other devices on the network. (Doing so disables proper communication.)
- 5. Set the inverter node address before switching on the inverter and do not change the setting while power is on. Otherwise you may get an electric shock.



X16



Node address 26: Set the "  $\hat{U}$ " of x16(SW3) to "2" and the

### **1.3 Specifications**

#### 1.3.1 Inverter option specifications

Туре	Inverter plug-in option type
Number of nodes occupied	One inverter occupies one node.
Connection cable	Cable which supports 12.0Mbps communication (EEIA-485(RS-485) standard)

### 1.3.2 Communication specifications

	Wiring length 1200m or less	9600bps, 19.2Kbps, 93.75Kbps
Communication croad	Wiring length 600m or less	187.5Kbps
Communication speed	Wiring length 200m or less	500Kbps, 1.5Mbps
	Wiring length 100m or less	3.0Mbps, 6.0Mbps, 12.0Mbps

### 2.1 Pre-Installation Instructions

Make sure that the input power of the inverter is off.

### 

With input power on, do not install or remove the plug-in option. Otherwise, the inverter and plug-in option may be damaged.

### 2.2 Installation of the Communication Option LED Display Cover

Mount the cover for displaying the operation status indication LED for the communication option on the inverter front cover.

- 1)Cut off hooks on the rear of the inverter front cover with nipper, etc. and open a window for fitting the LED display cover.
- 2)Fit the communication option LED display cover to the front of the inverter front cover and push it into until fixed with hooks.



Take care not to hurt your hand and such with portions left by cutting hooks of the rear of the front cover.

#### INSTALLATION





- 1) Remove the inverter front cover.
- Mount the hex-head screw for option mounting into the inverter screw hole (on earth plate). (size 5.5mm, tightening torque 0.56N·m to 0.75N·m)
- Securely fit the connector of the plug-in option to the inverter connector along the guides.
- 4) Securely fix the both right and left sides of the plug-in option to the inverter with the accessory mounting screws. If the screw holes do not line-up, the connector may not have been plugged snugly. Check for loose plugging.

#### REMARKS

After removing two screws on the right and left places, remove the plug-in option. (The plug-in option is easily removed if the control circuit terminal block is removed before.)

#### 

- 1. When the inverter can not recognize that the option unit is mounted due to improper installation, etc.,
  - "*E*. / " (option alarm) is displayed.
- 2. Note that a hex-head screw for option mounting or mounting screw may drop during mounting and removal.



### **3.1 Terminal Block**

Terminal block layout



Terminal No.	Terminal Name	Definition
1-A	V+ (VP)*1	Voltage output (approx. 5V to V-)
1-B	D+ (RXD/TXD-P)	Send and receive profibus signal+
2-A	D+ (RXD/TXD-P)	Send and receive profibus signal+
2-B	D+ (RXD/TXD-N)	Send and receive profibus signal-
3-A	D+ (RXD/TXD-N)	Send and receive profibus signal-
3-B	V- (DGND)*1	GND of D+/D-
4-A	D+ (RXD/TXD-P)	Send and receive profibus signal+
4-B	D+ (RXD/TXD-N)	Send and receive profibus signal-
5-A	V- (DGND)*1	GND of D+/D-
5-B	CNTR *2	Control signal (sending request from the inverter)
6-A	FG	(connected to the earth of the inverter unit)
6-B	FG	(connected to the earth of the inverter unit)

\*1 Use when selecting a terminating resistor.

\*2 It may not be necessary depending on the master used.

#### WIRING

### 3.2 Wiring

Use the network connection cable which supports 12.0Mbps communication.

(1) Strip off the sheath of the PROFIBUS communication dedicated cable and wind wires and shield cables to use. If the length of the sheath pealed is too long, a short circuit may occur among neighboring wires. If the length is too short, cables and shield cables might come off.



(2) Loosen the terminal screw and insert the cable into the terminal. Tighten each cable with fixing screws to the recommended tightening torque.



Screw Size	Screw Size Tightening Torque Cable Size		Screwdriver
M2	0.22N•m to 0.25N•m	0.3mm <sup>2</sup> to 0.75mm <sup>2</sup>	Small ⊖ flat-blade screwdriver (Tip thickness: 0.4mm /tip width: 2.5mm)

#### CAUTION =

Undertightening can cause cable disconnection or malfunction. Overtightening can cause a short circuit or malfunction due to damage to the screw or unit.

#### (3) Terminating resistor

If the node at both ends of the network are the FR-A7NP and inverter, connect a connector with a built-in terminating resistor.

Connection example



#### WIRING

(4) For wiring of the FR-F700 series 30K (FR-F720-01250, FR-F740-00620) or less, route wires between the control circuit terminal block and front cover. If cables can not be routed between the control circuit terminal block and front cover (approx 7mm), remove a hook of the front cover and use a space become available. For wiring of the FR-F700 series 37K (FR-F720-01540, FR-F740-00770) or more, use the space on the left side of the control circuit terminal block.



#### REMARKS

• When the hook of the inverter front cover is cut off for wiring, the protective structure (JEM1030) changes to open type (IP00 (The structure of the NA version is no longer NEMA 1.)).

### 

- Nhen performing wiring using the space between the inverter front cover and control circuit terminal block, take care not to subject the cable to stress.
- After wiring, wire offcuts must not be left in the inverter. They may cause an error, failure or malfunction.

### **INVERTER SETTING**

### 4.1 Parameter List

The following parameters are used for the communication option (FR-A7NP) Set the values according to need.

Parameter Number	Name	Setting Range	Minimum Setting Increments	Initial Value	Refer to page
79	Operation mode selection	0 to 4, 6, 7	1	0	13
338	Communication operation command source	0, 1	1	0	16
339	Communication speed command source	0, 1, 2	1	0	16
340	Communication startup mode selection	0, 1, 2, 10, 12	1	0	13
342	Communication EEPROM write selection	0, 1	1	0	19
349*1	Communication reset selection	0, 1	1	0	26
500*1	Communication error execution waiting time	0 to 999.8s	0.1s	0	20
501*1	Communication error occurrence count display	0	1	0	21
502*1	Stop mode selection at communication error	0, 1, 2, 3	1	0	22
550	NET mode control source selection	0, 1, 9999	1	9999	16

\*1 Parameters which can be displayed when the plug-in option (FR-A7NP) is mounted.

#### **INVERTER SETTING**



The inverter mounted with a communication option has three operation modes.

- (1) PU operation [PU]..... Controls the inverter from the key of the operation panel (FR-DU07) mounted on the inverter.
- (2) External operation [EXT] ... Controls the inverter by switching on/off external signals connected to the control circuit terminals of the inverter.

(The inverter is factory-set to this mode.)

(3) Network operation [NET] ... Controls the inverter with instructions from the network via the communication option.

(The operation signal and running frequency can be entered from the control circuit terminals depending on the *Pr. 338 Communication operation command source* and *Pr. 339 Communication speed command source* setting.

Refer to page 17.)

### 4.2.1 Operation mode indication

FR-DU07



Operation mode indication (The inverter operates according to the LED lit mode.) PU: PU operation mode EXT: External operation mode NET: Network operation mode

#### Operation mode switching and communication startup mode (Pr. 79, Pr. 340) 4.2.2

#### (1) Operation mode switching conditions

Before switching the operation mode, check that:

1) The inverter is at a stop;

- 2) Both the STF and STR signals are off; and
- 3) The Pr. 79 Operation mode selection setting is correct.

(Set with the operation panel of the inverter.)

Refer to the inverter manual (applied) for details of Pr. 79.

#### (2) Operation mode selection at power on and at restoration from instantaneous power failure

The operation mode at power on and at restoration from instantaneous power failure can be selected. Set a value other than "0" in Pr. 340 to select the network operation mode. After started in network operation mode, parameter write from the network is enabled.

#### REMARKS

- Change of the *Pr*: *340* setting is made valid when powering on or resetting the inverter. *Pr*: *340* can be changed with the operation panel independently of the operation mode.

#### **INVERTER SETTING**

Pr. 340 Setting	Pr. 79 Setting	Operation Mode at Power on or Power Restoration	Operation Mode Switchover			
	0 (initial value)	External operation mode	Switching among the external, PU, and NET operation mode is enabled *1			
	1	PU operation mode	PU operation mode fixed			
0	2	External operation mode	Switching between the external and Net operation mode is enabled Switching to the PU operation mode is disallowed			
(initial	3, 4	External/PU combined operation mode	Operation mode switching is disallowed			
value)	6	External operation mode	Switching among the external, PU, and NET operation mode is enabled while running.			
		X12 (MRS) signal ON external operation mode	Switching among the external, PU, and NET operation mode is enabled *1			
	7	X12 (MRS) signal OFF external operation mode	External operation mode fixed (Forcibly switched to external operation mode.)			
	0	NET operation mode				
	1	PU operation mode				
	2	NET operation mode				
<b>1, 2</b> *2	3, 4	External/PU combined operation mode	Same as when Pr: 340 = "0"			
	6 *4	NET operation mode	]			
	7	X12 (MRS) signal ON NET operation mode				
	'	X12 (MRS) signal OFF external operation mode				
	0	NET operation mode	Switching between the PU and NET operation mode is enabled *3			
	1	PU operation mode	Same as when <i>Pr. 340</i> = "0"			
10 12 10	2	NET operation mode	NET operation mode fixed			
10, 12 ^2	3, 4	External/PU combined operation mode	Same as when Pr. 340 = "0"			
	6 *4	NET operation mode	Switching between the PU and NET operation mode is enabled while running *3			
	7	External operation mode	Same as when Pr: 340 = "0"			

\*1 Operation mode can not be directly changed between the PU operation mode and network operation mode.

\*2 The *Pr. 340* settings "2, 12" are mainly used for communication operation using the inverter RS-485 terminal. When a value other than "9999" (selection of automatic restart after instantaneous power failure) is set in *Pr. 57 Restart coasting time*, the inverter will resume the same operation state which was in before after power has been restored from an instantaneous power failure.

- \*3 Operation mode can be changed between the PU operation mode and network operation mode with (FR-DU07) and X65 signal.
- \*4 *Pr.* 79 = "6" and *Pr.* 128 to *Pr.* 134 (*PID control*) are not activated simultaneously. Switchover mode and PID control are made invalid, and the inverter performs the same operation as when "0" is set in *Pr.* 79.



For the switching method from the external terminal, refer to *the inverter manual (applied)*. Refer to *page 49* and *71* for a switching method from the network.

#### -CAUTION =

- When starting the inverter in network operation mode at powering on or an inverter reset, set a value other than 0 in *Pr. 340. (Refer to page 13)*
- When setting a value other than 0 in Pr. 340, make sure that the initial settings of the inverter are correct.

### 4.3 Operation and Speed Command Source (Pr. 338, Pr. 339, Pr. 550)

#### (1) Select control source for the network operation mode (Pr. 550)

A control location for the network operation mode can be selected from either the inverter RS-485 terminal or communication option.

When using a communication option, set "0 or 9999 (initial value)" in Pr. 550.

Parameter Number	Name	Initial Value	Setting Range	Description
	NET mode operation command source selection		0	Control source of the communication option is valid (control source of the inverter RS-485 terminal is invalid)
550		9999	1	Control source of the inverter RS-485 terminal is valid (control source of the communication option is invalid)
			9999	Automatic recognition of the communication option Normally, control source of the RS- 485 terminal is valid. When a communication option is mounted, the control source of the communication option is valid.

Refer to the inverter manual (applied) for details.

#### (2) Selection of control source for the network operation mode (Pr. 338, Pr. 339)

- As control sources, there are operation command source that controls signals related to the start command and function selection of the inverter and speed command source that controls signals related to frequency setting.
- In network operation mode, commands from the external terminals and communication are as listed below.

Control Location Selection		Pr. 338 Communication operation command source		0:NET		1:External			Pomarke				
			Pr. 339 Communication speed command source	0:NET	1: External	2: External	0:NET	1: External	2: External	Remarks			
Fixed		Runn	ing frequency from communication	NET	—	NET	NET	_	NET				
fune	ction	S	Term	inal 2		External	_		External	_			
(Fui	ivale	nt	Term	inal 4		Exte	ernal		Exte	ernal			
to te	ərmir	als)	Term	inal 1			Compe	nsation					
		0	RL	Low-speed operation command/ remote setting clear	NET	Exte	ernal	NET	External		Pr. 59 = "0"		
	78 to Pr. 189 settings	1	RM	Middle-speed operation command/ remote setting deceleration	NET	Exte	ernal	NET	Exte	ernal	(multi-speed) Pr: 59 = "1, 2"		
su		tings	2	RH	High-speed operation command/ remote setting acceleration	NET	Exte	ernal	NET	Exte	ernal	(remote)	
tio		3	RT	Second function selection		NET			External				
u u		4	AU	Terminal 4 input selection	_	Com	bined		Com	bined			
e fi		78 to Pr. 18	78 to Pr. 18	5	JOG	Jog operation selection		_			External		
elective				78 to Pi	6	cs	Automatic restart after instantaneous power failure selection			Exte	ernal		
õ	r. 1	7	ОН	External thermal relay input			Exte	ernal					
	Ρ	8	REX	15-speed selection	NET	Exte	ernal	NET	Exte	ernal	Pr. 59 = "0" (multi-speed)		
	10 X10 Inverter operation enable signal External												

#### INVERTER SETTING



External

External

\*1 Setting can be made only for the EC and NA version.\*2 Setting can be made only for the EC and CH versions.

[Explanation of table]

66

67

External :Control by signal from external terminal is only valid.

X66 NET/external operation switchover

X67 Command source switchover

:Control from network is only valid NET

:Operation from either external terminal or communication is valid. :Operation from either external terminal or computer is invalid. Combined

:Control by signal from external terminal is only valid if Pr. 28 Multi-speed input compensation setting is "1". Compensation

### 4.3.1 Communication EEPROM write selection (Pr. 342)

When parameter write is performed from the communication option, write to RAM is enabled. Set when frequent parameter changes are necessary.

Parameter Number	Name	Initial Value	Setting Range	Description
342	Communication EEPROM write	0	0	Parameter values written by communication are written to the EEPROM and RAM.
	selection		1	Parameter values written by communication are written to the RAM.

When changing the parameter values frequently, set "1" in *Pr. 342* to write them to the RAM.
 Performing frequent parameter write with "0 (initial value)" (EEPROM write) set in will shorten the life of the EEPROM.

#### REMARKS

When "1" is set in *Pr. 342* (write to RAM only), powering off the inverter will erase the changed parameter values. Therefore, the parameter values available when power is switched on again are the values stored in EEPROM previously.

### 4.4 Operation at Communication Error Occurrence

### 4.4.1 Operation selection at communication error occurrence (Pr. 500 to Pr. 502)

You can select operations at communication error occurrences by setting *Pr. 500 to Pr. 502* under network operation. (1) The set time from when a communication line error occurrence until communication error output

You can set the waiting time from when a communication line error occurs until it is recognized as a communication error.

Parameter Number	Name	Setting Range	Minimum Setting Increments	Initial Value
500	Communication error execution waiting time	0 to 999.8s	0.1s	0



If the communication line error still persists after the time set in *Pr. 500* has elapsed, it is recognized as a communication error.

When the error is restored to normal communication within the set time, it is not regarded as a communication error and operation continues.

#### (2) Display and erasure of communication error occurrence count

The cumulative number of communication error occurrences can be indicated. Write "0" to erase this cumulative count.

Parameter Number	Name	Setting Range	Minimum Setting Increments	Initial Value
501	Communication error occurrence count display	0	1	0



At the point of communication line error occurrence, *Pr. 501 Communication error occurrence count display* is incremented by 1.

The communication error count occurrence is stored into RAM temporarily. Since this data is stored in EEPROM at one-hour intervals, performing power-on reset or inverter may cause the *Pr. 501* data to be the value stored in EEPROM the last time depending on the reset timing.



(3) Inverter operation selection at communication error occurrence You can select the inverter operation if a communication line error or an error of the option unit itself occurs.

Parameter Number	Name	Setting Range	Minimum Setting Increments	Initial Value
502	Stop mode selection at communication error	0, 1, 2, 3	1	0

#### About setting

#### •Operation at error occurrence

Alarm Definition	Pr. 502 Setting	Operation	Indication	Alarm Output	
	0				
Communication line	1	Continued *	Normal indication *	Not provided *	
	2	Continued			
	3				
Communication	0, 3	Coast to stop	E. 1 lit	Provided	
option itself	1, 2	Decelerated to stop	E. 1 lit after stop	Provided after stop	

\* When the error returns to normal communication within the time set in Pr. 500, it is not regarded as a communication line error (E.OP1).

#### •Operation at error recognition after elapse of Pr. 500 time

Alarm Definition	Pr. 502 Setting	Operation	Indication	Alarm Output
	0	Coast to stop	E.OP1 lit	Provided
Communication line	1	Decelerated to stop	E OP1 lit after stop	Provided after stop
Communication line	2			Not provided
	3	Continued	Normal indication	Not provided
Communication	0, 3	Coast to stop	E. 1 lit	Provided
option itself	1, 2	Decelerated to stop	E. 1 lit after stop	Provided after stop

#### Operation at error removal

Alarm Definition	Pr. 502 Setting	Operation	Indication	Alarm Output	
	0	Kent stonned	E OP1 kent lit	Kept provided	
Communication line	1	Rept Stopped			
Communication line	2	Restart	Normal indication	Not provided	
	3	Continued	Normal indication	Not provided	
Communication	0, 3	Kent stopped	E 1 kont lit	Kept provided	
option itself	1, 2	Rept Stopped			

-CAUTION =

- 1. A communication line error [E.OP1 (alarm data: HA1)] is an error that occurs on the communication line, and an error of the communication option unit itself [E. 1 (alarm data: HF1)] is a communication circuit error in the option.
- 2. The alarm output indicates alarm output signal (terminal ABC1) or alarm bit output.
- 3. When the setting was made to provide an alarm output, the error definition is stored into the alarm history. (The error definition is written to the alarm history when an alarm output is provided.) When no alarm output is provided, the error definition overwrites the alarm indication of the alarm history temporarily, but is not stored. After the error is removed, the alarm indication is reset and returns to the ordinary monitor, and the alarm
- history returns to the preceding alarm indication.
  4. When the *Pr. 502* setting is "1" or "2", the deceleration time is the ordinary deceleration time setting (e.g. *Pr. 8, Pr. 44, Pr. 45*).
- 5. The acceleration time at a restart is the ordinary acceleration time setting (e.g. Pr. 7, Pr. 44).
- 6. When the *Pr. 502* setting is "2", the operation/speed command at a restart is the one given before the error occurrence.
- 7. When a communication line error occurs at the *Pr. 502* setting of "2", removing the error during deceleration causes acceleration to restart at that point. (Acceleration is not restarted if the error is that of the option unit itself.)

#### **INVERTER SETTING**



### 4.4.2 Alarm and measures

(1) The inverter operates as follows at alarm occurrences.

Alarm	Status		Operation Mode			
Location			Network	External	PU Operation	
			Operation	Operation		
Invertor	Inverter operatio	n	Inverter trip	Inverter trip	Inverter trip	
Inventer	Data communica	ition	Continued	Continued	Continued	
Communication line	Inverter operation		Inverter trip (depends on the <i>Pr. 502</i> setting)	Continued	Continued	
	Data communication		Stop	Stop	Stop	
	Communication option	Inverter operation	Inverter trip (depends on the <i>Pr. 502</i> setting)	Inverter trip (depends on the <i>Pr</i> : 502 setting)	Inverter trip (depends on the <i>Pr: 502</i> setting)	
Communication	error	Data communication	Continued	Continued	Continued	
option	Error of	Inverter operation	Inverter trip (depends on the <i>Pr. 502</i> setting)	Continued	Continued	
	option itself	Data communication	Stop	Stop	Stop	

#### (2) Measures at alarm occurrences

Alarm Indication	Alarm Definition	Measures
E.OP1	Communication line error	Check the LED status of the option unit and remove the cause of the alarm. (Refer to <i>page 2</i> for LED indication status) Check the other nodes on the network. Inspect the master.
E.1	Option alarm	Check the connection between the inverter and option unit for poor contact, etc. and remove the cause of the error.

When alarms other than the above are displayed, refer to the inverter manual and remove the cause of the alarm.

#### 4.5 **Inverter Reset**

(1) Operation conditions of inverter reset Which resetting method is allowed or not allowed in each operation mode is described below.

		(	Operation Mode			
	Resetting Method			External Operation	PU Operation	
Depart from the	Inverter reset (Refer to page 50) *1		Allowed	Disallowed	Disallowed	
Reset from the	Error reset (STW(bit7)) at inverter fault ( <i>Refer to page 41</i> ) *2	Pr.349 = 0	Allowed	Allowed	Allowed	
network		Pr.349 = 1		Disallowed	Disallowed	
Connect terminals	RES-SD		Enabled	Enabled	Enabled	
Switch off inverter power			Enabled	Enabled	Enabled	
Reset from the	Inverter reset		Enabled	Enabled	Enabled	
PU/DU	Reset at inverter fault		Enabled	Enabled	Enabled	

\*1 Inverter reset can be made any time.

Reset can be made only when the protective function of the inverter is activated. (available with PPO type 1 to 5 only) \*2



- CAUTION =

- 1. When a communication line error has occurred, reset cannot be made from the network.
- 2. The inverter is set to the external operation mode if it has been reset in network operation mode. To resume the network operation, the inverter must be switched to the network operation mode again. Set a value other than "0" in *Pr. 340* to start in network operation mode. (*Refer to page 13.*)
- 3. The inverter can not be controlled for about 1s after release of a reset command .

#### (2) Error reset operation selection at inverter fault

When used with the communication option (FR-A7NP), an error reset command (STW(bit7)) from network can be made invalid in the external operation mode or PU operation mode.

Parameter Number	Name	Initial Value	Setting Range	Function
240	Communication reset	0	0	Error reset (STW(bit7)) is enabled independently of operation mode
549	selection	0	1	Error reset (STW(bit7)) is enabled only in the network operation mode

#### REMARKS

An error reset command (STW (bit7)) at inverter fault is available with PPO type 1 to 5. (Refer to page 41.)

### FUNCTIONS

5

### 5.1 Output from the Inverter to the Network

Main items to be output from the inverter (FR-A7NP) to the network and their descriptions are explained below.

		Refer t	Refer to Page		
Item	Description	PPO type Support Specification	PPO type Non Support Specification		
Inverter monitor	Monitor various items such as inverter output frequency and output current.	43, 47	68		
Parameter read	Read parameter settings of the inverter.	39, 56	62, 73		
Inverter status	Monitor output signal of the inverter.	42	65		
Operation mode read	Read the operation mode of the inverter.	42, 49			
Set frequency read	Read the frequency set in the inverter.	49	71		
Terminal input read	Read the analog value of terminal 2, 4, 1.	50	75		
Node address read	Read node address of the inverter.	50			
Alarm definition read	Monitor alarm history occurred in the inverter and energization time, output frequency, output current and output voltage at alarm occurrence are monitored.	51	71		
PNU list read	Read the available PNU number.	55	—		

#### REMARKS

Refer to the *inverter manual (applied)* for functions controllable from the network in each operation mode.

### 5.2 Input to the Inverter from the Network

Main items which can be commanded from the network to the inverter and their descriptions are explained below.

Item	Description	Refer to page	
		PPO type Support Specifications	PPO type Non Support Specifications
Frequency setting	Set the running frequency of the inverter.	43	71
Operation mode write	Set the operation mode of the inverter.	49	71
Run command	Set the control input command such as forward operation signal (STF) and reverse rotation signal (STR).	41	70
Inverter reset	Reset the inverter.	41, 50	69
Parameter write	Set parameters of the inverter.	39, 56	62, 73
Parameter clear	Return parameters to the initial values.	49	69
Input terminal function	Use the function of the inverter input terminal.	44	70

#### REMARKS

Refer to the *inverter manual (applied)* for functions controllable from the network in each operation mode.

## **PROFIBUS DEVICE DATA**

### 6.1 Device Data (GSD file)

melc08fa.gsd is a GSD file designed to recognize the features and functions of the Profibus-DP devices of the FR-A7NP. You can obtain it from us.

GSD file can be downloaded from Mitsubishi Electric FA Network Service

MELFANS web: <u>http://www.MitsubishiElectric.co.jp/melfansweb</u> or obtained from your sales representative. When editing this file, use a text editor.

For installation instructions, refer to the instruction manual of the Profibus-DP Configuration Software. Although this product complies with PPO specification, it includes specification which do not support PPO specification (FR-A5NP intercompatibility protocol). This manual states the section supporting PPO specification as PPO specification and the section not supporting PPO as PPO non support specification.

#### 

You can not use the device data which does not include PPO support specification (data for the FR-A5NP).

#### <melc08fa.gsd>

Parameter	Value	Description *1
#Profibus_DP		File header
GSD_Revision	1	ID version of GSD file
Vendor_Name	"Mitsubishi Electric"	Maker name *2
Model_Name	"FR-A7NP"	Product name
Revision	"Revision 2.00"	Product version
Ident_Number	0865н	Device number obtained from Profibus Nutzer Organization
Protocol_Ident	0	Profibus-DP is 0 fixed.
Station_Type	0	DP slave is 0 fixed.
FMS_Supp	0	FMS (Field-Bus Message Specifications) not supported.
Hardware_Release	"Series A"	Hardware version
#### PROFIBUS DEVICE DATA

 $\mathbb{Z}$ 

Parameter	Value	Description *1
Software_Release	"Revision 2.00"	Software version
9.6_supp	1	Communication speed 9600bps support
19.2_supp	1	Communication speed 19.2Kbps support
93.75_supp	1	Communication speed 93.75Kbps support
187.5_supp	1	Communication speed 187.5Kbps support
500_supp	1	Communication speed 500Kbps support
1.5M_supp	1	Communication speed 1.5Mbps support
3.0M_supp	1	Communication speed 3.0Mbps support
6.0M_supp	1	Communication speed 6.0Mbps support
12.0M_supp	1	Communication speed 12.0Mbps support
MaxTsdr_9.6	60	Longest time 60 bit times at communication speed 9600bps
MaxTsdr_19.2	60	Longest time 60 bit times at communication speed 19.2Kbps
MaxTsdr_93.75	60	Longest time 60 bit times at communication speed 93.75Kbps
MaxTsdr_187.5	60	Longest time 60 bit times at communication speed 187.5Kbps
MaxTsdr_500	100	Longest time 100 bit times at communication speed 500Kbps
MaxTsdr_1.5M	150	Longest time 150 bit times at communication speed 1.5MKbps
MaxTsdr_3.0M	250	Longest time 250 bit times at communication speed 3.0Mbps
MaxTsdr_6.0M	450	Longest time 450 bit times at communication speed 6.0Mbps
MaxTsdr_12.0M	800	Longest time 800 bit times at communication speed 12.0Mbps



Parameter	Value	Description *1
Redundancy	0	Redundancy not supported.
Repeater_Ctrl_Sig	2	Installed as TTL level via RTS signal from module.
24V_Pins	0	24V power supply for maintenance device connection is not used.
Freeze_Mode_supp	1	Freeze mode supported.
Sync_Mode_supp	1	Synchronous mode supported.
Auto_Baud_supp	1	Automatic baud rate detection support
Set_Slave_Add_supp	0	Slave address is not set.
Min_Slave_Intervall	1	100 $\mu$ s interval between 2 polling cycles
Modular_Station	1	Modular device specified.
Max_Module	1	Maximum number of modules:1
Max_Input_Len	28	Input data: Maximum 28 bytes
Max_output_Len	28	Output data: Maximum 28 bytes
Max_Data_Len	56	Input and output data: Maximum 28 + 28 = 56 bytes
Fail_Safe	0	Failsafe not supported
Max_Diag_Data_Len	6	Diagnostic data of 6 bytes secured (no external diagnosis)
Slave_Family	1	Drives defined as function class (Main Family)
PrmText	1	Text selection 1 registration
Text(0)	"No byte swapping"	If Bit 0 = 0, "No byte swapping"
Text(1)	"Byte swapping"	If Bit 0 = 1, "Byte swapping"
EndPrmText		
ExtUserPrmData	1 "Byte swapping"	Byte swapping selection 1 registration on text base
Bit(0) 0 0-1		Bit 0 = default 0, range 0 to 1

Parameter	Value	Description *1
Prm_Text_Ref	1	Text selection 1 is used.
EndExtUserPrmData		
Max_User_Prm_Data_Len	2	User parameter of 2 bytes secured
Ext_User_Prm_Data_Const(0)	01н	Initial value of user parameter's 1 byte
Ext_User_Prm_Data_Const(1)	00н	Initial value of user parameter's 2 byte
Ext_User_Prm_Data_Ref(1)	1	Byte swapping selection 1 is used on text base in user parameter's 2 byte.
Module	"PPO type 1" F3н, F1н	PPO type 1 selection
EndModule		
Module	"PPO type 2" F3н, F5н	PPO type 2 selection
EndModule		
Module	"PPO type 3" F1н	PPO type 3 selection
EndModule		
Module	"PPO type 4" F5н	PPO type 4 selection
EndModule		
Module	"РРО type 5" F3н, F9н	PPO type 5 selection
EndModule		
Module	"A5NP" 75H	FR-A5NP intercompatibility protocol selection
EndModule		

\*1 Description is not included in the ASCII file itself.

\*2 Use "Mitsubishi" if the maximum number of characters of the vendor-name of the master used is 10.



#### **6.2 Slave User Parameter**

By changing the slave user parameter value, you can use the byte swapping function (byte inversion function).

Setting "1" at Address 1H (Bit 0) makes the byte swapping function valid.

Since "-" is an unused bit, set "0".

Address		FUNCTIONS										
0н		For manufacturer setting (Always set "1".)										
1	7 Bit	6 Bit	5 Bit	4 Bit	3 Bit	2 Bit	1 Bit	0 Bit				
ТН						_		0:Byte swapping invalid 1:Byte swapping valid				



6

# MEMO

#### 7.1 Profibus Profiles

The option unit operates as a "slave of the Profibus DP master" or a "controller equivalent to Profibus DP master class 1 on an RS-485 network".

The Profibus profile (data buffer) can be selected from among six different types, "PPO type1" to "PPO type5", "A5NP". This chapter expalins the profile of Module type "PPO type1" to "PPO type5". For the Module type "A5NP" profile, refer to page *59*.

Module type is changed with the slave module setting. For details, refer to the instruction manual of the Network Master Configuration Software. The configuration of PPO type is as follows.

Module type	1				1									
PPO type1	PKE	IND	P١	VE I	STW / ZSW	HSW / HIW	Input Output	Data : Data :	6Words 6Words					
PPO type2	PKE	IND	P١	I VE	STW / ZSW	HSW / HIW	ECW / ESW	Reserved	Reserved	Reserved	Inpu Outpu	t Data : t Data :	10Word 10Word	s
PPO type3	       				STW / ZSW	HSW / HIW	Input Output	Data : Data :	2Words 2Words					
PPO type4					STW / ZSW	HSW / HIW	ECW / ESW	Reserved	Reserved	Reserved	Inpu Outpu	t Data : t Data :	6Words 6Words	
PPO type5	PKE	IND	P١	VE	STW / ZSW	HSW / HIW	ECW / ESW	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved
											C	Input D Dutput D	ata : 14 ata : 14	Words Words
	1Word	Pł	γ <w< td=""><td></td><td></td><td></td><td></td><td></td><td>PZ</td><td>Ώ</td><td></td><td></td><td></td><td></td></w<>						PZ	Ώ				

#### 7.2 ID Definitions

	ID	Definition
	PKE	PNU number (PNU) and task or response Id (AK)
PKW/	IND	Sub-Index number and reserved area for extension
1100	PWE	Set 0 since high bits (Bits 16 to 31) are not used. Low bits (Bits 0 to 15): Parameter value
	STW/ZSW	STW: Control Word (Command request)*
		ZSW: Status Word (command response)*
	HSW/HIW	HSW: Set frequency (command request)*
P7D		HIW: Output frequency (command response)*
ΓZD		ECW: Extended Control Word (Command request)*
	LGW/EGW	ECW: Extended Status Word (Command response)*
	Reserved	Reserved area for extension

\*Command request:Message from the master to the slave Command response:Message from the slave to the master



#### 7.3 Buffer Memory Map

The following shows the buffer memory map of the PPO type1 to PPO type5 Profibus profiles.

type	1Word	2Word	3Word	4Word	5Word	6Word	7Word	8Word	9Word	10Word	11Word	12Word	13Word	14Word	
PPO type1	PKE	IND	PV	VE	STW / ZSW	HSW / HIW									
PPO					STW//		ECW//								
type2	PKE	IND	PV	VE	ZSW	HIW	ECW/ ESW	Reserved	Reserved	Reserved					1
					1 1 1			1							i
PPO type3	STW / ZSW	HSW / HIW			     			   							1
								1 1 1							
PPO type4	STW / ZSW	HSW / HIW	ECW / ESW	Reserved	Reserved	Reserved									1
					1			1							J
PPO type5	PKE	IND	PV	VE	STW / ZSW	HSW / HIW	ECW / ESW	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	

#### Module



The buffer memory configuration is shown below.



For buffer memory details, refer to page 39.



#### 7.5 Buffer Memory Details

The following indicates the build memory details of the Frombus promes.	The following	indicates the	e buffer memor	y details of the	Profibus profiles.
---	---------------	---------------	----------------	------------------	--------------------

	Nar	ne	Bit	Definition
		PNU	0 to 10	PNU number
		SPM	11	Not used (0 is set)
PKW	PKE	AK	12 to 15	[Command request]         0       : No task         1       : Parameter value is requested (read request)         2       : Parameter value (word) is changed (write request)         3 to 5       : Non-supported         6       : Parameter value (array) is requested (read request)         7       : Parameter value (array word) is changed (write request)         8 to 15       : Non-supported         [Command response]       0         0       : No response (Busy status)         1       : Parameter value (word) is transferred.         2 to 3       : Non-supported         4       : Parameter value (array word) is transferred.         5 to 6       : Non-supported         7       : Command execution error (error number is stored into PWE)         8 to 15: Non-supported       : Store into PWE)
			0 to 7	Reserved area for extension (0 is set)
		IND	8 to 15	Sub-Index number At command request, set this number when AK =6, 7.

7

 $\sim$ 

	Name	Bit	Definition
	Name	Bit	Definition         PNU read value/write value         When command response AK = 7 (command execution error), PWE definition is as follows.         Error Definition         0       Invalid PNU         1       Parameter value unchangeable (This error also occurs when <i>Pr:77=1</i> )         2       Outside setting range         3       Invalid Sub-Index number         4       Without array         11       No parameter change right
PKW	PWE	0 to 15	3       Invalid Sub-Index number         4       Without array         11       No parameter change right         18       Other error *         * Error Definition         • Outside AK number range       • Write data error         • External operation error       • Without option error         • Instruction code error       • With STF error         • With STF error       • With operation mode specification error         • Outside AK number range       • Outside AK number range         • Parameter calibration error ( <i>Pr. 900</i> and later)
		16 to 21	Reset disabled error (per <i>Pr.</i> 75 reset input specification)
		101031	ואטר נושבע (ט וש שבר)

	Nar	ne	Bit	Definition
		_	0 to 2	Not used (1 is set)
		Control enable	3	0: Inverter output shutoff 1: Inverter output shutoff is cancelled
		_	4 to 6	Not used (1 is set)
		Fault reset (Reset)	7	<ul> <li>[At inverter error]</li> <li>0: No action</li> <li>1: When <i>Pr. 349</i>=0, error reset can be made in any operation mode. When <i>Pr. 349</i>=1, error reset is enabled only in NET operation mode.</li> <li>[When inverter is normal] No action</li> </ul>
			8 to 9	Not used (0 is set)
PZD	STW	PZD enable	10	0: Command request of PZD is not processed.*1 1: Command request of PZD is processed. • At power-on or inverter reset, set 1 once.
		STF signal	11	0: OFF 1: ON (forward rotation command)
		STR signal	12	0: OFF 1: ON (reverse rotation command)
		RT terminal	13	0: OFF 1: ON · Functions are changed according to the <i>Pr. 183</i> setting.
		MRS terminal	14	<ul> <li>0: OFF</li> <li>1: ON (output is shut off)</li> <li>Functions are changed according to the <i>Pr</i>:187 setting. However, do not change the factory-set value "6".</li> </ul>
		RAM/ EEPROM	15	<ol> <li>O: Set frequency (HSW) is written to RAM (Power-on reset returns the changed set frequency to the setting before it was written to RAM.).</li> <li>1: Set frequency (HSW) is written to EEPROM.</li> </ol>

\*1 PZD enable and command count request can be executed.

	Nar	ne	Bit	Definition
		_	0 to 2	Not used (1 is returned)
		Fault	3	0: Inverter normal 1: Inverter alarm occurrence
		_	4 to 5	Not used (1 is returned)
		Power-on inhibit	6	0 is returned
		Alarm	7	Command execution normal Command execution error
		_	8	Not used (0 is returned)
P7D	ZD ZSW F	Control request	9	1 is returned
		FU signa	FU signal	10
		RUN signal	11	0: OFF 1: ON (inverter running)
		FWD	12	0: Other than forward running (during stop, reverse running) 1: Forward running
		REW	13	<ul><li>0: Other than reverse running (during stop, forward running)</li><li>1: Reverse running</li></ul>
		Operation mode	14	0: Other than network operation mode 1: Network operation mode

	Nar	ne	Bit		Definiti	on			
DZD	ZSW	BUSY	15	0: Read 1: Busy *If it tak annou respoi maste respoi	dy status x status * xes time to perform slave side proce inced since reply to the master will the nse data are unfixed values. When the r is invalid. Therefore, the same reconse data of the FR-A7NP during Bu	essing, slave side busy status is be delayed. During busy status, other he slave side is busy, request from the guest must be sent again. The sy status is as follows.			
PZD					During Busy status and inverter reset	During Busy status and other than inverter rest			
				PKW	0	All 0 when AK=0 Reply data when AB $\neq$ 0			
				PZD ZSW Bit15=1 ZSW B Other error Bit=0 Other e		ZSW Bit15=1 Other error Bit=inverter status data			
	HSW		0 to 15	Set free	quency (0.01 Hz increments)				
		HIW	0 to 15	Output	put frequency (0.01 Hz increments)				

7

/

	Nar	ne	Bit	D	Definition				
		Terminal RH	0	High speed operation command*					
		Terminal RM	1	Middle-speed operation command*	Functions assigned to terminal RH, RM,				
		Terminal RL	2	Low-speed operation command*	RL, JOG, AU and CS are activated. *Signal names are initial values. Using <i>Pr.180</i>				
	ECW	Terminal JOG	3	Jog operation command*	output signal functions. Refer to the invert manual (applied) for details of <i>Pr. 180 to</i>				
		Terminal AU	4	Current input selection*	Pr.182, Pr. 184 to Pr. 186.				
070		Terminal CS	5	Selection of automatic restart after instantaneous power failure*					
PZD		_	6 to 7	Not used (0 is set)					
		Command count	8 to 15	Jsed by the master to recognize the command response.					
		SU signal	0	0: OFF 1: ON (up to frequency)					
		OL signal	1	0: OFF 1: ON (overload alarm)					
	ESW	IPF signal	2	0: OFF 1: ON (an instantaneous power failur	e or undervoltage occurs)				
		_	3 to 7	Not used (0 is set)					
		Command count	8 to 15	Echo back of the command request.					
	Reserved		0 to 15	Not used (0 is set, 0 is returned)					

#### ----- CAUTION =

Only when the contents of the command request (request for changing the inverter setting: PKW, HSW, STW/ ECW) from the master changed, the inverter processes the request. If the contents of the command request are identical with those of the last request, the inverter does not process the request. (The received request is cleared.)

For instance, while the master keeps sending the "network operation mode enabled" command, changing the mode to the PU operation mode with switchover function does not allow the "network operation mode enabled" command to be executed due to the same contents as that sent last time. Therefore, the operation mode remains the PU operation mode without changing to the network operation mode. In this case, send another command as "PU operation mode enabled" from the master once, then send the

"network operation mode enabled" command again.

#### 7.6 Outline of PNU

You can use the PNU to make inverter settings from the network. The data used with the network is denoted PNU(P) to differentiate it from the parameter (Pr.). This chapter explains the Module type "PPO type 1" to "PPO type 5".

#### 

Parameter definitions differ according to the Module type selected. When using "A5NP", refer to page 67.

(1) PNU data definition

P<u>1902.1</u> Sub-Index Number — When the data type is "with array", the Sub-Index number is included in the PNU.

(2) PNU data type

The PNU has the data types of "Array Unsigned 16" and "Unsigned 16".

Array Unsigned 16 :(AUs16) P1902. <u>1</u> Sub-Index Number	With array	When the data type is "with array", include the Sub-Index number in the PNU.
Unsigned 16 :(Us16) P1240	Without array	

#### 7.7 Profibus PNU

#### 7.7.1 Real-time monitor

The following items can be monitored from the master.

PNU	ltem	Increments	Data Type	PNU	ltem	Increments	Data Type
P1.1	Output frequency	0.01Hz	AUs16	P1.13	Input power	0.01kW/ 0.1kW*	AUs16
P1.2	Output current	0.01A/ 0.1A*	AUs16	P1.14	Output power	0.01kW/ 0.1kW*	AUs16
P1.3	Output voltage	0.1V	AUs16	P1.15	Input terminal status (refer to 1) on the next page )	_	AUs16
P1.5	Frequency setting	0.01Hz	AUs16	P1.16	Output terminal status (refer to 2) on the next page )	_	AUs16
P1.6	Running speed	1r/min	AUs16	P1.17	Load meter	0.1%	AUs16
P1.8	Converter output voltage	0.1V	AUs16	P1.20	Cumulative energization time	1h	AUs16
P1.9	Regenerative brake duty	0.1%	AUs16	P1.23	Actual operation time	1h	AUs16
P1.10	Electronic thermal relay function load factor	0.1%	AUs16	P1.24	Motor load factor	0.1%	AUs16
P1.11	Output current peak value	0.01A/ 0.1A*	AUs16	P1.25	Cumulative power	1kWh	AUs16
P1.12	Converter output voltage peak value	0.1V	AUs16	P1.50	Power saving effect	Differ according to Pr.	AUs16

\*The setting depends on the inverter capacity. (55K (FR-F720-02330, FR-F740-01160) or less/75K (FR-F720-03160, FR-F740-01800) or more)

PNU	Item	Increments	Data Type	PNU	Item	Increments	Data Type
P1.51	Cumulative saving power	Differ according to Pr.	AUs16	P1.53	PID measurement value	0.1%	AUs16
P1.52	PID set point	0.1%	AUs16	P1.54	PID deviation	0.1%	AUs16

(1) External input terminal status PWE bit map

b15														b0
	_	_	CS	RES	STOP	MRS	JOG	RH	RM	RL	RT	AU	STR	STF

\*Functions of each terminal are assigned using Pr:178 to Pr:189.

(Refer to the inverter manual for details)

(2) External output terminal status PWE bit map

b15															b0
—	_	_	_	_	_	_	_	_	ABC2	ABC1	FU	OL	IPF	SU	RUN

\*Functions of each terminal are assigned using Pr.190 to Pr.196.

(Refer to the inverter manual for details)

#### 7.7.2 Parameter clear

Parameter clear can be performed from the master.

PNU	Item	Data Definition	Data Type
P2.2	Parameter clear	965Ан	AUs16
P2.3	All parameter clear	99ААн	AUs16
P2.5	Parameter clear *1	5А96н	AUs16
P2.6	All parameter clear *1	АА99н	AUs16
P2.8	Error history clear	0000н	AUs16

\*1 Communication parameters (Pr. 117 to Pr. 124, Pr. 331 to Pr. 341, Pr. 343, Pr. 349, Pr. 549 to Pr. 551) are not cleared.

#### 7.7.3 Operation mode read/write

Read/write of the operation mode can be performed from the master.

PNU	Item	Data Definition	Data Type
Р3	Operation mode read/write	External operation mode:10 H PU operation mode: 11H ( <i>Pr:79</i> ="6") Network operation mode:14H	Us16

#### 7.7.4 Set frequency read

The frequency set to the inverter can be read from the master.

PNU	Item	Data Definition	Data Type
P4.1	Set frequency (RAM) read	Set frequency (RAM) is read.	AUs16
P4.2	Set frequency (EEPROM) read	Set frequency (EEPROM) is read.	AUs16



#### 7.7.5 Terminal input read

Analog input value of terminal 2, 4, 1 can be read.

PNU	Item	Data Definition	Data Type
P5.1	Terminal 2 input value read	Terminal 2 input value (%) is read.	Us16
P5.2	Terminal 4 input value read	Terminal 4 input value (%) is read.	Us16
P5.3	Terminal 1 input value read	Terminal 1 input value (%) is read.	Us16

#### 7.7.6 Inverter reset

The inverter can be reset from the master.

PNU	Item	Data Definition	Data Type	
P6	Inverter reset	The inverter is reset after the data was written from the master.	Us16	

· The inverter maintains the resetting status while reset is requested.

• When  $Pr.75 \neq$  "0, 2, 14, 16", reset is enabled only during an inverter error.

#### 7.7.7 Node address read

The node address of the inverter can be read.

PNU	Item	Data Definition	Data Type
P918	Node address read	Set node address is read.	Us16

#### 7.7.8 Alarm definition read

(1) Alarm definitions of past eight alarms occurred in the inverter can be read. (refer to page 52 for error number)

PNU	Item	Data I	Data Definition		
P947.1 to P947.8	Latest alarm is read	P947.1 P947.2 to P947.8	:error number :all 0	AUs16	
P947.9 to P947.16	Second alarm in past is read	P947.9 P947.10 to P947.16	:error number :all 0	AUs16	
P947.17 to P947.24	Third alarm in past is read	P947.17 P947.18 to P947.24	:error number :all 0	AUs16	
P947.25 to P947.32	Forth alarm in past is read	P947.25 P947.26 to P947.32	:error number :all 0	AUs16	
P947.33 to P947.40	Fifth alarm in past is read	P947.33 P947.34 to P947.40	:error number :all 0	AUs16	
P947.41 to P947.48	Sixth alarm in past is read	P947.41 P947.42 to P947.48	:error number :all 0	AUs16	
P947.49 to P947.56	Seventh alarm in past is read	P947.49 P947.50 to P947.56	:error number :all 0	AUs16	
P947.57 to P947.64	Eighth alarm in past is read	P947.57 P947.58 to P947.64	:error number :all 0	AUs16	

<Alarm data>

Error Number	Definition	Error Number	Definition	Error Number	Definition
00н	No fault present	52H	E.ILF	ВЗн	E.PE2
10н	E.OC1	60н	E.OLT	С0н	E.CPU
11н	E.OC2	70н	E.BE	С1н	E.CTE
12н	E.OC3	80н	E.GF	С2н	E.P24
20н	E.OV1	81н	E.LF	С4н	CDO
21н	E.OV2	90н	E.OHT	С5н	IOH
22н	E.OV3	91н	E.PTC	С6н	SER
30н	E.THT	АОн	E.OPT	С7н	AIE
31н	E.THM	А1н	E.OP1	F1H	E. 1
40н	E.FIN	В0н	E.PE	<b>F</b> 6н	E. 6
50н	E.IPF	В1н	E.PUE	F7H	E. 7
51H	E.UVT	В2н	E.RET	FDH	E. 13

Refer to the inverter manual for details of alarm definitions.

(2) Energization time (fault monitor) for past eight alarms at the inverter alarm occurrence can be read.

PNU	Item	Data D	Definition	Data Type
P948.1 to P948.8	Latest fault monitor energization time read	P948.1 P948.2 to P948.8	:energization time :all 0	AUs16
P948.9 to P948.16	Energization time of second fault monitor in past read	P948.9 P948.10 to P948.16	:energization time :all 0	AUs16
P948.17 to P948.24	Energization time of third fault monitor in past read	P948.17 P948.18 to P948.24	:energization time :all 0	AUs16
P948.25 to P948.32	Energization time of forth fault monitor in past read	P948.25 P948.26 to P948.32	:energization time :all 0	AUs16
P948.33 to P948.40	Energization time of fifth fault monitor in past read	P948.33 P948.34 to P948.40	:energization time :all 0	AUs16
P948.41 to P948.48	Energization time of sixth fault monitor in past read	P948.41 P948.42 to P948.48	:energization time :all 0	AUs16
P948.49 to P948.56	Energization time of seventh fault monitor in past read	P948.49 P948.50 to P948.56	:energization time :all 0	AUs16
P948.57 to P948.64	Energization time of eighth fault monitor in past read	P948.57 P948.58 to P948.64	:energization time :all 0	AUs16

(3) Output frequency, output current and output voltage for past eight alarms at the inverter alarm occurrence can be read.

PNU	ltem	Data D	Data Definition		
P949.1 to P949.8	Latest fault monitor frequency, current and voltage read	P949.1 P949.2 P949.3 P949.4 to P949.8	:output frequency :output current :output voltage :all 0	AUs16	
P949.9 to P949.16	Second fault monitor frequency, current and voltage in past read	P949.9 P949.10 P949.11 P949.12 to P949.16	:output frequency :output current :output voltage :all 0	AUs16	
P949.17 to P949.24	Third fault monitor frequency, current and voltage in past read	P949.17 P949.18 P949.19 P949.20 to P949.24	:output frequency :output current :output voltage :all 0	AUs16	
P949.25 to P949.32	Forth fault monitor frequency, current and voltage in past read	P949.25 P949.26 P949.27 P949.28 to P949.32	:output frequency :output current :output voltage :all 0	AUs16	
P949.33 to P949.40	Fifth fault monitor frequency, current and voltage in past read	P949.33 P949.34 P949.35 P949.36 to P949.40	:output frequency :output current :output voltage :all 0	AUs16	
P949.41 to P949.48	Sixth fault monitor frequency, current and voltage in past read	P949.41 P949.42 P949.43 P949.44 to P949.48	:output frequency :output current :output voltage :all 0	AUs16	
P949.49 to P949.56	Seventh fault monitor frequency, current and voltage in past read	P949.49 P949.50 P949.51 P949.52 to P949.56	:output frequency :output current :output voltage :all 0	AUs16	
P949.57 to P949.64	Eighth fault monitor frequency, current and voltage in past read	P949.57 P949.58 P949.59 P949.60 to P949.64	:output frequency :output current :output voltage :all 0	AUs16	



#### 7.7.9 PNU list read

The usable PNU numbers can be read.

P980.1 to 116 P981.1 to 116 P982.1 to 116 P983.1 to 116	PNU	Item	Data Definition	Data Type
P984.1 to 116 P985.1 to 116 P985.1 to 116 P986.1 to 116 P987.1 to 116 P988.1 to 116 P988.1 to 116	P980.1 to 116 P981.1 to 116 P982.1 to 116 P983.1 to 116 P983.1 to 116 P985.1 to 116 P985.1 to 116 P986.1 to 116 P988.1 to 116	PNU list read	Usable PNU numbers are read in sorted status.	AUs16

PNU list read example

PNU	Usable PNU number	REMARKS
P980.1	1	
P980.2	2	
P980.3	3	inverter command parameter
÷	:	
P980.116	1000	
P981.1	1001	
P981.2	1002	Inverter standard parameter
:	÷	
P982.111	0*1	

\*1 When 0 is stored, read is terminated.



#### 7.8 Standard Parameters

You can use the PNU to make parameter settings from the network.

The table below lists PNU numbers corresponding to parameter numbers.

Standard parameter examples are introduced below. Refer to the examples and make parameter settings. Refer to the inverter manual for details of the parameters.

Representation of the PNU for standard parameters (Example: Pr.902)



#### Example of parameter list

Parameter			Minimum	Setting	Range	Data
Number	PNU	Name	Setting Increments	Decimal	Hexadecimal	Туре
0	P1000	Torque boost	0.1%	0 to 30	0 to 12C	Us16
1	P1001	Maximum frequency	0.01Hz	0 to 120	0 to 2EE0	Us16
2	P1002	Minimum frequency	0.01Hz	0 to 120	0 to 2EE0	Us16
3	P1003	Base Frequency	0.01Hz	0 to 400	0 to 9C40	Us16
4	P1004	Multi-speed setting (high speed)	0.01Hz	0 to 400	0 to 9C40	Us16
5	P1005	Multi-speed setting (middle speed)	0.01Hz	0 to 400	0 to 9C40	Us16
6	P1006	Multi-speed setting (low speed)	0.01Hz	0 to 400	0 to 9C40	Us16
:	÷	:	:	÷	:	:

EXECUTION =

Write to Pr. 77 and Pr. 79 is not allowed from the network with the FR-A7NP. (Read is allowed.)

The following parameters require the Sub-Index number for the PNU.

Parameter			Minimum	Settin	Data	
Number	PNU Name		Setting Increments	Decimal	Hexadecimal	Туре
900	P1900.1	FM terminal calibration	—	—	—	AUs16
901	P1901.1	AM terminal calibration *	—	—	—	AUs16
002	P1902.1	Terminal 2 frequency setting bias frequency	0.01Hz	0 to 400	0 to 9C40	AUs16
902	P1902.2	Terminal 2 frequency setting bias	0.1%	0 to 300	0 to BB8	AUs16
003	P1903.1	Terminal 2 frequency setting gain frequency	0.01Hz	0 to 400	0 to 9C40	AUs16
903	P1903.2	Terminal 2 frequency setting gain	0.1%	0 to 300	0 to BB8	AUs16
004	P1904.1	Terminal 4 frequency setting bias frequency	0.01Hz	0 to 400	0 to 9C40	AUs16
904	P1904.2	Terminal 4 frequency setting bias	0.1%	0 to 300	0 to BB8	AUs16
005	P1905.1	Terminal 4 frequency setting gain frequency	0.01Hz	0 to 400	0 to 9C40	AUs16
905	P1905.2	Terminal 4 frequency setting gain	0.1%	0 to 300	0 to BB8	AUs16

\*For the NA, EC and CH version, the terminal name is CA terminal calibration.

# MEMO

### 8

### **PPO TYPE NON SUPPORT SPECIFICATION**

### **8.1 Profibus Profiles**

The option unit operates as a "slave of the Profibus DP master" or a "controller equivalent to Profibus DP master class 1 on an RS-485 network".

The Profibus profile (data buffer) can be selected from among six different types, "PPO type1" to "PPO type5", "A5NP".

This chapter explains the Module type "A5NP" profile. For the Module type "PPO type1" to "PPO type5" profiles, refer to page *35*.

Module type is changed with the slave module setting. For details, refer to the instruction manual of the Network Master Configuration Software.

#### REMARKS

The "A5NP" profile is compatible with the FR-A5NP profile.

Use "A5NP" profile when replacing the FR-A5NP with FR-A7NP, etc.

The configuration of the "A5NP" is as follows.



#### 8.2 ID definitions

ID		Definition
	PKE	PNU number (PNU) and task or response Id (AK)
	IND	Index number
PRV	PWE	Set 0 since high bits (Bits 16 to 31) are not used.
		Lower (Bits 16 to 31): Parameter value
PZD		Bits 0 to 7: Inverter status
	ZSW	(Command response)
		Bits 8 to 14: Command count
		(command request/response)
	HIW	Reserved area for extension

\*Command request:Message from the master to the slave

Command response:Message from the slave to the master

#### 8.3 Buffer memory map

The following shows the buffer memory map of the A5NP Profibus profiles.

Module tupe	1Word 2Word 3Word 4Word 5Word 6W					6Word	
A5NP	PKE	IND	PV	VE	ZSW	HIW	

#### **8.4 Buffer Memory Configuration**



#### **8.5 Buffer Memory Details**

The following indicates the buffer memory details of the Profibus profiles.

Name		Bit	Definition	
		PNU	0 to 10	PNU number (Together, the PNU and the IND define which data word is being accessed.)
		PNU number	11	Not used (0 is set)
PKW	PKE	AK	12 to 15	[Command request]         0       : No task         1       : Parameter value is requested (read request)         2       : Parameter value (word) is changed (write request)         3 to 15: Non-supported         [Command response]         0       : No response (Busy status)         1       : I nverter can accept data (Ready status)         2 to 6 : Not-used         7       : Command execution error (error number is stored into PWE)         8       : No operation change rights         9 to 15: Not used

Name			Bit	Definition	
PKW	IND	РР	0 to 7	Page Index : If IND = 01 (system environment variables(sev)), the PP values specify dif blocks of sev's: PP = 0 : sev_I, block I PP = 1 : sev_II, block II (alarm history) PP = 2 : sev_III, block III (For details, refer to <i>page 69</i> .) If IND is other than 01, set PP to 0.	
		IND	8 to 15	Parameter Index : Specifies the area from which Parameter Number (PNU) is being accessed. (For details, refer to <i>page 68.</i> ) IND = 0H: real-time monitor area IND = 1H: system environment variable area (3 blocks) IND = 2H: normal parameter area IND = 3H: <i>Pr. 900</i> to frequency parameter area IND = 4H: <i>Pr. 900</i> to frequency parameter area	

	Name	Bit	Definition			
PKW			PNU read value/write value         When command response AK = 7 (command execution error), PWE definition         is as follows.         PNU         Error Definition		nition	
			0н	Without error		
			1н	Unsupported task (includs writing)		
	PWE	0 to 15	2н	Invalid Index (IND)		
			3н	Invalid PNU		
			6н	Invalid page index (PP)		
			41H	Mode error		
			42H	Instruction code error		
			43H	Data setting range error		
		16 to 31	Not used (0 is set)			
		10 10 31	NOT USED (U IS SET)			

Name			Bit	Definition		
PZD	ZSW	RUN signal	0	0 : OFF 1 : ON (inverter running)		
		FWD signal	1	0 : OFF 1 : ON (forward rotation operation being performed)	For master-to-slave messages (command request), bits 0 to 7 are not used and must be set to 0. The bit-wise data here do not reflect <i>Pr:190 to Pr: 196</i> (output terminal function selection). At command response, signals are the same. Signals are not affected by settings of <i>Pr:190 to Pr:196</i> (output terminal function selection).	
		REV signal	2	0 : OFF 1 : ON (reverse rotation operation being performed)		
		SU signal	3	0 : OFF 1 : ON (up to frequency)		
		OL signal	4	0 : OFF 1 : ON (overload alarm)		
		IPF signal	5	0 : OFF 1 : ON (an instantaneous power failure or undervoltage occurs)		
		FU signal	6	0 : OFF 1 : ON (output frequency being detected)		
		ABC signal 7		0 : Inverter normal 1 : Inverter alarm occurrence		
		Command count	8 to 14	Command count The command count is an optiona and can range from 00H to 7FH. The option unit copies the comman same byte offset in the response in synchronize commands and response	I feature maintained by the Profibus master nd count from the command it receives to the t sends. The master may use this to onses.	
	_		15	Not used (0 is set)		
	HIW		0 to 15	Not used (0 is set)		
#### 

Only when the contents of the command request (request for changing the inverter setting: PKW) from the master changed, the inverter processes the request. If the contents of the command request are identical with those of the last request, the inverter does not process the request. (The received request is cleared.)

For instance, while the master keeps sending the "network operation mode enabled" command, changing the mode to the PU operation mode with switchover function does not allow the "network operation mode enabled" command to be executed due to the same contents as that sent last time. Therefore, the operation mode remains the PU operation mode without changing to the network operation mode. In this case, send another command as "PU operation mode enabled" from the master once, then send the

In this case, send another command as "PU operation mode enabled" from the master once, then send the "network operation mode enabled" command again.

## 8.6 Outline of PNU

You can use the PNU to make inverter settings from the network. The data used with the network is denoted PNU(P) to differentiate it from the parameter (Pr.). This chapter explains the Module type "A5NP".

#### 

Parameter definitions differ according to the Module type selected. When using "PPO type1" to "PPO type5", refer to *page 46*.

## 8.7 Profibus PNU (Module Type A5NP)

## 8.7.1 Real time monitor area (IND=0000н)

The following items can be monitored from the master.

IND	PNU	Item	Increments	IND	PNU	Item	Increments
0000н	0н	Output frequency	0.01Hz	0000н	Ен	Input terminal status	—
0000н	1н	Output current	0.01A/0.1A*	0000н	Fн	Output terminal status	
0000н	2н	Output voltage	0.1V	0000н	10н	Load meter	0.1%
0000н	3н	Frequency setting	0.01Hz	0000н	13н	Cumulative energization time	1Hr
0000н	5н	Running speed	1r/min	0000н	16н	Actual operation time	1Hr
0000н	7н	Converter output voltage	0.1V	0000н	17н	Motor load factor	0.1%
0000н	8н	Regenerative brake duty	0.1%	0000н	<b>18</b> н	Cumulative power	0.01kWh
0000н	9н	Electronic thermal relay function load factor	0.1%	0000н	31н	Power saving effect	Differ according to Pr.
0000н	Ан	Output current peak value	0.01A/0.1A*	0000н	32н	Cumulative saving power	Differ according to Pr.
0000н	Вн	Converter output voltage peak value	0.1V	0000н	33н	PID set point	0.1%
0000н	Сн	Input power	0.01kW/ 0.1kW∗	0000н	34н	PID measured value	0.1%
0000н	Dн	Output power	0.01kW/ 0.1kW∗	0000н	35н	PID deviation	0.1%

\*The setting depends on the inverter capacity. (55K (FR-F720-02330, FR-F740-01160) or less/75K (FR-F720-03160, FR-F740-01800) or more)

## 8.7.2 System environment variable (sev) area (IND = 01PPн)

## SEV Interface (IND = 0100H, PP = 00, SEV\_I, Block I)

#### (1) Parameter clear

Parameter clear can be performed from the master.

IND	PNU	Item	Data Definition
0100н	1н	Inverter reset	
0100н	2н	Parameter clear	WriteVal = 965AH
0100н	3н	All parameter clear	WriteVal = 99ААн
0100н	5н	Parameter clear *1	WriteVal = 5А96н
0100н	6н	All parameter clear *1	WriteVal = AA99н

\*1 Communication parameters (Pr. 117 to Pr. 124, Pr. 331 to Pr.341, Pr.343, Pr. 349, Pr.549 to Pr.551) are not cleared.

#### PPO TYPE NON SUPPORT SPECIFICATION

(2) Inverter status/operation command The inverter status can be monitored and operation command can be given from the master.

IND	PNU	Item					
		Inverter status Refer to page 65					
		Run command					
		Name	Bit	Defini	tion		
		—	0	Reserved (0 is set)			
		Terminal STF	1	Forward rotation command			
	Ан	Terminal STR	2	Reverse rotation command			
			Terminal RH	3	High-speed operation command *		
0100н		Terminal RM	4	Middle-speed operation command *	and MRS are activated		
		Terminal RL	5	Low-speed operation command *	*Signal names are initial values.		
		Terminal JOG	6	JOG operation selection *	Using Pr. 180 to Pr .187, you can		
			Terminal RT	7	Second function selection *	change output signal functions.	
		Terminal AU	8	Terminal 4 input selection *	(applied) for details of $Pr$ 180 to		
					Terminal CS	9	Restart after instantaneopus power failure selection *
		Terminal MRS	10	Inverter output shut off *	1		
				11 to 15	Not used (0 is set)		

#### (3) Operation mode write

Write of the operation mode can be performed from the master.

IND	PNU	Item	Data Definition
0100н	Вн	Operation mode	External operation mode:10H PU operation mode:11H (When <i>Pr:79</i> = "6") Network operation mode:14H

#### (4) Set frequency read/write

The frequency set to the inverter can be read/written from the master.

IND	PNU	ltem	Data Definition
0100н	DH	Set frequency (RAM) *1	Set frequency (RAM) is read or written.
0100н	Ен	Set frequency (EEPROM) *1,2	Write set frequency to EEPROM.

\*1 Writing to PNU = DH or PNU = EH can be read out from PNU = DH.

\*2 To change the running frequency consecutively, always write data to the inverter RAM.

### Alarm History (IND = 0101H, PP = 01, SEV\_II, Block II)

The past eight inverter alarm definitions can be read.

IND	PNU	Item	IND	PNU	ltem
0101н	0н	Latest alarm *3	0101н	4н	Fifth alarm in past is read
0101н	1н	Second alarm in past is read	0101н	5н	Sixth alarm in past is read
0101н	2н	Third alarm in past is read	0101н	6н	Seventh alarm in past is read
0101н	3н	Forth alarm in past is read	0101н	7н	Eighth alarm in past is read

\*3 Writing a value of 0000H to this parameter resets all alarm history. All other parameters at this index are read only.

#### PPO TYPE NON SUPPORT SPECIFICATION

<Alarm data>

Error Number	Definition	Error Number	Definition	Error Number	Definition
00н	No fault present	52н	E.ILF	ВЗн	E.PE2
10н	E.OC1	60н	E.OLT	С0н	E.CPU
11н	E.OC2	70н	E.BE	С1н	E.CTE
12н	E.OC3	80н	E.GF	С2н	E.P24
20н	E.OV1	81н	E.LF	С4н	CDO
21н	E.OV2	90н	E.OHT	С5н	IOH
22н	E.OV3	91н	E.PTC	С6н	SER
30н	E.THT	АОн	E.OPT	С7н	AIE
31н	E.THM	А1н	E.OP1	F1H	E. 1
40н	E.FIN	В0н	E.PE	F6н	E. 6
50H	E.IPF	В1н	E.PUE	F7H	E. 7
51н	E.UVT	В2н	E.RET	FDH	E. 13

Refer to the inverter manual for details of alarm definitions.

## **8.8 Standard Parameters**

## 8.8.1 Normal parameter area (IND = 0200н)

You can use the PNU to make parameter settings from the network.

The table below lists PNU numbers corresponding to parameter numbers.

Standard parameter examples are introduced below. Refer to the examples and make parameter settings. Refer to the inverter manual for details of the parameters.

#### Example of parameter list

	Parameter			Minimum	Setting	Range
IND	Number	PNU	Name	Setting Increments	Decimal	Hexadecimal
	0	0н	Torque boost	0.1%	0 to 30	0 to 12C
	1	1н	Maximum frequency	0.01Hz	0 to 120	0 to 2EE0
	2	2н	Minimum frequency	0.01Hz	0 to 120	0 to 2EE0
0200	3	3н	Base Frequency	0.01Hz	0 to 400	0 to 9C40
0200H	4	4н	Multi-speed setting (high speed)	0.01Hz	0 to 400	0 to 9C40
	5	5н	Multi-speed setting (middle speed)	0.01Hz	0 to 400	0 to 9C40
	6	6н	Multi-speed setting (low speed)	0.01Hz	0 to 400	0 to 9C40
	:	:	:	÷	:	:

CAUTION =

Write to Pr. 77 and Pr. 79 is not allowed from the network with the FR-A7NP. (Read is allowed.)

## 8.8.2 Pr. 900 to calibration parameter (frequency) area (IND=0300н)

The following parameters can be set with IND=0300H.

Parameter				Minimum	Setting Range	
Number	IND	PNU	Name	Setting Increments	Decimal	Hexadecimal
900	0300н	147н	FM terminal calibration	1	0 to 8191	0 to 1FFF
901	0300н	148н	AM terminal calibration *	1	0 to 8191	0 to 1FFF
902	0300н	149н	Terminal 2 frequency setting bias frequency	0.01Hz	0 to 400	0 to 9C40
903	0300н	14Ан	Terminal 2 frequency setting gain frequency	0.01Hz	0 to 400	0 to 9C40
904	0300н	14Вн	Terminal 4 frequency setting bias frequency	0.01Hz	0 to 400	0 to 9C40
905	0300н	14Сн	Terminal 4 frequency setting gain frequency	0.01Hz	0 to 400	0 to 9C40

\*For the NA, EC and CH version, the terminal name is CA terminal calibration.

## 8.8.3 Pr. 900 to calibration parameter (%) area (IND=0400H)

The following parameters can be set with IND=0400H.

Parameter Number	IND	PNU	Name	Minimum Setting Increments
902	0400н	2н	Terminal 2 frequency setting bias	0.1%
903	0400н	3н	Terminal 2 frequency setting gain	0.1%
904	0400н	4н	Terminal 4 frequency setting bias	0.1%
905	0400н	5н	Terminal 4 frequency setting gain	0.1%

## 8.8.4 Terminal input read (IND=0500н)

When IND=0500H, the analog input values of terminal 2, 4, 1 can be read.

IND	PNU	Name	Minimum Setting Increments
0400н	1н	Terminal 2 input value read	0.1%
0400н	2н	Terminal 4 input value read	0.1%
0400н	3н	Terminal 1 input value read	0.1%

# MEMO

# 9

# TROUBLESHOOTING

If an alarm occurred in the inverter and the inverter and option unit do not function, refer to the following check points, find the cause from the operation panel indication of the inverter and the LED status of the option unit, and take an adequate action. If any of the causes does not apply to the alarm, a failure may have occurred. In that case, contact your sales representative.

Operation Panel Indication	Option Unit LED Status	Assumed Cause	Check Point
			Make sure that the option is fitted properly.
		Option unit does not	Reset the inverter.
		function	Perform parameter all clear to return the parameters to the factory settings, and switch power off once, then on again.
	Off	Network is instable	Make sure that the network cables between the nodes are connected properly.
0.00			Make sure that the network cables are terminated.
			Check the network setting from the Profibus-DP Network Configuration Software.
			Check the other nodes for a network error.
		Network master does not exist or does not function properly	Check the connection and operation of the Profibus-DP master.
E.***	Red is lit	Inverter in error	Refer to the inverter manual.

\*The error code of the inverter enters.

#### REVISIONS

\*The manual number is given on the bottom left of the back cover.

Print Date	*Manual Number	Revision
Nov., 2004	IB(NA)-0600214ENG-A	First edition