

# User Manual

High Performance/Flexible Options/ Micro Type AC Motor Drives



### Power Range:

1-phase 115V series:0.2~0.75kW (0.25~1HP)

1-phase 230V series: 0.2~2.2kW (0.25~3HP)

3-phase 230V series:0.2~15kW (0.25~20HP)

3-phase 460V series:0.4~22kW (0.50~30HP)



### www.delta.com.tw/industrialautomation

# ASIA Taoyuan1

### Delta Electronics, Inc.

31-1, Xingbang Road, Guishan Industrial Zone, Taoyuan County 33370, Taiwan, R.O.C TEL: 886-3-362-6301 / FAX: 886-3-362-7267

### Delta Electronics (Jiang Su) Ltd.

Wujiang Plant3

1688 Jiangxing East Road, Wujiang Economy Development Zone, Wujiang City, Jiang Su Province, People's Republic of China (Post code: 215200) TEL: 86-512-6340-3008 / FAX: 86-512-6340-7290

### Delta Electronics (Japan), Inc. Tokyo Office

Delta Shibadaimon Building, 2-1-14 Shibadaimon, Minato-Ku, Tokyo, 105-0012, Japan TEL: 81-3-5733-1111 / FAX: 81-3-5733-1211

### Delta Electronics (Korea), Inc.

234-9, Duck Soo BD 7F, Nonhyun-dong, Kangnam-Gu, Seoul, Korea Post code: 135-010 TEL: 82-2-515-5303/5 / FAX: 82-2-515-5302

Delta Electronics (Singapore) Pte. Ltd.

8 Kaki Bukit Road 2, #04-18 Ruby Warehouse Complex, Singapore 417841

TEL: 65-6747-5155 / FAX: 65-6744-9228

# Delta Energy Systems (India) Pvt. Ltd. Plot No. 27 & 31, Sector-34, EHTP,

Gurgaon-122001 Haryana, India TEL: 91-124-4169040 / FAX: 91-124-4036045

### **AMERICA**

### **Delta Products Corporation (USA)**

Raleigh Office

P.O. Box 12173,5101 Davis Drive, Research Triangle Park, NC 27709, U.S.A. TEL: 1-919-767-3813 / FAX: 1-919-767-3969

### **EUROPE**

Deltronics (Netherlands) B.V.

Eindhoven Off

De Witbogt 15, 5652 AG Eindhoven, The Netherlands TEL: 31-40-259-28-50/ FAX: 31-40-259-28-51





**A** NELTA

*VF⊅-*E

User Manual

High Performance/Flexible Options/ Micro Type AC Motor Drives

# Preface

Thank you for choosing DELTA's high-performance VFD-E Series. The VFD-E Series is manufactured with high-quality components and materials and incorporate the latest microprocessor technology available.

This manual is to be used for the installation, parameter setting, troubleshooting, and daily maintenance of the AC motor drive. To guarantee safe operation of the equipment, read the following safety guidelines before connecting power to the AC motor drive. Keep this operating manual at hand and distribute to all users for reference.

To ensure the safety of operators and equipment, only qualified personnel familiar with AC motor drive are to do installation, start-up and maintenance. Always read this manual thoroughly before using VFD-E series AC Motor Drive, especially the WARNING, DANGER and CAUTION notes. Failure to comply may result in personal injury and equipment damage. If you have any questions, please contact your dealer.

### PLEASE READ PRIOR TO INSTALLATION FOR SAFETY.



- 1. AC input power must be disconnected before any wiring to the AC motor drive is made.
- A charge may still remain in the DC-link capacitors with hazardous voltages, even if the power
  has been turned off. To prevent personal injury, please ensure that power has turned off before
  opening the AC motor drive and wait ten minutes for the capacitors to discharge to safe voltage
  levels.
- 3. Never reassemble internal components or wiring.
- 4. The AC motor drive may be destroyed beyond repair if incorrect cables are connected to the input/output terminals. Never connect the AC motor drive output terminals U/T1, V/T2, and W/T3 directly to the AC mains circuit power supply.
- Ground the VFD-E using the ground terminal. The grounding method must comply with the laws of the country where the AC motor drive is to be installed. Refer to the Basic Wiring Diagram.
- VFD-E series is used only to control variable speed of 3-phase induction motors, NOT for 1phase motors or other purpose.
- 7. VFD-E series shall NOT be used for life support equipment or any life safety situation.



- DO NOT use Hi-pot test for internal components. The semi-conductor used in AC motor drive easily damage by high-voltage.
- There are highly sensitive MOS components on the printed circuit boards. These components are especially sensitive to static electricity. To prevent damage to these components, do not touch these components or the circuit boards with metal objects or your bare hands.
- 3. Only qualified persons are allowed to install, wire and maintain AC motor drives.



- 1. Some parameters settings can cause the motor to run immediately after applying power.
- DO NOT install the AC motor drive in a place subjected to high temperature, direct sunlight, high humidity, excessive vibration, corrosive gases or liquids, or airborne dust or metallic particles.
- Only use AC motor drives within specification. Failure to comply may result in fire, explosion or electric shock.
- To prevent personal injury, please keep children and unqualified people away from the equipment.
- 5. When the motor cable between AC motor drive and motor is too long, the layer insulation of the motor may be damaged. Please use a frequency inverter duty motor or add an AC output reactor to prevent damage to the motor. Refer to appendix B Reactor for details.
- The rated voltage for AC motor drive must be ≤ 240V (≤ 480V for 460V models) and the short circuit must be ≤ 5000A RMS (≤10000A RMS for the ≥ 40hp (30kW) models).

DeviceNet is a registered trademark of the Open DeviceNet Vendor Association, Inc. Lonwork is a registered trademark of Echelon Corporation. Profibus is a registered trademark of Profibus International. CANopen is a registered trademark of CAN in Automation (CiA). Other trademarks belong to their respective owners.

# **Table of Contents**

Preface	i
Table of Contents	iii
Chapter 1 Introduction	1-1
1.1 Receiving and Inspection	1-2
1.1.1 Nameplate Information	1-2
1.1.2 Model Explanation	1-2
1.1.3 Series Number Explanation	1-3
1.1.4 Drive Frames and Appearances	1-3
1.1.5 Remove Instructions	1-7
1.2 Preparation for Installation and Wiring	1-9
1.2.1 Ambient Conditions	1-9
1.2.2 DC-bus Sharing: Connecting the DC-bus of the AC M Parallel	
1.3 Dimensions	1-13
Chapter 2 Installation and Wiring	2-1
2.1 Wiring	2-2
2.2 External Wiring	2-12
2.3 Main Circuit	2-13
2.3.1 Main Circuit Connection	2-13
2.3.2 Main Circuit Terminals	2-16
2.4 Control Terminals	2-17

CI	hapter 3 Keypad and Start Up	3-1
	3.1 Keypad	3-1
	3.2 Operation Method	3-2
	3.3 Trial Run	3-3
CI	hapter 4 Parameters	4-1
	4.1 Summary of Parameter Settings	4-2
	4.2 Parameter Settings for Applications4	-33
	4.3 Description of Parameter Settings4	-38
	4.4 Different Parameters for VFD*E*C Models4-	181
C	hapter 5 Troubleshooting	5-1
	5.1 Over Current (OC)	5-1
	5.2 Ground Fault	5-2
	5.3 Over Voltage (OV)	5-2
	5.4 Low Voltage (Lv)	5-3
	5.5 Over Heat (OH)	5-4
	5.6 Overload	5-4
	5.7 Keypad Display is Abnormal	5-5
	5.8 Phase Loss (PHL)	5-5
	5.9 Motor cannot Run	5-6
	5.10 Motor Speed cannot be Changed	5-7
	5.11 Motor Stalls during Acceleration	5-8
	5.12 The Motor does not Run as Expected	5-8
	5.13 Electromagnetic/Induction Noise	5-9
	5.14 Environmental Condition	5-9
	5.15 Affecting Other Machines	5-10

Chapter 6 Fault Code Information and Maintenance	6-1
6.1 Fault Code Information	6-1
6.1.1 Common Problems and Solutions	6-1
6.1.2 Reset	6-6
6.2 Maintenance and Inspections	6-6
Appendix A Specifications	A-1
Appendix B Accessories	B-1
B.1 All Brake Resistors & Brake Units Used in AC Motor Drives	B-1
B.1.1 Dimensions and Weights for Brake Resistors	B-4
B.1.2 Specifications for Brake Unit	B-7
B.1.3 Dimensions for Brake Unit	B-8
B.1.4 DIN Rail Installation	B-9
B.2 No-fuse Circuit Breaker Chart	B-10
B.3 Fuse Specification Chart	B-11
B.4 AC Reactor	B-12
B.4.1 AC Input Reactor Recommended Value	B-12
B.4.2 AC Output Reactor Recommended Value	B-13
B.4.3 Applications	B-14
B.5 Zero Phase Reactor (RF220X00A)	B-17
B.6 Remote Controller RC-01	B-18
B.7 PU06	B-19
B.7.1 Description of the Digital Keypad VFD-PU06	B-19
B.7.2 Explanation of Display Message	B-19
B.7.3 Operation Flow Chart	B-20

В.	8 KPE-LE02	B-21
	B.8.1 Description of the Digital Keypad KPE-LE02	.B-21
	B.8.2 How to Operate the Digital Keypad	.B-23
	B.8.3 Reference Table for the 7-segment LED Display of the Digital Keypad	.B-24
	B.8.4 Keypad Dimensions	.B-24
В.	9 Extension Card	B-25
	B.9.1 Relay Card	.B-25
	B.9.2 Digital I/O Card	.B-26
	B.9.3 Analog I/O Card	.B-26
	B.9.4 Communication Card	.B-26
	B.9.5 Speed Feedback Card	.B-27
В.	10 Fieldbus Modules	B-27
	B.10.1 DeviceNet Communication Module (CME-DN01)	.B-27
	B.10.1.1 Panel Appearance and Dimensions	.B-27
	B.10.1.2 Wiring and Settings	.B-28
	B.10.1.3 Mounting Method	.B-28
	B.10.1.4 Power Supply	.B-29
	B.10.1.5 LEDs Display	.B-29
	B.10.2 LonWorks Communication Module (CME-LW01)	.B-30
	B.10.2.1 Introduction	.B-30
	B.10.2.2 Dimensions	.B-30
	B.10.2.3 Specifications	.B-30
	B.10.2.4 Wiring	.B-31
	B.10.2.5 LED Indications	.B-31

B.10.3 Profibus Communication Module (CME-PD0	1)B-31
B.10.3.1 Panel Appearance	B-32
B.10.3.2 Dimensions	B-33
B.10.3.3 Parameters Settings in VFD-E	B-33
B.10.3.4 Power Supply	B-33
B.10.3.5 PROFIBUS Address	B-33
B.10.4 CME-COP01 (CANopen)	B-34
B.10.4.1 Product Profile	B-34
B.10.4.2 Specifications	B-34
B.10.4.3 Components	B-35
B.10.4.4 LED Indicator Explanation & Troublesho	ootingB-36
B.11 DIN Rail	B-38
B.11.1 MKE-DRA	B-38
B.11.2 MKE-DRB	B-39
B.11.3 MKE-EP	B-39
Appendix C How to Select the Right AC Motor Drive	C-1
C.1 Capacity Formulas	C-2
C.2 General Precaution	
C.3 How to Choose a Suitable Motor	
Appendix D How to Use PLC Function	D-1
D.1 PLC Overview	D-1
D.1.1 Introduction	D-1
D.1.2 Ladder Diagram Editor – WPLSoft	D-1
D.2 Start-up	D-2

	D.2.1 The Steps for PLC Execution	D-2
	D.2.2 Device Reference Table	D-3
	D.2.3 WPLSoft Installation	D-4
	D.2.4 Program Input	D-4
	D.2.5 Program Download	D-5
	D.2.6 Program Monitor	D-5
	D.2.7 The Limit of PLC	D-5
D	.3 Ladder Diagram	D-7
	D.3.1 Program Scan Chart of the PLC Ladder Diagram	D-7
	D.3.2 Introduction	D-7
	D.3.3 The Edition of PLC Ladder Diagram	D-10
	D.3.4 The Example for Designing Basic Program	D-13
D	.4 PLC Devices	D-18
	D.4.1 Summary of DVP-PLC Device Number	D-18
	D.4.2 Devices Functions	D-19
	D.4.3 Value, Constant [K] / [H]	D-20
	D.4.4 The Function of Auxiliary Relay	D-21
	D.4.5 The Function of Timer	D-21
	D.4.6 The Features and Functions of Counter	D-22
	D.4.7 Register Types	D-23
	D.4.8 Special Auxiliary Relays	D-24
	D.4.9 Special Registers	D-25
	D.4.10 Communication Addresses for Devices (only for PLC2 mod 26	de) D-
	D.4.11 Function Code (only for PLC2 mode)	D-27

D.5 Commands
D.5.1 Basic Commands
D.5.2 Output Commands
D.5.3 Timer and CountersD-28
D.5.4 Main Control Commands
D.5.5 Rising-edge/falling-edge Detection Commands of ContactD-28
D.5.6 Rising-edge/falling-edge Output Commands
D.5.7 End Command
D.5.8 Explanation for the Commands
D.5.9 Description of the Application CommandsD-44
D.5.10 Explanation for the Application CommandsD-45
D.5.11 Special Application Commands for the AC Motor DriveD-57
D.6 Error Code
D.6 Effor Code
Appendix E CANopen Function
Appendix E CANopen FunctionE-1
Appendix E CANopen FunctionE-1  E.1 OverviewE-2
Appendix E CANopen Function         E-1           E.1 Overview         E-2           E.1.1 CANopen Protocol         E-2
Appendix E CANopen Function         E-1           E.1 Overview         E-2           E.1.1 CANopen Protocol         E-2           E.1.2 RJ-45 Pin Definition         E-3
Appendix E CANopen Function       E-1         E.1 Overview       E-2         E.1.1 CANopen Protocol       E-2         E.1.2 RJ-45 Pin Definition       E-3         E.1.3 Pre-Defined Connection Set       E-3
Appendix E CANopen Function       E-1         E.1 Overview       E-2         E.1.1 CANopen Protocol       E-2         E.1.2 RJ-45 Pin Definition       E-3         E.1.3 Pre-Defined Connection Set       E-3         E.1.4 CANopen Communication Protocol       E-4
Appendix E CANopen Function       E-1         E.1 Overview       E-2         E.1.1 CANopen Protocol       E-2         E.1.2 RJ-45 Pin Definition       E-3         E.1.3 Pre-Defined Connection Set       E-3         E.1.4 CANopen Communication Protocol       E-4         E.1.4.1 NMT (Network Management Object)       E-4
Appendix E CANopen Function       E-1         E.1 Overview       E-2         E.1.1 CANopen Protocol       E-2         E.1.2 RJ-45 Pin Definition       E-3         E.1.3 Pre-Defined Connection Set       E-3         E.1.4 CANopen Communication Protocol       E-4         E.1.4.1 NMT (Network Management Object)       E-4         E.1.4.2 SDO (Service Data Object)       E-6

This page intentionally left blank

# Chapter 1 Introduction

The AC motor drive should be kept in the shipping carton or crate before installation. In order to retain the warranty coverage, the AC motor drive should be stored properly when it is not to be used for an extended period of time. Storage conditions are:



- 1. Store in a clean and dry location free from direct sunlight or corrosive fumes.
- Store within an ambient temperature range of -20 °C to +60 °C.
- 3. Store within a relative humidity range of 0% to 90% and non-condensing environment.
- 4. Store within an air pressure range of 86 kPA to 106kPA.
- DO NOT place on the ground directly. It should be stored properly. Moreover, if the surrounding environment is humid, you should put exsiccator in the package.
- DO NOT store in an area with rapid changes in temperature. It may cause condensation and frost.
- 7. If the AC motor drive is stored for more than 3 months, the temperature should not be higher than 30 °C. Storage longer than one year is not recommended, it could result in the degradation of the electrolytic capacitors.
- When the AC motor drive is not used for longer time after installation on building sites or places with humidity and dust, it's best to move the AC motor drive to an environment as stated above.




# 1.1 Receiving and Inspection

This VFD-E AC motor drive has gone through rigorous quality control tests at the factory before shipment. After receiving the AC motor drive, please check for the following:


- Check to make sure that the package includes an AC motor drive, the User Manual/Quick Start and CD.
- Inspect the unit to assure it was not damaged during shipment.
- Make sure that the part number indicated on the nameplate corresponds with the part number of your order.

### 1.1.1 Nameplate Information


Example for 1HP/0.75kW 3-phase 230V AC motor drive



# 1.1.2 Model Explanation




# 1.1.3 Series Number Explanation



If the nameplate information does not correspond to your purchase order or if there are any problems, please contact your distributor.


# 1.1.4 Drive Frames and Appearances

# 0.25-2HP/0.2-1.5kW (Frame A)







### 1-5HP/0.75-3.7kW (Frame B)



### 7.5-15HP/5.5-11kW (Frame C)




### 20-30HP/15-22kW (Frame D)





### Internal Structure



- ♠ READY: power indicator
  - RUN: status indicator
  - FAULT: fault indicator
- 1. Switch to ON for 50Hz, refer to P 01.00 to P01.02 for details
  - 2. Switch to ON for free run to stop refer to P02.02
  - 3. Switch to ON for setting frequency source to ACI (P 02.00=2)
- ( Keypad mounting port
- ACI terminal (ACI/AVI2 switch )
- NPN/PNP
- Mounting port for extension card
- @ RS485 port (RJ-45)



The LED "READY" will light up after applying power. The light won't be off until the capacitors are discharged to safe voltage levels after power off.

### **RFI Jumper Location**

### Frame A: near the output terminals (U/T1, V/T2, W/T3)





Frame B: above the nameplate



Frame C: above the warning label



Frame D: near the input terminals (R/L1, S/L2, T/L3)

Frame	Power range	Models		
A (A1)	0.25-2hp (0.2-1.5kW)	VFD002E11A/21A/23A, VFD004E11A/21A/23A/43A, VFD007E21A/23A/43A, VFD015E23A/43A  VFD002E11C/21C/23C, VFD004E11C/21C/23C/43C, VFD007E21C/23C/43C, VFD015E23C/43C  VFD002E11T/21T/23T, VFD004E11T/21T/23T/43T, VFD007E21T/23T/43T, VFD015E23T/43T		
A (A2)	0.25-2hp (0.2-1.5kW)	VFD002E11P/21P/23P, VFD004E11P/21P/23P/43P, VFD007E21P/23P/43P, VFD015E23P/43P		
В	1-5hp (0.75-3.7kW)	VFD007E11A, VFD015E21A, VFD022E21A/23A/43A, VFD037E23A/43A, VFD007E11C, VFD015E21C, VFD022E21C/23C/43C, VFD037E23C/43C		
С	7.5-15hp (5.5-11kW)	VFD055E23A/43A, VFD075E23A/43A, VFD110E23A/43A, VFD055E23C/43C, VFD075E23C/43C, VFD110E23C/43C		
D	20-30hp (15-22kW)	VFD150E23A/43A, VFD150E23C/43C, VFD185E43A/43C, VFD220E43A/43C		



### RFI Jumper

RFI Jumper: The AC motor drive may emit the electrical noise. The RFI jumper is used to suppress the interference (Radio Frequency Interference) on the power line.

Main power isolated from earth:

If the AC motor drive is supplied from an isolated power (IT power), the RFI jumper must be cut off. Then the RFI capacities (filter capacitors) will be disconnected from ground to prevent circuit damage (according to IEC 61800-3) and reduce earth leakage current.



- 1 After applying power to the AC motor drive, do not cut off the RFI jumper. Therefore, please make sure that main power has been switched off before cutting the RFI jumper.
- 2 The gap discharge may occur when the transient voltage is higher than 1,000V. Besides. electro-magnetic compatibility of the AC motor drives will be lower after cutting the RFI iumper.
- 3 Do NOT cut the RFI jumper when main power is connected to earth.
- 4 The RFI jumper cannot be cut when Hi-pot tests are performed. The mains power and motor must be separated if high voltage test is performed and the leakage currents are too hiah.
- 5. To prevent drive damage, the RFI jumper connected to ground shall be cut off if the AC motor drive is installed on an ungrounded power system or a high resistance-grounded (over 30 ohms) power system or a corner grounded TN system.

### 1.1.5 Remove Instructions

### Remove Keypad

- Press and hold in the tabs on each side 1 of the cover.
- 2. Pull the cover up to release.



### Remove Front Cover



Step 1

Step 2

### Remove RST Terminal Cover

For Frame B, Frame C and Frame D: it only needs to turn the cover lightly to open it



For frame A, it doesn't have cover and can be wired directly.

### Remove UVW Terminal Cover

For Frame B, Frame C and Frame D: it only needs to turn the cover light to open the cover



For frame A, it doesn't have cover and can be wired directly.

### Remove Fan

For Frame A, Frame B, Frame C and Frame D,

press and hold in the tabs on each side of the fan and pull the fan up to release.



### Remove Extension Card

For Frame A, Frame B, Frame C and Frame

press and hold in the tabs on each side of the extension card and pull the extension card up to release. On the other hand, it can install the extension card into the AC motor drive with screws.





# 1.2 Preparation for Installation and Wiring


# 1.2.1 Ambient Conditions


Install the AC motor drive in an environment with the following conditions:


	Air Temperature:	-10 ~ +50°C (14 ~ 122°F) for UL & cUL -10 ~ +40°C (14 ~ 104°F) for side-by-side mounting				
	Relative Humidity:	<90%, no condensation allowed				
Operation	Atmosphere pressure:	86 ~ 106 kPa				
	Installation Site Altitude:	<1000m				
	Vibration:	<20Hz: 9.80 m/s <sup>2</sup> (1G) max 20 ~ 50Hz: 5.88 m/s <sup>2</sup> (0.6G) max				
	Temperature:	-20°C ~ +60°C (-4°F ~ 140°F)				
Storage	Relative Humidity:	<90%, no condensation allowed				
Transportation	Atmosphere pressure:	86 ~ 106 kPa				
	Vibration: <20Hz: 9.80 m/s² (1G) max 20 ~ 50Hz: 5.88 m/s² (0.6G) max					
Pollution Degree	2: good for a factory type environment.					

# Minimum Mounting Clearances

# Frame A Mounting Clearances













### Frame B, C and D Mounting Clearances







For VFD-E-P series: heat sink system example






- 1 Operating, storing or transporting the AC motor drive outside these conditions may cause damage to the AC motor drive.
- 2. Failure to observe these precautions may void the warranty!
- 3 Mount the AC motor drive vertically on a flat vertical surface object by screws. Other directions are not allowed
- The AC motor drive will generate heat during operation. Allow sufficient space around the unit 4. for heat dissipation.




- 5. The heat sink temperature may rise to 90°C when running. The material on which the AC motor drive is mounted must be noncombustible and be able to withstand this high temperature.
- 6 When AC motor drive is installed in a confined space (e.g. cabinet), the surrounding temperature must be within 10 ~ 40°C with good ventilation. DO NOT install the AC motor drive in a space with bad ventilation.
- 7. Prevent fiber particles, scraps of paper, saw dust, metal particles, etc. from adhering to the heatsink
- 8. When installing multiple AC more drives in the same cabinet, they should be adjacent in a row with enough space in-between. When installing one AC motor drive below another one, use a metal separation between the AC motor drives to prevent mutual heating.



# 1.2.2 DC-bus Sharing: Connecting the DC-bus of the AC Motor Drives in Parallel

- 1. This function is not for VFD-E-T series.
- The AC motor drives can absorb mutual voltage that generated to DC bus when deceleration
- 3. Enhance brake function and stabilize the voltage of the DC bus.
- 4. The brake module can be added to enhance brake function after connecting in parallel.
- 5. Only the same power system can be connected in parallel.
- It is recommended to connect 5 AC motor drives in parallel (no limit in horsepower but these 5 drives should be the same power system).




For frame A, terminal + (-) is connected to the terminal + (-) of the brake module. For frame B, C and D, terminal +/B1 (-) is connected to the terminal + (-) of the brake module.





### 1.3 Dimensions

(Dimensions are in millimeter and [inch]) Frame A









Unit: mm [inch]

Frame	W	W1	Н	H1	D	D1	D2	S1	S2
A (A1)	72.0 [2.83]	60.0 [2.36]	142.0 [5.59]	120.0 [4.72]	152.0 [5.98]	50.0 [1.97]	4.5 [0.18]	5.2 [0.20]	5.2 [0.20]
A (A2)	72.0 [2.83]	56.0 [2.20]	155.0 [6.10]	143.0 [5.63]	111.5 [4.39]	9.5 [0.37]	-	5.3 [0.21]	-




Frame A (A1): VFD002E11A/21A/23A, VFD004E11A/21A/23A/43A, VFD007E21A/23A/43A, VFD015E23A/43A, VFD002E11C/21C/23C, VFD004E11C/21C/23C/43C, VFD007E21C/23C/43C, VFD015E23C/43C, VFD002E11T/21T/23T, VFD004E11T/21T/23T/43T, VFD007E21T/23T/43T, VFD015F23T/43T

Frame A (A2): VFD002E11P/21P/23P, VFD004E11P/21P/23P/43P, VFD007E21P/23P/43P, VFD015E23P/43P



Frame B




Unit: mm [inch]

Frame	W	W1	Н	H1	D	D1	D2	S1	S2
B1	100.0	89.0	174.0	162.0	152.0	50.0	4.0	5.5	5.5
ы	[3.94]	[3.50]	[6.86]	[6.38]	[5.98]	[1.97]	[0.16]	[0.22]	[0.22]



Frame B (B1): VFD007E11A, VFD015E21A, VFD022E21A/23A/43A, VFD037E23A/43A, VFD007E11C, VFD015E21C, VFD022E21C/23C/43C, VFD037E23C/43C




Unit: mm [inch]


Frame	W	W1	Н	H1	D	D1	D2	S1	S2
C1	130.0	116.0	260.0	246.5	169.2	78.5	8.0	6.5	5.5
Ci	[5.12]	[4.57]	[10.24]	[9.70]	[6.66]	[3.09]	[0.31]	[0.26]	[0.22]





Frame C (C1): VFD055E23A/43A, VFD075E23A/43A, VFD110E23A/43A, VFD055E23C/43C, VFD075E23C/43C, VFD110E23C/43C

### Frame D









Unit: mm [inch]

	Frame	W	W1	Н	H1	D	D1	D2	S1	S2
-	D	200.0	180.0	310.0	290.0	190.0	92.0	10.0	10.0	9.0
		[7.87]	[7.09]	[12.20]	[11.42]	[7.48]	[3.62]	[0.39]	[0.39]	[0.35]



Frame D (D1): VFD150E23A/23C, VFD150E43A/43C, VFD185E43A/43C, VFD220E43A/43C

# Chapter 2 Installation and Wiring

After removing the front cover, check if the power and control terminals are clear. Be sure to observe the following precautions when wiring.

General Wiring Information

Applicable Codes

All VFD-E series are Underwriters Laboratories, Inc. (UL) and Canadian Underwriters Laboratories (cUL) listed, and therefore comply with the requirements of the National Electrical Code (NEC) and the Canadian Electrical Code (CEC).

Installation intended to meet the UL and cUL requirements must follow the instructions provided in "Wiring Notes" as a minimum standard. Follow all local codes that exceed UL and cUL requirements. Refer to the technical data label affixed to the AC motor drive and the motor nameplate for electrical data.

The "Line Fuse Specification" in Appendix B, lists the recommended fuse part number for each VFD-E Series part number. These fuses (or equivalent) must be used on all installations where compliance with U.L. standards is a required.



- Make sure that power is only applied to the R/L1, S/L2, T/L3 terminals. Failure to comply may result in damage to the equipment. The voltage and current should lie within the range as indicated on the nameplate.
- All the units must be grounded directly to a common ground terminal to prevent lightning strike or electric shock.
- Please make sure to fasten the screw of the main circuit terminals to prevent sparks which is made by the loose screws due to vibration.
- 4. Check following items after finishing the wiring:
  - A. Are all connections correct?
  - B No loose wires?
  - C. No short-circuits between terminals or to ground?






- A charge may still remain in the DC bus capacitors with hazardous voltages even if the power has been turned off. To prevent personal injury, please ensure that the power is turned off and wait ten minutes for the capacitors to discharge to safe voltage levels before opening the AC motor drive.
- 2. Only qualified personnel familiar with AC motor drives is allowed to perform installation, wiring and commissioning.
- 3. Make sure that the power is off before doing any wiring to prevent electric shock.

# 2.1 Wiring

Users must connect wires according to the circuit diagrams on the following pages. Do not plug a modem or telephone line to the RS-485 communication port or permanent damage may result. The pins 1 & 2 are the power supply for the optional copy keypad only and should not be used for RS-485 communication.




Figure 1 for models of VFD-E Series VFD002E11A/21A, VFD004E11A/21A, VFD007E21A, VFD002E11C/21C, VFD004E11C/21C, VFD007E21C, VFD002E11P/21P, VFD004E11P/21P, VFD007E21P



# Chapter 2 Installation and Wiring |


Figure 2 for models of VFD-E Series

VFD002E23A, VFD004E23A/43A, VFD007E23A/43A, VFD015E23A/43A, VFD002E23C, VFD004E23C/43C, VFD007E23C/43C, VFD002E23P, VFD004E23P/43P, VFD007E23P/43P, VFD007E23P






### Figure 3 for models of VFD-E Series VFD007E11A, VFD015E21A, VFD022E21A, VFD007E11C, VFD015E21C, VFD022E21C



### Chapter 2 Installation and Wiring | Value |


Figure 4 for models of VFD-E Series

VFD022E23A/43A, VFD037E23A/43A, VFD055E23A/43A, VFD075E23A/43A, VFD110E23A/43A, VFD022E23C/43C, VFD037E23C/43C, VFD055E23C/43C, VFD075E23C/43C, VFD110E23C/43C, VFD150E23A/23C, VFD150E43A/43C, VFD185E43A/43C, VFD220E43A/43C






### Figure 5 for models of VFD-E Series VFD002E11T/21T, VFD004E11A/21T, VFD007E21T



NOTE For VFD-E-T series, the braking resistor can be used by connecting terminals (B1 and B2) directly. But it can't connect DC-BUS in parallel.




NOTE For VFD-E-T series, the braking resistor can be used by connecting terminals (B1 and B2) directly. But it can't connect DC-BUS in parallel.




### Figure 7 Wiring for NPN mode and PNP mode


### A. NPN mode without external power



### B. NPN mode with external power



#### C. PNP mode without external power





D. PNP mode with external power




Figure 8 RJ-45 pin definition for VFD\*E\*C models

PIN	Signal	Description
1	CAN_H	CAN_H bus line (dominant high)
2	CAN_L	CAN_L bus line (dominant low)
3	CAN_GND	Ground / 0V /V-
4	SG+	485 communication
5	SG-	485 communication
7	CAN_GND	Ground / 0V /V-



1. The wiring of main circuit and control circuit should be separated to prevent erroneous actions.


Please use shield wire for the control wiring and not to expose the peeled-off net in front of the

- terminal.
- 3. Please use the shield wire or tube for the power wiring and ground the two ends of the shield wire or tube.
- 4. Damaged insulation of wiring may cause personal injury or damage to circuits/equipment if it comes in contact with high voltage.
- 5. The AC motor drive, motor and wiring may cause interference. To prevent the equipment damage, please take care of the erroneous actions of the surrounding sensors and the equipment.
- 6. When the AC drive output terminals U/T1, V/T2, and W/T3 are connected to the motor terminals U/T1, V/T2, and W/T3, respectively. To permanently reverse the direction of motor rotation, switch over any of the two motor leads.

2.




- 7. With long motor cables, high capacitive switching current peaks can cause over-current, high leakage current or lower current readout accuracy. To prevent this, the motor cable should be less than 20m for 3.7kW models and below. And the cable should be less than 50m for 5.5kW models and above. For longer motor cables use an AC output reactor.
- 8 The AC motor drive, electric welding machine and the greater horsepower motor should be grounded separately.
- 9 Use ground leads that comply with local regulations and keep them as short as possible.
- 10 No brake resistor is built in the VFD-E series, it can install brake resistor for those occasions that use higher load inertia or frequent start/stop. Refer to Appendix B for details.
- Multiple VFD-E units can be installed in one location. All the units should be grounded directly to a common ground terminal, as shown in the figure below. Ensure there are no ground loops.





# 2.2 External Wiring



Items	Explanations
Power supply	Please follow the specific power supply requirements shown in Appendix A.
Fuse/NFB (Optional)	There may be an inrush current during power up. Please check the chart of Appendix B and select the correct fuse with rated current. Use of an NFB is optional.
Magnetic contactor (Optional)	Please do not use a Magnetic contactor as the I/O switch of the AC motor drive, as it will reduce the operating life cycle of the AC drive.
Input AC Line Reactor (Optional)	Used to improve the input power factor, to reduce harmonics and provide protection from AC line disturbances₁ (surges, switching spikes, short interruptions, etc.). AC line reactor should be installed when the power supply capacity is 500kVA or more or advanced capacity is activated .The wiring distance should be ≤ 10m. Refer to appendix B for details.
Zero-phase Reactor (Ferrite Core Common Choke) (Optional)	Zero phase reactors are used to reduce radio noise especially when audio equipment is installed near the inverter. Effective for noise reduction on both the input and output sides. Attenuation quality is good for a wide range from AM band to 10MHz. Appendix B specifies the zero phase reactor. (RF220X00A)
EMI filter	To reduce electromagnetic interference.
Brake resistor and Brake unit (Optional)	Used to reduce the deceleration time of the motor. Please refer to the chart in Appendix B for specific Brake resistors.
Output AC Line Reactor (Optional)	Motor surge voltage amplitude depends on motor cable length. For applications with long motor cable (>20m), it is necessary to install a



#### 2.3 Main Circuit

#### 2.3.1 Main Circuit Connection

#### Figure 1

For frame A: VFD002E11A/21A/23A, VFD004E11A/21A/23A/43A, VFD007E21A/23A/43A, VFD015E23A/43A, VFD002E11C/21C/23C, VFD004E11C/21C/23C/43C,

VFD007E21C/23C/43C, VFD002E11P/21P/23P, VFD004E11P/21P/23P/43P,

VFD007E11P/21P/23P/43P, VFD015E23P/43P




Figure 2

For frame B: VFD007E11A, VFD015E21A, VFD022E21A/23A/43A, VFD037E23A/43A, VFD007E11C, VFD015E21C, VFD022E21C/23C/43C, VFD037E23C/43C

For frame C: VFD055E23A/43A, VFD075E23A/43A, VFD110E23A/43A, VFD055E23C/43C, VFD075E23C/43C, VFD110E23C/43C

For frame D: VFD150E23A/23C, VFD150E43A/43C, VFD185E43A/43C, VFD220E43A/43C





Figure 3 For Frame A: VFD002E11T/21T/23T, VFD004E11T/21T/23T/43T, VFD007E21T/23T/43T, VFD015E23T/43T





Terminal Symbol	Explanation of Terminal Function
R/L1, S/L2, T/L3 AC line input terminals (1-phase/3-phase)	
U/T1, V/T2, W/T3 AC drive output terminals for connecting 3-phase indu	
+/B1~ B2	Connections for Brake resistor (optional)
+/B1, -	Connections for External Brake unit (BUE series)
-	Earth connection, please comply with local regulations.



#### Mains power terminals (R/L1, S/L2, T/L3)

- Connect these terminals (R/L1, S/L2, T/L3) via a no-fuse breaker or earth leakage breaker to 3-phase AC power (some models to 1-phase AC power) for circuit protection. It is unnecessary to consider phase-sequence.
- It is recommended to add a magnetic contactor (MC) in the power input wiring to cut off power quickly and reduce malfunction when activating the protection function of AC motor drives. Both ends of the MC should have an R-C surge absorber.
- Please make sure to fasten the screw of the main circuit terminals to prevent sparks which is made by the loose screws due to vibration.
- Please use voltage and current within the regulation shown in Appendix A.
- When using a general GFCI (Ground Fault Circuit Interrupter), select a current sensor with sensitivity of 200mA or above, and not less than 0.1-second operation time to avoid nuisance tripping. For the specific GFCI of the AC motor drive, please select a current sensor with sensitivity of 30mA or above.
- Do NOT run/stop AC motor drives by turning the power ON/OFF. Run/stop AC motor drives by RUN/STOP command via control terminals or keypad. If you still need to run/stop AC drives by turning power ON/OFF, it is recommended to do so only ONCE per hour
- Do NOT connect 3-phase models to a 1-phase power source.


#### Output terminals for main circuit (U, V, W)

The factory setting of the operation direction is forward running. The methods to control the operation direction are: method 1, set by the communication parameters. Please refer



- to the group 9 for details, Method2, control by the optional keypad KPE-LE02, Refer to Appendix B for details.
- When it needs to install the filter at the output side of terminals U/T1, V/T2, W/T3 on the AC motor drive. Please use inductance filter. Do not use phase-compensation capacitors or L-C (Inductance-Capacitance) or R-C (Resistance-Capacitance), unless approved by Delta
- DO NOT connect phase-compensation capacitors or surge absorbers at the output terminals of AC motor drives
- Use well-insulated motor, suitable for inverter operation.

#### Terminals [+/B1, B2] for connecting brake resistor



- Connect a brake resistor or brake unit in applications with frequent deceleration ramps, short deceleration time, too low brake torque or requiring increased brake torque.
- If the AC motor drive has a built-in brake chopper (frame B, frame C and VFDxxxExxT models), connect the external brake resistor to the terminals [+/B1, B2] or [B1, B2].
- Models of frame A don't have a built-in brake chopper. Please connect an external optional brake unit (BUE-series) and brake resistor. Refer to BUE series user manual for details.
- Connect the terminals [+(P), -(N)] of the brake unit to the AC motor drive terminals [+/B1, -]. The length of wiring should be less than 5m with cable.
- When not used, please leave the terminals [+/B1, -] open.




Short-circuiting [B2] or [-] to [+/B1] can damage the AC motor drive.



### 2.3.2 Main Circuit Terminals

#### Frame A






R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, 🖶 , +, -				
Models	Wire	Torque	Wire type	
VFD002E11A/21A/23A				
VFD004E11A/21A/23A/				
43A				
VFD007E21A/23A/43A				
VFD015E23A/43A				
VFD002E11C/21C/23C				
VFD004E11C/21C/23C/				
43C				
VFD007E21C/23C/43C	12-14 AWG.		Stranded	
VFD015E23C/43C	(3.3-	14kgf-cm	copper	
VFD002E11T/21T/23T	2.1mm <sup>2</sup> )	(12in-lbf)	Only,	
VFD004E11T/21T/23T/	2.111111		75℃	
43T				
VFD007E21T/23T/43T				
VFD015E23T/43T				
VFD002E11P/21P/23P				
VFD004E11P/21P/23P/	1			
43P				
VFD007E21P/23P/43P				
VFD015E23P/43P				

Frame B


Main circuit terminals:



R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, (+)B1, B2, -				
Models	Wire	Torque	Wire type	
VFD007E11A,				
VFD015E21A,				
VFD022E21A/23A/43A,			Stranded	
VFD037E23A/43A,	8-18 AWG. (8.4-0.8mm <sup>2</sup> )	18kgf-cm	copper	
VFD007E11C,	(8.4-0.8mm <sup>2</sup> )	(15.6in-lbf)		
VFD015E21C,			75℃	
VFD022E21C/23C/43C,				
VFD037E23C/43C,				



#### Frame C



Main circuit terminals:

R/L1, S/L2, T/L3, U/T1, V/T2, W/T3, 🗐, +/B1, B2, -

Models	Wire	Torque	Wire type
VFD055E23A/43A,			
VFD075E23A/43A,			
VFD110E23A/43A,	0 1071110.	30kgf-cm (26in-lbf)	Stranded copper Only, 75℃
VFD055E23C/43C,			
VFD075E23C/43C,			
VFD110E23C/43C			




To connect 6 AWG (13.3 mm<sup>2</sup>) wires, use Recognized Ring Terminals




R/L1. S/L2. T/L3. U/T1. V/T2. W/T3. . B1. B2. +. -

Models	Wire	Torque	Wire type
VFD150E23A/23C,			
VFD150E43A/43C,	4-14 AWG. (21.2-	57kgf-cm (49.5in-lbf)	Stranded copper
VFD185E43A/43C,	2.1mm <sup>2</sup> )		
VFD220E43A/43C			

Internal Circuit




### 2.4 Control Terminals





## The position of the control terminals



### Terminal symbols and functions

Terminal Symbol	Terminal Function	Factory Settings (NPN mode) ON: Connect to DCM	
MI1	Forward-Stop command	ON: Run in MI1 direction OFF: Stop acc. to Stop Method	
MI2	Reverse-Stop command	ON: Run in MI2 direction OFF: Stop acc. to Stop Method	
MI3	Multi-function Input 3		
MI4	Multi-function Input 4	Refer to Pr.04.05 to Pr.04.08 for programming the Multi-function Inputs.	
MI5	Multi-function Input 5	ON: the activation current is 16mA.  OFF: leakage current tolerance is 10 $\mu$ A.	
MI6	Multi-function Input 6	,	
+24V	DC Voltage Source	+24VDC, 20mA used for PNP mode.	
DCM	Digital Signal Common	Common for digital inputs and used for NPN mode.	
RA	Multi-function Relay output (N.O.) a	Resistive Load: 5A(N.O.)/3A(N.C.) 240VAC	
RB	Multi-function Relay output (N.C.) b	5A(N.O.)/3A(N.C.) 24VDC Inductive Load: 1.5A(N.O.)/0.5A(N.C.) 240VAC	
RC	Multi-function Relay common	1.5A(N.O.)/0.5A(N.C.) 24VDC Refer to Pr.03.00 for programming	

100	-	_	-	-	
- 1	₩7			м	
- 8.					
_	_			_	

Terminal Symbol	Terminal Function	Factory Settings (NPN mode) ON: Connect to DCM
MO1	Multi-function Output 1 (Photocoupler)	Maximum 48VDC, 50mA Refer to Pr.03.01 for programming  Mo1-DCM  Mo1  Mo1  Mo1  Mo1  Mo1  Mo1  Mo1  M
MCM	Multi-function output common	Common for Multi-function Outputs
+10V	Potentiometer power supply	+10VDC 3mA
AVI	Analog voltage Input  AVI circuit  AVI  AVI  internal circuit	
ACM	Analog control signal (common)	Common for AVI, ACI, AFM
ACI	Analog current Input  ACI Circuit  ACI MINIMA MINIM	Impedance: $250Ω/100kΩ$ Resolution:       10 bits         Range: $4 \sim 20mA =$ 0 ~ Max. Output Frequency (Pr.01.00)         Selection:       Pr.02.00, Pr.02.09, Pr.10.00         Set-up:       Pr.04.15 ~ Pr.04.18
AFM	Analog output meter  ACM circuit  O-10V  potentiometer  Max. 2mA	0 to 10V, 2mA Impedance: $100k\Omega$ Output current 2mA max Resolution: 8 bits Range: $0 \sim 10VDC$ Function: $Pr.03.03$ to $Pr.03.04$


NOTE: Control signal wiring size: 18 AWG (0.75 mm<sup>2</sup>) with shielded wire.

#### Chapter 2 Installation and Wiring | Value |



#### Analog inputs (AVI, ACI, ACM)

- Analog input signals are easily affected by external noise. Use shielded wiring and keep it as short as possible (<20m) with proper grounding. If the noise is inductive, connecting the shield to terminal ACM can bring improvement.
- If the analog input signals are affected by noise from the AC motor drive, please connect a capacitor (0.1  $\mu$  F and above) and ferrite core as indicated in the following diagrams:



wind each wires 3 times or more around the core

#### Digital inputs (MI1~MI6, DCM)

When using contacts or switches to control the digital inputs, please use high quality components to avoid contact bounce.

#### Digital outputs (MO1, MCM)

- Make sure to connect the digital outputs to the right polarity, see wiring diagrams.
- When connecting a relay to the digital outputs, connect a surge absorber or fly-back diode across the coil and check the polarity.

#### General

- Keep control wiring as far away as possible from the power wiring and in separate conduits to avoid interference. If necessary let them cross only at 90° angle.
- The AC motor drive control wiring should be properly installed and not touch any live power wiring or terminals.




Damaged insulation of wiring may cause personal injury or damage to circuits/equipment if it comes in contact with high voltage.

### The specification for the control terminals



#### The position of the control terminals



Frame	Control Terminals	Torque	Wire
A. B. C	Terminals 1	5 kgf-cm (4.4 in-lbf)	12-24 AWG (3.3-0.2mm <sup>2</sup> )
А, В, С	Terminals 2	2 kgf-cm (1.7 in-lbf)	16-24 AWG (1.3-0.2mm <sup>2</sup> )



Frame A: VFD002E11A/21A/23A, VFD004E11A/21A/23A/43A, VFD007E21A/23A/43A, VFD0015E23A/43A, VFD002E11C/21C/23C, VFD004E11C/21C/23C/43C, VFD007E21C/23C/43C, VFD015E23C/43C, VFD002E11T/21T/23T, VFD004E11T/21T/23T/43T, VFD007E21T/23T/43T, VFD0015E23T/43T, VFD002E11P/21P/23P, VFD004E11P/21P/23P/43P, VFD007E21P/23P/43P, VFD015E23P/43P

Frame B: VFD007E11A, VFD015E21A, VFD022E21A/23A/43A, VFD037E23A/43A, VFD007E11C, VFD015E21C. VFD022E21C/23C/43C. VFD037E23C/43C

Frame C: VFD055E23A/43A, VFD075E23A/43A, VFD110E23A/43A, VFD055E23C/43C, VFD075E23C/43C, VFD110E23C/43C

Frame D: VFD150E23A/43A, VFD150E23C/43C, VFD185E43A/43C, VFD220E43A/43C



This page intentionally left blank

# Chapter 3 Keypad and Start Up



- Make sure that the wiring is correct. In particular, check that the output terminals U/T1, V/T2, W/T3. are NOT connected to power and that the drive is well grounded.
- Verify that no other equipment is connected to the AC motor drive
- Do NOT operate the AC motor drive with humid hands.
- Please check if READY LED is ON when power is applied. Check if the connection is well when option from the digital keypad KPE-LE02.



■ It should be stopped when fault occurs during running and refer to "Fault Code Information and Maintenance" for solution. Please do NOT touch output terminals U, V, W when power is still applied to L1/R, L2/S, L3/T even when the AC motor drive has stopped. The DC-link capacitors may still be charged to hazardous voltage levels, even if the power has been turned off.

## 3.1 Keypad



There are three LEDs on the keypad:

LED READY: It will light up after applying power. The light won't be off until the capacitors are discharged to safe voltage levels after power off.


LED RUN: It will light up when the motor is running.

LED FAULT: It will light up when fault occurs.



## 3.2 Operation Method

The operation method can be set via communication, control terminals and optional keypad KPE-LE02.



- A RS485 port (RJ-45) It needs to use VFD-USB01 or IFD8500 converter to connect to the PC.
- © Control terminals (MI1 to MI6)
- ( Keypad mounting port



Operation Method	Frequency S	ource	Operation Command Source
Operate from the communication	When setting communication IFD8500 converter to connect Refer to the communication	ct to the PC.	101H setting for details.
Operate from external signal		FWD/Stop  REV/Stop  Multi-step 1  Multi-step 2  Multi-step 3  Multi-step 4  Digital Signal Commo  Ply the mains voltage determinals.  SKΩ  Analog Signal Commo	DCM    Construction   Power supply
Operate from the optional keypad (KPE-LE02)		▼	RUN STOP RESET

## 3.3 Trial Run

The factory setting of the operation source is from the external terminal (Pr.02.01=2).

- 1. Both MI1-DCM and MI2-DCM need to connect a switch for switching FWD/STOP and REV/STOP.
- 2. Please connect a potentiometer among AVI, 10V and DCM or apply power 0-10Vdc to AVI-DCM (as shown in figure 3-1)

### Chapter 3 Keypad and Start Up | Valle

- 3. Setting the potentiometer or AVI-DCM 0-10Vdc power to less than 1V.
- Setting MI1=On for forward running. And if you want to change to reverse running, you should set MI2=On. And if you want to decelerate to stop, please set MI1/MI2=Off.
- 5. Check following items:
- Check if the motor direction of rotation is correct.
- Check if the motor runs steadily without abnormal noise and vibration.
- Check if acceleration and deceleration are smooth.

If you want to perform a trial run by using optional digital keypad, please operate by the following steps.

- Connect digital keypad to AC motor drive correctly.
- After applying the power, verify that LED display shows F 0.0Hz.
- Set Pr.02.00=0 and Pr.02.01=0. (Refer to Appendix B operation flow for detail)
- 4. Press key to set frequency to around 5Hz.
- 5. Press key for forward running.
  And if you want to change to reverse

running, you should press in


rwe page. And if you want to

decelerate to stop, please press

6. Check following items:

key.

- Check if the motor direction of rotation is correct.
- Check if the motor runs steadily without abnormal noise and vibration.
- Check if acceleration and deceleration are smooth.



If the results of trial run are normal, please start the formal run.

# Chapter 4 Parameters

The VFD-E parameters are divided into 14 groups by property for easy setting. In most applications, the user can finish all parameter settings before start-up without the need for re-adjustment during operation.

#### The 14 groups are as follows:

Group 0: User Parameters

Group 1: Basic Parameters

Group 2: Operation Method Parameters

Group 3: Output Function Parameters

Group 4: Input Function Parameters

Group 5: Multi-Step Speed Parameters

Group 6: Protection Parameters

Group 7: Motor Parameters

Group 8: Special Parameters

Group 9: Communication Parameters

Group 10: PID Control Parameters

Group 11: Multi-function Input/Output Parameters for Extension Card

Group 12: Analog Input/Output Parameters for Extension Card

Group 13: PG function Parameters for Extension Card



# 4.1 Summary of Parameter Settings

★: The parameter can be set during operation.

### Group 0 User Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
00.00	Identity Code of the AC motor drive	Read-only	##	
00.01	Rated Current Display of the AC motor drive	Read-only	#.#	
		0: Parameter can be read/written		
		1: All parameters are read only		
00.02	Parameter Reset	6: Clear PLC program (NOT for VFD*E*C models)	0	
00.02	Parameter Reset	9: All parameters are reset to factory settings (50Hz, 230V/400V or 220V/380V depends on Pr.00.12)	0	
		10: All parameters are reset to factory settings (60Hz, 220V/440V)		
		0: Display the frequency command value (Fxxx)		
		1: Display the actual output frequency (Hxxx)		
<b>₩</b> 00.03	Start-up Display Selection	2: Display the content of user-defined unit (Uxxx)	0	
	Selection	3: Multifunction display, see Pr.00.04		
		4: FWD/REV command		
		5: PLCx (PLC selections: PLC0/PLC1/PLC2) (NOT for VFD*E*C models)		
<b>₩</b> 00.04	Content of Multi- function Display	0: Display the content of user-defined unit (Uxxx)	0	
		1: Display the counter value (c)		
		2: Display PLC D1043 value (C) (NOT for VFD*E*C models)		
		3: Display DC-BUS voltage (u)		
		4: Display output voltage (E)		

Parameter	Explanation	Chapter 4 Para Settings	Factory Setting	Customer
		5: Display PID analog feedback signal value (b) (%)		
		6: Output power factor angle (n)		
		7: Display output power (P)		
		8: Display the estimated value of torque as it relates to current (t)		
		9: Display AVI (I) (V)		
		10: Display ACI / AVI2 (i) (mA/V)		
		11: Display the temperature of IGBT (h) (°C)		
		12: Display AVI3/ACI2 level (I.)		
		13: Display AVI4/ACI3 level (i.)		
		14: Display PG speed in RPM (G)		
		15: Display motor number (M)		
<b>₩</b> 00.05	User-Defined Coefficient K	0. 1 to 160.0	1.0	
00.06	Power Board Software Version	Read-only	#.##	
00.07	Control Board Software Version	Read-only	#.##	
80.00	Password Input	0 to 9999	0	
00.09	Password Set	0 to 9999	0	
00.10	Control Method	0: V/f Control	0	
00.10	Control Metriou	1: Vector Control		
00.11	Reserved			
00.12	50Hz Base Voltage Selection	0: 230V/400V 1: 220V/380V	0	

### Group 1 Basic Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
01.00	Maximum Output Frequency (Fmax)	50.00 to 600.0 Hz	60.00	

Parameter	Explanation	Settings	Factory Setting	Customer
01.01	Maximum Voltage Frequency (Fbase) (Motor 0)	0.10 to 600.0 Hz	60.00	
01.02	Maximum Output	115V/230V series: 0.1V to 255.0V	220.0	
01.02	Voltage (Vmax) (Motor 0)	460V series: 0.1V to 510.0V	440.0	
01.03	Mid-Point Frequency (Fmid) (Motor 0)	0.10 to 600.0 Hz	1.50	
01.04	Mid-Point Voltage	115V/230V series: 0.1V to 255.0V	10.0	
01.04	(Vmid) (Motor 0)	460V series: 0.1V to 510.0V	20.0	
01.05	Minimum Output Frequency (Fmin) (Motor 0)	0.10 to 600.0 Hz	1.50	
04.00	Minimum Output	115V/230V series: 0.1V to 255.0V	10.0	
01.06	Voltage (Vmin) (Motor 0)	460V series: 0.1V to 510.0V	20.0	
01.07	Output Frequency Upper Limit	0.1 to 120.0%	110.0	
01.08	Output Frequency Lower Limit	0.0 to100.0 %	0.0	
<b> ∕</b> 01.09	Accel Time 1	0.1 to 600.0 / 0.01 to 600.0 sec	10.0	
<b> ∕ ∕</b> 01.10	Decel Time 1	0.1 to 600.0 / 0.01 to 600.0 sec	10.0	
<b>₩</b> 01.11	Accel Time 2	0.1 to 600.0 / 0.01 to 600.0 sec	10.0	
<b>⊮</b> 01.12	Decel Time 2	0.1 to 600.0 / 0.01 to 600.0 sec	10.0	
<b>⊮</b> 01.13	Jog Acceleration Time	0.1 to 600.0 / 0.01 to 600.0 sec	1.0	
<b>⊮</b> 01.14	Jog Deceleration Time	0.1 to 600.0 / 0.01 to 600.0 sec	1.0	
<b> ∕</b> 01.15	Jog Frequency	0.10 Hz to Fmax (Pr.01.00) Hz	6.00	
		0: Linear Accel/Decel		
	Auto appliantion /	1: Auto Accel, Linear Decel		
01.16	Auto acceleration / deceleration (refer	2: Linear Accel, Auto Decel	0	
	to Accel/Decel time setting)	3: Auto Accel/Decel (Set by load)		
		4: Auto Accel/Decel (set by Accel/Decel Time setting)		

Chapter 4 Parameters | Variable | Factory

Parameter	Explanation	Settings	Factory Setting	Customer
01.17	Acceleration S- Curve	0.0 to 10.0 / 0.00 to 10.00 sec	0.0	
01.18	Deceleration S- Curve	0.0 to 10.0 / 0.00 to 10.00 sec	0.0	
01.19	Accel/Decel Time	0: Unit: 0.1 sec	0	
	Unit	1: Unit: 0.01 sec	Ů	
01.20	Delay Time at 0Hz for Simple Position	0.00 to 600.00 sec	0.00	
01.21	Delay Time at 10Hz for Simple Position	0.00 to 600.00 sec	0.00	
01.22	Delay Time at 20Hz for Simple Position	0.00 to 600.00 sec	0.00	
01.23	Delay Time at 30Hz for Simple Position	0.00 to 600.00 sec	0.00	
01.24	Delay Time at 40Hz for Simple Position	0.00 to 600.00 sec	0.00	
01.25	Delay Time at 50Hz for Simple Position	0.00 to 600.00 sec	0.00	
01.26	Maximum Voltage Frequency (Fbase) (Motor 1)	0.10 to 600.0 Hz	60.00	
04.07	Maximum Output	115V/230V series: 0.1V to 255.0V	220.0	
01.27	Voltage (Vmax) (Motor 1)	460V series: 0.1V to 510.0V	440.0	
01.28	Mid-Point Frequency (Fmid) (Motor 1)	0.10 to 600.0 Hz	1.50	
01.29	Mid-Point Voltage	115V/230V series: 0.1V to 255.0V	10.0	
01.29	(Vmid) (Motor 1)	460V series: 0.1V to 510.0V	20.0	
01.30	Minimum Output Frequency (Fmin) (Motor 1)	0.10 to 600.0 Hz	1.50	
04.04	Minimum Output	115V/230V series: 0.1V to 255.0V	10.0	
01.31	Voltage (Vmin) (Motor 1)	460V series: 0.1V to 510.0V	20.0	
01.32	Maximum Voltage Frequency (Fbase) (Motor 2)	0.10 to 600.0 Hz	60.00	

Parameter	Explanation	Settings	Factory Setting	Customer
01.33	Maximum Output Voltage (Vmax)	115V/230V series: 0.1V to 255.0V	220.0	
01.33	(Motor 2)	460V series: 0.1V to 510.0V	440.0	
01.34	Mid-Point Frequency (Fmid) (Motor 2)	0.10 to 600.0 Hz	1.50	
01.35	Mid-Point Voltage	115V/230V series: 0.1V to 255.0V	10.0	
01.33	(Vmid) (Motor 2)	460V series: 0.1V to 510.0V	20.0	
01.36	Minimum Output Frequency (Fmin) (Motor 2)	0.10 to 600.0 Hz	1.50	
01.37	Minimum Output Voltage (Vmin)	115V/230V series: 0.1V to 255.0V	10.0	
01.37	(Motor 2)	460V series: 0.1V to 510.0V	20.0	
01.38	Maximum Voltage Frequency (Fbase) (Motor 3)	0.10 to 600.0 Hz	60.00	
01.39	Maximum Output	115V/230V series: 0.1V to 255.0V	220.0	
01.39	Voltage (Vmax) (Motor 3)	460V series: 0.1V to 510.0V	440.0	
01.40	Mid-Point Frequency (Fmid) (Motor 3)	0.10 to 600.0 Hz	1.50	
01.41	Mid-Point Voltage	115V/230V series: 0.1V to 255.0V	10.0	
01.41	(Vmid) (Motor 3)	460V series: 0.1V to 510.0V	20.0	
01.42	Minimum Output Frequency (Fmin) (Motor 3)	0.10 to 600.0 Hz	1.50	
01.43	Minimum Output	115V/230V series: 0.1V to 255.0V	10.0	
01.43	Voltage (Vmin) (Motor 3)	460V series: 0.1V to 510.0V	20.0	



## Group 2 Operation Method Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
		0: Digital keypad UP/DOWN keys or Multi- function Inputs UP/DOWN. Last used frequency saved.		
/00 00	Source of First	1: 0 to +10V from AVI		
<b>№</b> 02.00	Master Frequency Command	2: 4 to 20mA from ACI or 0 to +10V from AVI2	1	
		3: RS-485 (RJ-45)/USB communication		
		4: Digital keypad potentiometer		
		5: CANopen communication		
		0: Digital keypad		
		1: External terminals. Keypad STOP/RESET enabled.		
	Source of First Operation Command	2: External terminals. Keypad STOP/RESET disabled.		
<b>₩</b> 02.01		3: RS-485 (RJ-45)/USB communication. Keypad STOP/RESET enabled.	1	
		4: RS-485 (RJ-45)/USB communication. Keypad STOP/RESET disabled.		
		5: CANopen communication. Keypad STOP/RESET disabled.		
		0: STOP: ramp to stop; E.F.: coast to stop		
		1: STOP: coast to stop; E.F.: coast to stop		
02.02	Stop Method	2: STOP: ramp to stop; E.F.: ramp to stop	0	
		3: STOP: coast to stop; E.F.: ramp to stop		
02.03	PWM Carrier Frequency Selections	1 to 15kHz	8	
		0: Enable forward/reverse operation		
02.04	Motor Direction Control	1: Disable reverse operation	0	
		2: Disabled forward operation		
02.05	Line Start Lockout	0: Disable. Operation status is not changed even if operation command source Pr.02.01 is changed.	1	
		1: Enable. Operation status is not changed even if operation command source Pr.02.01 is changed.		

Parameter	Explanation	Settings	Factory Setting	Customer
		Disable. Operation status will change if operation command source Pr.02.01 is changed.		
		Enable. Operation status will change if operation command source Pr.02.01 is changed.		
		0: Decelerate to 0 Hz		
02.06	Loss of ACI Signal	1: Coast to stop and display "AErr"	1	
	(4-20mA)	2: Continue operation by last frequency command		
		0: by UP/DOWN Key		
02.07	Up/Down Mode	1: Based on accel/decel time	0	
02.07	Op/Down Mode	2: Constant speed (Pr.02.08)		
		3: Pulse input unit (Pr.02.08)		
02.08	Accel/Decel Rate of Change of UP/DOWN Operation with Constant Speed	0.01~10.00 Hz	0.01	
<b>₩</b> 02.09	Source of Second Frequency Command	O: Digital keypad UP/DOWN keys or Multifunction Inputs UP/DOWN. Last used frequency saved.  1: 0 to +10V from AVI 2: 4 to 20mA from ACI or 0 to +10V from AVI2 3: RS-485 (RJ-45)/USB communication 4: Digital keypad potentiometer 5: CANopen communication	0	
<b>⊮</b> 02.10	Combination of the First and Second Master Frequency Command	First Master Frequency Command     First Master Frequency Command+     Second Master Frequency Command     First Master Frequency Command -     Second Master Frequency Command	0	
<b>⊮</b> 02.11	Keypad Frequency Command	0.00 to 600.0Hz	60.00	
<b>⊮</b> 02.12	Communication Frequency Command	0.00 to 600.0Hz	60.00	

<del> </del>		Chapter 4 Para		VFD-E
Parameter	Explanation	Settings	Factory Setting	Customer
	The Selections for Saving Keypad or	0: Save Keypad & Communication Frequency		
02.13	Communication Frequency Command	1: Save Keypad Frequency only	0	
		2: Save Communication Frequency only		
	Initial Frequency	0: by Current Freq Command		
02.14	Selection (for keypad &	1: by Zero Freq Command	0	
	RS485/USB)	2: by Frequency Display at Stop		
02.15	Initial Frequency Setpoint (for keypad & RS485/USB)	0.00 ~ 600.0Hz	60.00	
02.16	Display the Master Freq Command Source	Read Only Bit0=1: by First Freq Source (Pr.02.00) Bit1=1: by Second Freq Source (Pr.02.09) Bit2=1: by Multi-input function Bit3=1: by PLC Freq command (NOT for VFD*E*C models)	##	
02.17	Display the Operation Command Source	Read Only Bit0=1: by Digital Keypad Bit1=1: by RS485 communication Bit2=1: by External Terminal 2/3 wire mode Bit3=1: by Multi-input function Bit4=1: by PLC Operation Command (NOT for VFD*E*C models) Bit5=1: by CANopen communication	##	

Group 3 Output Function Parameters

Modulation

02.18

Selection of Carrier

Parameter	Explanation	Settings	Factory Setting	Customer
		0: No function	8	
03.00	Multi-function Output Relay (RA1, RB1, RC1)	1: AC drive operational		
03.00		2: Master frequency attained		
		3: Zero speed		
		4: Over torque detection		

0: by carrier modulation of load current and temperature

1: by carrier modulation of load current

0

Parameter	Explanation	Settings	Factory Setting	Customer
	Multi-function	5: Base-Block (B.B.) indication	1	
03.01	Output Terminal	6: Low-voltage indication		
	MO1	7: Operation mode indication		
		8: Fault indication		
		9: Desired frequency 1 attained		
		10: Terminal count value attained		
		11: Preliminary count value attained		
		12: Over Voltage Stall supervision		
		13: Over Current Stall supervision		
		14: Heat sink overheat warning		
		15: Over Voltage supervision		
		16: PID supervision		
		17: Forward command		
		18: Reverse command		
		19: Zero speed output signal		
		20: Warning(FbE,Cexx, AoL2, AUE, SAvE)		
		21: Brake control (Desired frequency attained)		
		22: Drive ready		
		23: Desired frequency 2 attained		
03.02	Desired Frequency 1 Attained	0.00 to 600.0Hz	0.00	
	Analog Output	0: Analog frequency meter		
<b>№</b> 03.03	Signal Selection (AFM)	1: Analog current meter	0	
<b>№</b> 03.04	Analog Output Gain	1 to 200%	100	
03.05	Terminal Count Value	0 to 9999	0	
03.06	Preliminary Count Value	0 to 9999	0	
03.07	EF Active When Terminal Count	0: Terminal count value attained, no EF display	0	
	Value Attained	1: Terminal count value attained, EF active		
03.08	Fan Control	0: Fan always ON	0	

Chapter 4 Parameters Factory Customer Parameter Explanation Settings Setting 1: 1 minute after AC motor drive stops, fan will be OFF 2: Fan ON when AC motor drive runs, fan OFF when AC motor drive stops 3: Fan ON when preliminary heatsink temperature attained Read only Bit0=1:RLY used by PLC Bit1=1:MO1 used by PLC The Digital Output Bit2=1:MO2/RA2 used by PLC Used by PLC 03 09 ## Bit3=1:MO3/RA3 used by PLC (NOT for VFD\*E\*C models) Bit4=1:MO4/RA4 used by PLC Bit5=1:MO5/RA5 used by PLC Bit6=1:MO6/RA6 used by PLC Bit7=1:MO7/RA7 used by PLC Read only The Analog Output Bit0=1:AFM used by PLC Used by PLC 03.10 ## (NOT for VFD\*E\*C Bit1=1: AO1 used by PLC models) Bit2=1: AO2 used by PLC Brake Release 03.11 0.00 to 20.00Hz 0.00 Frequency Brake Engage 0.00 to 20.00Hz 0.00 03 12 Frequency Read only Bit0: RLY Status Bit1: MO1 Status Bit2: MO2/RA2 Status Display the Status of 03 13 Multi-function Bit3: MO3/RA3 Status ## **Output Terminals** Bit4: MO4/RA4 Status Bit5: MO5/RA5 Status Bit6: MO6/RA6 Status Bit7: MO7/RA7 Status

Desired Frequency

2 Attained

0.00 to 600 0Hz

03 14

0.00



## Group 4 Input Function Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
<b>₩</b> 04.00	Keypad Potentiometer Bias	0.0 to 100.0 %	0.0	
<b>₩</b> 04.01	Keypad Potentiometer Bias Polarity	0: Positive bias 1: Negative bias	00	
<b>₩</b> 04.02	Keypad Potentiometer Gain	0.1 to 200.0 %	100.0	
04.03	Keypad Potentiometer Negative Bias, Reverse Motion	0: No negative bias command	0	
	Enable/Disable	1: Negative bias: REV motion enabled		
04.04	2-wire/3-wire Operation Control	0: 2-wire: FWD/STOP, REV/STOP		
	Modes	1: 2-wire: FWD/REV, RUN/STOP	0	
		2: 3-wire operation		
04.05	Multi-function Input Terminal (MI3)	0: No function	1	
	reminal (Mis)	1: Multi-Step speed command 1		
		2: Multi-Step speed command 2		
04.06	Multi-function Input Terminal (MI4)	3: Multi-Step speed command 3	2	
	reminai (MI4)	4: Multi-Step speed command 4		
		5: External reset		
04.07	Multi-function Input Terminal (MI5)	6: Accel/Decel inhibit	3	
	reminai (iviis)	7: Accel/Decel time selection command		
		8: Jog Operation		
04.08	Multi-function Input Terminal (MI6)	9: External base block	4	
	Terminal (MI6)	10: Up: Increment master frequency		
		11: Down: Decrement master frequency		
		12: Counter Trigger Signal		
		13: Counter reset		
		14: E.F. External Fault Input		

Parameter	Explanation	Chapter 4 Para Settings	Factory Setting	Customer
		15: PID function disabled	Octung	
		16: Output shutoff stop		
		17: Parameter lock enable		
		18: Operation command selection (external terminals)		
		19: Operation command selection(keypad)		
		20: Operation command selection (communication)		
		21: FWD/REV command		
		22: Source of second frequency command		
		23: Run/Stop PLC Program (PLC1) (NOT for VFD*E*C models)		
		23: Quick Stop (Only for VFD*E*C models)		
		24: Download/execute/monitor PLC Program (PLC2) (NOT for VFD*E*C models)		
		25: Simple position function		
		26: OOB (Out of Balance Detection)		
		27: Motor selection (bit 0)		
		28: Motor selection (bit 1)		
		Bit0:MI1		
		Bit1:MI2		
		Bit2:MI3		
		Bit3:MI4		
		Bit4:MI5		
		Bit5:MI6		
04.09		Bit6:MI7		
	Multi-function Input Contact Selection	Bit7:MI8	0	
	Contact Selection	Bit8:MI9		
		Bit9:MI10		
		Bit10:MI11		
		Bit11:MI12		
		0:N.O., 1:N.C.		
		P.S.:MI1 to MI3 will be invalid when it is 3-wire control.		
04.10	Digital Terminal Input Debouncing Time	1 to 20 (*2ms)	1	

VED-E			
1/27/1			
1/27/20 -1			

Parameter	Explanation	Settings	Factory Setting	Customer
04.11	Min AVI Voltage	0.0 to 10.0V	0.0	
04.12	Min AVI Frequency	0.0 to 100.0%	0.0	
04.13	Max AVI Voltage	0.0 to 10.0V	10.0	
04.14	Max AVI Frequency	0.0 to 100.0%	100.0	
04.15	Min ACI Current	0.0 to 20.0mA	4.0	
04.16	Min ACI Frequency	0.0 to 100.0%	0.0	
04.17	Max ACI Current	0.0 to 20.0mA	20.0	
04.18	Max ACI Frequency	0.0 to 100.0%	100.0	
04.19	ACI/AVI2 Selection	0: ACI	0	
	7.0	1: AVI2	Ů	
04.20	Min AVI2 Voltage	0.0 to 10.0V	0.0	
04.21	Min AVI2 Frequency	0.0 to 100.0%	0.0	
04.22	Max AVI2 Voltage	0.0 to 10.0V	10.0	
04.23	Max AVI2 Frequency	0.0 to 100.0%	100.0	
04.24	The Digital Input	Read only	##	
	Used by PLC (NOT for VFD*E*C	Bit0=1:MI1 used by PLC		
	models)	Bit1=1:MI2 used by PLC		
		Bit2=1:MI3 used by PLC		
		Bit3=1:MI4 used by PLC		
		Bit4=1:MI5 used by PLC		
		Bit5=1:MI6 used by PLC		
		Bit6=1: MI7 used by PLC		
		Bit7=1: MI8 used by PLC		
		Bit8=1: MI9 used by PLC		
		Bit9=1: MI10 used by PLC		
		Bit10=1: MI11 used by PLC		

		Chapter 4 Para		
Parameter	Explanation	Settings	Factory Setting	Customer
		Bit11=1: MI12 used by PLC		
		Read only		
	The Analog Input	Bit0=1:AVI used by PLC		
04.25	Used by PLC (NOT for VFD*E*C	Bit1=1:ACI/AVI2 used by PLC	##	
	models)	Bit2=1: Al1 used by PLC		
		Bit3=1: Al2 used by PLC		
		Read only		
		Bit0: MI1 Status		
	Display the Status	Bit1: MI2 Status		
		Bit2: MI3 Status		
		Bit3: MI4 Status		
		Bit4: MI5 Status		
04.26	of Multi-function	Bit5: MI6 Status	##	
	Input Terminal	Bit6: MI7 Status		
		Bit7: MI8 Status		
		Bit8: MI9 Status		
		Bit9: MI10 Status		
		Bit10: MI11 Status		
		Bit11: MI12 Status		
04.27	Internal/External Multi-function Input Terminals Selection	0~4095	0	
<b> ∕</b> 04.28	Internal Terminal Status	0~4095	0	

## Group 5 Multi-Step Speeds Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
<b>№</b> 05.00	1st Step Speed Frequency	0.00 to 600.0 Hz	0.00	
<b>№</b> 05.01	2nd Step Speed Frequency	0.00 to 600.0 Hz	0.00	

Chapter 4 Parameters | V=201E

Parameter	Explanation	Settings	Factory Setting	Customer
<b>⊮</b> 05.02	3rd Step Speed Frequency	0.00 to 600.0 Hz	0.00	
<b>⊮</b> 05.03	4th Step Speed Frequency	0.00 to 600.0 Hz	0.00	
<b>№</b> 05.04	5th Step Speed Frequency	0.00 to 600.0 Hz	0.00	
<b>₩</b> 05.05	6th Step Speed Frequency	0.00 to 600.0 Hz	0.00	
<b>№</b> 05.06	7th Step Speed Frequency	0.00 to 600.0 Hz	0.00	
<b>№</b> 05.07	8th Step Speed Frequency	0.00 to 600.0 Hz	0.00	
<b>№</b> 05.08	9th Step Speed Frequency	0.00 to 600.0 Hz	0.00	
<b>№</b> 05.09	10th Step Speed Frequency	0.00 to 600.0 Hz	0.00	
<b>⊮</b> 05.10	11th Step Speed Frequency	0.00 to 600.0 Hz	0.00	
<b>⊮</b> 05.11	12th Step Speed Frequency	0.00 to 600.0 Hz	0.00	
<b>⊮</b> 05.12	13th Step Speed Frequency	0.00 to 600.0 Hz	0.00	
<b>⊮</b> 05.13	14th Step Speed Frequency	0.00 to 600.0 Hz	0.00	
<b>⊮</b> 05.14	15th Step Speed Frequency	0.00 to 600.0 Hz	0.00	

### **Group 6 Protection Parameters**

Parameter	Explanation	Settings	Factory Setting	Customer
		115/230V series: 330.0V to 410.0V	390.0V	
06.00	Over-Voltage Stall Prevention	460V series: 660.0V to 820.0V	780.0V	
		0.0: Disable over-voltage stall prevention		
06.01	Over-Current Stall Prevention during Accel	0:Disable 20 to 250%	170	

Chapter 4 Parameters | Valle

Parameter	Explanation	Settings	Factory Setting	Customer
06.02	Over-Current Stall Prevention during Operation	0:Disable 20 to 250%	170	
		0: Disabled		
		Enabled during constant speed operation. After the over-torque is detected, keep running until OL1 or OL occurs.	0	
06.03	Over-Torque Detection Mode (OL2)	2: Enabled during constant speed operation. After the over-torque is detected, stop running.		
		3: Enabled during accel. After the over-torque is detected, keep running until OL1 or OL occurs.		
		4: Enabled during accel. After the over-torque is detected, stop running.		
<b>№</b> 06.04	Over-Torque Detection Level	10 to 200%	150	
06.05	Over-Torque Detection Time	0.1 to 60.0 sec	0.1	
	Electronic Thermal	0: Standard motor (self cooled by fan)		
06.06	Overload Relay Selection	1: Special motor (forced external cooling)	2	
		2: Disabled		
06.07	Electronic Thermal Characteristic	30 to 600 sec	60	
		0: No fault	0	
		1: Over current (oc)		
06.08	Present Fault Record	2: Over voltage (ov)		
		3: IGBT Overheat (oH1)		
		4: Power Board Overheat (oH2)		
		5: Overload (oL)		
		6: Overload1 (oL1)		
		7: Motor over load (oL2)		
06.09	Second Most	8: External fault (EF)		
	Recent Fault Record	9: Current exceeds 2 times rated current during accel.(ocA)		

Parameter	Explanation	Settings	Factory Setting	Customer
		10: Current exceeds 2 times rated current during decel.(ocd)		
		11: Current exceeds 2 times rated current during steady state operation (ocn)		
		12: Ground fault (GFF)		
		13: Reserved		
		14: Phase-Loss (PHL)		
		15: Reserved		
		16: Auto Acel/Decel failure (CFA)		
06.10	Third Most Recent	17: SW/Password protection (codE)		
	Fault Record	18: Power Board CPU WRITE failure (cF1.0)		
		19: Power Board CPU READ failure (cF2.0)		
		20: CC, OC Hardware protection failure (HPF1)		
06.11	Fourth Most Recent	21: OV Hardware protection failure (HPF2)		
	Fault Record	22: GFF Hardware protection failure (HPF3)		
		23: OC Hardware protection failure (HPF4)		
		24: U-phase error (cF3.0)		
06.12	Fifth Most Recent	25: V-phase error (cF3.1)		
00.12	Fault Record	26: W-phase error (cF3.2)		
		27: DCBUS error (cF3.3)		
		28: IGBT Overheat (cF3.4)		
		29: Power Board Overheat (cF3.5)		
		30: Control Board CPU WRITE failure (cF1.1)		
		31: Control Board CPU WRITE failure (cF2.1)		
		32: ACI signal error (AErr)		
		33: Reserved		

		Chapter 4 Para		VIEW E
Parameter	Explanation	Settings	Factory Setting	Customer
		34: Motor PTC overheat protection (PtC1)		
		35-39: Reserved		
		40: Communication time-out error of control board and power board (CP10)		
		41: dEb error		
		42: ACL (Abnormal Communication Loop)		

# Group 7 Motor Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
07.00	Motor Rated Current (Motor 0)	30 %FLA to 120% FLA	FLA	
07.01	Motor No-Load Current (Motor 0)	0%FLA to 99% FLA	0.4*FLA	
<b>₩</b> 07.02	Torque Compensation (Motor 0)	0.0 to 10.0	0.0	
<b>₩</b> 07.03	Slip Compensation (Used without PG) (Motor 0)	0.00 to 10.00	0.00	
07.04	Motor Parameters Auto Tuning	0: Disable 1: Auto tuning R1 2: Auto tuning R1 + no-load test	0	
07.05	Motor Line-to-line Resistance R1 (Motor 0)	0~65535 mΩ	0	
07.06	Motor Rated Slip (Motor 0)	0.00 to 20.00 Hz	3.00	
07.07	Slip Compensation Limit	0 to 250%	200	
07.08	Torque Compensation Time Constant	0.01 ~10.00 Sec	0.30	
07.09	Slip Compensation Time Constant	0.05 ~10.00 sec	0.20	
07.10	Accumulative Motor Operation Time (Min.)	0 to 1439 Min.	0	

Parameter	Explanation	Settings	Factory Setting	Customer
07.11	Accumulative Motor Operation Time (Day)	0 to 65535 Day	0	
07.12	Motor PTC Overheat Protection	0: Disable 1: Enable	0	
07.13	Input Debouncing Time of the PTC Protection	0~9999(*2ms)	100	
07.14	Motor PTC Overheat Protection Level	0.1~10.0V	2.4	
07.15	Motor PTC Overheat Warning Level	0.1~10.0V	1.2	
07.16	Motor PTC Overheat Reset Delta Level	0.1~5.0V	0.6	
07.17	Treatment of the Motor PTC Overheat	0: Warn and RAMP to stop 1: Warn and COAST to stop 2: Warn and keep running	0	
07.18	Motor Rated Current (Motor 1)	30 %FLA to 120% FLA	FLA	
07.19	Motor No-Load Current (Motor 1)	0%FLA to 99% FLA	0.4*FLA	
<b>⊮</b> 07.20	Torque Compensation (Motor 1)	0.0 to 10.0	0.0	
<b>⊮</b> 07.21	Slip Compensation (Used without PG) (Motor 1)	0.00 to 10.00	0.00	
07.22	Motor Line-to-line Resistance R1 (Motor 1)	0~65535 mΩ	0	
07.23	Motor Rated Slip (Motor 1)	0.00 to 20.00 Hz	3.00	
07.24	Motor Pole Number (Motor 1)	2 to 10	4	
07.25	Motor Rated Current (Motor 2)	30 %FLA to 120% FLA	FLA	

	Chapter 4 Parameters				
Parameter	Explanation	Settings	Factory Setting	Customer	
07.26	Motor No-Load Current (Motor 2)	0%FLA to 99% FLA	0.4*FLA		
<b>⊮</b> 07.27	Torque Compensation (Motor 2)	0.0 to 10.0	0.0		
<b>⊮</b> 07.28	Slip Compensation (Used without PG) (Motor 2)	0.00 to 10.00	0.00		
07.29	Motor Line-to-line Resistance R1 (Motor 2)	0~65535 mΩ	0		
07.30	Motor Rated Slip (Motor 2)	0.00 to 20.00 Hz	3.00		
07.31	Motor Pole Number (Motor 3)	2 to 10	4		
07.32	Motor Rated Current (Motor 3)	30 %FLA to 120% FLA	FLA		
07.33	Motor No-Load Current (Motor 3)	0%FLA to 99% FLA	0.4*FLA		
<b>₩</b> 07.34	Torque Compensation (Motor 3)	0.0 to 10.0	0.0		
<b>№</b> 07.35	Slip Compensation (Used without PG) (Motor 3)	0.00 to 10.00	0.00		
07.36	Motor Line-to-line Resistance R1 (Motor 3)	0~65535 mΩ	0		
07.37	Motor Rated Slip (Motor 3)	0.00 to 20.00 Hz	3.00		

#### **Group 8 Special Parameters**

(Motor 3)

07.38

Parameter	Explanation	Settings	Factory Setting	Customer
08.00	DC Brake Current Level	0 to 100%	0	

2 to 10

Motor Pole Number

4

Parameter	Explanation	Settings	Factory Setting	Customer
08.01	DC Brake Time during Start-Up	0.0 to 60.0 sec	0.0	
08.02	DC Brake Time during Stopping	0.0 to 60.0 sec	0.0	
08.03	Start-Point for DC Brake	0.00 to 600.0Hz	0.00	
08.04	Momentary Power Loss Operation Selection	O: Operation stops after momentary power loss     Operation continues after momentary power loss, speed search starts with the Last Frequency     Operation continues after momentary power loss, speed search starts with the minimum frequency	0	
08.05	Maximum Allowable Power Loss Time	0.1 to 20.0 sec	2.0	
08.06	Base-block Speed Search	Disable speed search     Speed search starts with last frequency     Starts with minimum output frequency	1	
08.07	B.B. Time for Speed Search	0.1 to 5.0 sec	0.5	
08.08	Current Limit for Speed Search	30 to 200%	150	
08.09	Skip Frequency 1 Upper Limit	0.00 to 600.0 Hz	0.00	
08.10	Skip Frequency 1 Lower Limit	0.00 to 600.0 Hz	0.00	
08.11	Skip Frequency 2 Upper Limit	0.00 to 600.0 Hz	0.00	
08.12	Skip Frequency 2 Lower Limit	0.00 to 600.0 Hz	0.00	
08.13	Skip Frequency 3 Upper Limit	0.00 to 600.0 Hz	0.00	
08.14	Skip Frequency 3 Lower Limit	0.00 to 600.0 Hz	0.00	
08.15	Auto Restart After Fault	0 to 10 (0=disable)	0	
			1	

Chapter 4 Paramete	ters
--------------------	------

		epto u.u		
Parameter	Explanation	Settings	Factory Setting	Customer
08.16	Auto Reset Time at Restart after Fault	0.1 to 6000 sec	60.0	
		0: Disable		
08.17	Auto Energy Saving	1: Enable	0	
		0: AVR function enable	0	
08.18	AVR Function	1: AVR function disable		
06.16	AVR FUNCTION	2: AVR function disable for decel.		
		3: AVR function disable for stop		
08.19	Software Brake	115V / 230V series: 370.0to 430.0V	380.0	
08.19	Level	460V series: 740.0 to 860.0V	760.0	
<b>⊮</b> 08.20	Compensation Coefficient for Motor Instability	0.0~5.0	0.0	
08.21	OOB Sampling Time	0.1 to 120.0 sec	1.0	
08.22	Number of OOB Sampling Times	00 to 32	20	
08.23	OOB Average Sampling Angle	Read only	#.#	
08.24	DEB Function	0: Disable	0	
JUL 201.24	DEB I GIISTOII	1: Enable		
08.25	DEB Return Time	0 to 250 sec	0	

# Group 9 Communication Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
<b>₩</b> 09.00	Communication Address	1 to 254	1	
		0: Baud rate 4800bps		
<b>№</b> 09.01	Transmission Speed	1: Baud rate 9600bps	1	
<b>7</b> 09.01	Transmission Speed	2: Baud rate 19200bps	'	
		3: Baud rate 38400bps		

Parameter	Explanation	Settings	Factory Setting	Customer
		0: Warn and keep operating		
	Transmission Fault	1: Warn and ramp to stop	_	
<b>№</b> 09.02	Treatment	2: Warn and coast to stop	3	
		3: No warning and keep operating		
<b>№</b> 09.03	Time-out Detection	0.1 ~ 120.0 seconds 0.0: Disable	0.0	
		0: 7,N,2 (Modbus, ASCII)		
		1: 7,E,1 (Modbus, ASCII)	0	
100.04	Communication	2: 7,O,1 (Modbus, ASCII)		
<b>№</b> 09.04	Protocol	3: 8,N,2 (Modbus, RTU)		
		4: 8,E,1 (Modbus, RTU)		
		5: 8,O,1 (Modbus, RTU)		
		6: 8,N,1 (Modbus, RTU)		
		7: 8,E,2 (Modbus, RTU)		
		8: 8,O,2 (Modbus, RTU)		
		9: 7,N,1 (Modbus, ASCII)		
		10: 7,E,2 (Modbus, ASCII)		
		11: 7,O,2 (Modbus, ASCII)		
09.05	Reserved			
09.06	Reserved			
<b>№</b> 09.07	Response Delay Time	0 ~ 200 (unit: 2ms)	1	
<b>№</b> 09.08	Transmission Speed for USB Card	0: Baud rate 4800 bps 1: Baud rate 9600 bps 2: Baud rate 19200 bps 3: Baud rate 38400 bps 4: Baud rate 57600 bps	2	

Chapter 4 Parameters				1/577 E
Parameter	Explanation	Settings	Factory Setting	Customer
<b>№</b> 09.09	Communication Protocol for USB Card	0: 7,N,2 for ASCII 1: 7,E,1 for ASCII 2: 7,O,1 for ASCII 3: 8,N,2 for RTU 4: 8,E,1 for RTU 5: 8,O,1 for RTU	1	
<b>№</b> 09.09	Communication Protocol for USB Card	6: 8,N,1 (Modbus, RTU) 7: 8,E,2 (Modbus, RTU) 8: 8,O,2 (Modbus, RTU) 9: 7,N,1 (Modbus, ASCII) 10: 7,E,2 (Modbus, ASCII) 11: 7,O,2 (Modbus, ASCII)		
<b>₩</b> 09.10	Transmission Fault Treatment for USB Card	0: Warn and keep operating 1: Warn and ramp to stop 2: Warn and coast to stop 3: No warning and keep operating	0	
<b>₩</b> 09.11	Time-out Detection for USB Card	0.1 ~ 120.0 seconds 0.0: Disable	0.0	
09.12	COM port for PLC Communication (NOT for VFD*E*C	0: RS485 1: USB card	0	

# Group 10 PID Control Parameters

models)

Parameter	Explanation	Settings	Factory Setting	Customer
		0: Disable PID operation		
		1: Keypad (based on Pr.02.00)		
10.00	PID Set Point	2: 0 to +10V from AVI	0	
	Selection	3: 4 to 20mA from ACI or 0 to +10V from AVI2		
		4: PID set point (Pr.10.11)		

Parameter	Explanation	Settings	Factory Setting	Customer
		0: Positive PID feedback from external terminal AVI (0 ~ +10VDC)		
10.01		1: Negative PID feedback from external terminal AVI (0 ~ +10VDC)		
	Input Terminal for PID Feedback	2: Positive PID feedback from external terminal ACI (4 ~ 20mA)/ AVI2 (0 ~ +10VDC).	0	
		3: Negative PID feedback from external terminal ACI (4 ~ 20mA)/ AVI2 (0 ~ +10VDC).		
<b>⊮</b> 10.02	Proportional Gain (P)	0.0 to 10.0	1.0	
<b>⊮</b> 10.03	Integral Time (I)	0.00 to 100.0 sec (0.00=disable)	1.00	
<b>⊮</b> 10.04	Derivative Control (D)	0.00 to 1.00 sec	0.00	
10.05	Upper Bound for Integral Control	0 to 100%	100	
10.06	Primary Delay Filter Time	0.0 to 2.5 sec	0.0	
10.07	PID Output Freq Limit	0 to 110%	100	
10.08	PID Feedback Signal Detection Time	0.0 to 3600 sec (0.0 disable)	60.0	
	Treatment of the	0: Warn and RAMP to stop		
10.09	Erroneous PID Feedback Signals	1: Warn and COAST to stop	0	
	T CCUDACK OIGHAIS	2: Warn and keep operation		
10.10	Gain Over the PID Detection Value	0.0 to 10.0	1.0	
<b>ж</b> 10.11	Source of PID Set point	0.00 to 600.0Hz	0.00	
10.12	PID Offset Level	1.0 to 50.0%	10.0	
10.13	Detection Time of PID Offset	0.1 to 300.0 sec	5.0	
10.14	Sleep/Wake Up Detection Time	0.0 to 6550 sec	0.0	
10.15	Sleep Frequency	0.00 to 600.0 Hz	0.00	

Chapter 4 Parameters | V

Parameter	Explanation	Settings	Factory Setting	Customer
10.16	Wakeup Frequency	0.00 to 600.0 Hz	0.00	
10.17	Minimum PID Output Frequency Selection	0: By PID control 1: By minimum output frequency (Pr.01.05)	0	

Group 11 Parameters for Extension Card

Parameter	Explanation	Settings	Factory Setting	Customer
		0: No function		
11.00	Multi-function 1: AC	1: AC drive operational	0	
11.00	Output Terminal MO2/RA2	2: Master frequency attained	0	
		3: Zero speed		
		4: Over torque detection		
44.04	Multi-function	5: Base-Block (B.B.) indication		
11.01	Output Terminal MO3/RA3	6: Low-voltage indication	0	
		7: Operation mode indication		
		8: Fault indication		
	Multi-function Output Terminal MO4/RA4	9: Desired frequency 1 attained		
11.02		10: Terminal count value attained	0	
		11: Preliminary count value attained		
		12: Over Voltage Stall supervision		
44.00	Multi-function	13: Over Current Stall supervision		
11.03	Output Terminal MO5/RA5	14: Heat sink overheat warning	0	
		15: Over Voltage supervision		
		16: PID supervision		
11 04	Multi-function Output Terminal	17: Forward command	0	
11.04	MO6/RA6	18: Reverse command		
		19: Zero speed output signal		
		20: Warning(FbE,Cexx, AoL2, AUE, SAvE)		

Parameter	Explanation	Settings	Factory Setting	Customer
	Multi-function	21: Brake control (Desired frequency attained)	0	
11.05	Output Terminal MO7/RA7	22: Drive ready		
		23: Desired frequency 2 attained		
		0: No function	0	
11.06 Multi-function Input Terminal (MI7)		1: Multi-Step speed command 1		
		2: Multi-Step speed command 2		
		3: Multi-Step speed command 3	0	
11.07 Multi-function Input Terminal (MI8)		4: Multi-Step speed command 4		
		5: External reset		
		6: Accel/Decel inhibit	0	
11.08	Multi-function Input Terminal (MI9)	7: Accel/Decel time selection command		
		8: Jog Operation		
		9: External base block	0	
11.09	11.09 Multi-function Input Terminal (MI10)	10: Up: Increment master frequency		
		11: Down: Decrement master frequency		
		12: Counter Trigger Signal	0	
11.10	Multi-function Input	13: Counter reset		
11.10	Terminal (MI11)	14: E.F. External Fault Input		
		15: PID function disabled		
11.11	Multi-function Input Terminal (MI12)	16: Output shutoff stop	0	
	reminal (M112)	17: Parameter lock enable		
		18: Operation command selection (external terminals)		
		19: Operation command selection (keypad)		
		20: Operation command selection (communication)		
		21: FWD/REV command		
		22: Source of second frequency command		
		23: Run/Stop PLC Program (PLC1) (NOT for VFD*E*C models)		

			Chapter 4 Parameters		
Parameter	Explanation	Settings	Factory Setting	Customer	
		23: Quick Stop (Only for VFD*E*C models)			
	24: Download/execute/monitor PLC Program (PLC2) (NOT for VFD*E*C models)				
	25: Simple position function				
		26: OOB (Out of Balance Detection)			
		27: Motor selection (bit 0)			
		28: Motor selection (bit 1)			

Group 12: Analog Input/Output Parameters for Extension Card

Parameter	Explanation	Settings	Factory Setting	Customer
		0: Disabled		
		1: Source of the 1st frequency		
12.00	Al1 Function	2: Source of the 2nd frequency	0	
12.00	Selection	3: PID Set Point (PID enable)	U	
		4: Positive PID feedback		
		5: Negative PID feedback		
12.01	Al1 Analog Signal	0: ACI2 analog current (0.0 ~ 20.0mA)	1	
12.01	Mode	1: AVI3 analog voltage (0.0 ~ 10.0V)	ı	
12.02	Min. AVI3 Input Voltage	0.0 to 10.0V	0.0	
12.03	Min. AVI3 Scale Percentage	0.0 to 100.0%	0.0	
12.04	Max. AVI3 Input Voltage	0.0 to 10.0V	10.0	
12.05	Max. AVI3 Scale Percentage	0.0 to 100.0%		
12.06	Min. ACI2 Input Current	0.0 to 20.0mA	4.0	
12.07	Min. ACI2 Scale Percentage	0.0 to 100.0%	0.0	

Parameter	Explanation	Settings	Factory Setting	Customer
12.08	Max. ACI2 Input Current	0.0 to 20.0mA	20.0	
12.09	Max. ACI2 Scale Percentage	0.0 to 100.0%	100.0	
12.10	Al2 Function Selection	0: Disabled 1: Source of the 1st frequency 2: Source of the 2nd frequency 3: PID Set Point (PID enable) 4: Positive PID feedback 5: Negative PID feedback		
12.11	Al2 Analog Signal Mode	0: ACI3 analog current (0.0 ~ 20.0mA) 1: AVI4 analog voltage (0.0 ~ 10.0V)	1	
12.12	Min. AVI4 Input Voltage	0.0 to 10.0V	0.0	
12.13	Min. AVI4 Scale Percentage	0.0 to 100.0%	0.0	
12.14	Max. AVI4 Input Voltage	0.0 to 10.0V	10.0	
12.15	Max. AVI4 Scale Percentage	0.0 to 100.0%		
12.16	Min. ACI3 Input Current	0.0 to 20.0mA		
12.17	Min. ACI3 Scale Percentage	0.0 to 100.0%	0.0	
12.18	Max. ACI3 Input Current	0.0 to 20.0mA	20.0	
12.19	Max. ACI3 Scale Percentage	0.0 to 100.0%	100.0	
12.20	AO1 Terminal Analog Signal Mode	0: AVO1 1: ACO1 (analog current 0.0 to 20.0mA) 2: ACO1 (analog current 4.0 to 20.0mA)	0	
12.21	AO1 Analog Output Signal	0: Analog Frequency 1: Analog Current (0 to 250% rated current)	0	
12.22	AO1 Analog Output Gain	1 to 200%	100	

Chapter 4 Parameters | Variable Factory Setting Customer Parameter Explanation Settings 0: AVO2 AO2 Terminal 12.23 1: ACO2 (analog current 0.0 to 20.0mA) 0 Analog Signal Mode 2: ACO2 (analog current 4.0 to 20.0mA) 0: Analog Frequency AO2 Analog Output 12.24 0 Signal 1: Analog Current (0 to 250% rated current) AO2 Analog Output 12.25 1 to 200% 100

Gain

# Chapter 4 Parameters | Variation

Group 13: PG function Parameters for Extension Card

Parameter	Explanation	Settings	Factory Setting	Customer
13.00	PG Input	Disabled     Single phase     Forward/Counterclockwise rotation	0	
		3: Reverse/Clockwise rotation		
13.01	PG Pulse Range	1 to 20000	600	
13.02	Motor Pole Number (Motor 0)	2 to 10	4	
<b>⊮</b> 13.03	Proportional Gain (P)	0.0 to 10.0	1.0	
<b>⊮</b> 13.04	Integral Gain (I)	0.00 to 100.00 sec	1.00	
<b>⊮</b> 13.05	Speed Control Output Frequency Limit	0.00 to 100.00Hz	10.00	
<b>⊮</b> 13.06	Speed Feedback Display Filter	0 to 9999 (*2ms)	500	
<b>⊮</b> 13.07	Detection Time for Feedback Signal Fault	0.0: disabled 0.1 to 10.0 sec	1	
<b>⊮</b> 13.08	Treatment of the Feedback Signal Fault	O: Warn and RAMP to stop  1: Warn and COAST to stop  2: Warn and keep operation	1	
<b>⊮</b> 13.09	Speed Feedback Filter	0 to 9999 (*2ms)	16	
13.10	Source of the High-	0: PG card	Read	
13.10	speed Counter	1: PLC (NOT for VFD*E*C models)	Only	



# 4.2 Parameter Settings for Applications

#### **Speed Search**

Applications	Purpose	Functions	Related Parameters
Windmill, winding machine, fan and all inertia loads	Restart free- running motor	Before the free-running motor is completely stopped, it can be restarted without detection of motor speed. The AC motor drive will auto search motor speed and will accelerate when its speed is the same as the motor speed.	08.04~08.08

#### DC Brake before Running

Applications	Purpose	Functions	Related Parameters
When e.g. windmills, fans and pumps rotate freely by wind or flow without applying power	standstill.	If the running direction of the free- running motor is not steady, please execute DC brake before start-up.	08.00 08.01

# **Energy Saving**

Applications	Purpose	Functions	Related Parameters
Punching machines fans, pumps and precision machinery	Energy saving and less vibrations	Energy saving when the AC motor drive runs at constant speed, yet full power acceleration and deceleration For precision machinery it also helps to lower vibrations.	08.17

#### **Multi-step Operation**

Applications	Purpose	Functions	Related Parameters
Conveying machinery		To control 15-step speeds and duration by simple contact signals.	04.05~04.10 05.00~05.14

# Switching acceleration and deceleration times

Applications	Purpose	Functions	Related Parameters
Auto turntable for conveying machinery	Switching acceleration and deceleration times by external signal	When an AC motor drive drives two or more motors, it can reach high-speed but still start and stop smoothly.	01.09~01.12 04.05~04.08

# Chapter 4 Parameters | VIII



# **Overheat Warning**

Applications	Purpose	Functions	Related Parameters
Air conditioner	Safety measure	When AC motor drive overheats, it uses a thermal sensor to have overheat warning.	03.00~03.01 04.05~04.08

#### Two-wire/three-wire

Applications	Purpose	Functions	Related Parameters
General application	To run, stop, forward and reverse by external terminals	MI1:("OPEN":STOP) ("CLOSE":REV)	02.00 02.01 02.09 04.04

#### **Operation Command**

Applications	Purpose	Functions	Related Parameters
General application	Selecting the source of control signal	Selection of AC motor drive control by external terminals, digital keypad or RS485.	02.01 04.05~04.08

# Frequency Hold

Applications	Purpose	Functions	Related Parameters
General application	Acceleration/ deceleration pause	Hold output frequency during Acceleration/deceleration	04.05~04.08



#### **Auto Restart after Fault**

Applications	Purpose	Functions	Related Parameters
Air conditioners, remote pumps	For continuous and reliable operation without operator intervention	The AC motor drive can be restarted/reset automatically up to 10 times after a fault occurs.	08.15~08.16

# **Emergency Stop by DC Brake**

Applications	Purpose	Functions	Related Parameters
High-speed rotors	Emergency stop without brake resistor	AC motor drive can use DC brake for emergency stop when quick stop is needed without brake resistor. When used often, take motor cooling into consideration.	08.00 08.02 08.03

#### **Over-torque Setting**

Applications	Purpose	Functions	Related Parameters
Pumps, fans and extruders	To protect machines and to have continuous/ reliable operation	The over-torque detection level can be set. Once OC stall, OV stall and over-torque occurs, the output frequency will be adjusted automatically. It is suitable for machines like fans and pumps that require continuous operation.	06.00~06.05

#### **Upper/Lower Limit Frequency**

Applications	Purpose	Functions	Related Parameters
Pump and fan	Control the motor speed within upper/lower limit	When user cannot provide upper/lower limit, gain or bias from external signal, it can be set individually in AC motor drive.	01.07 01.08

# **Skip Frequency Setting**

Applications	Purpose	Functions	Related Parameters
Pumps and fans	To prevent machine vibrations	The AC motor drive cannot run at constant speed in the skip frequency range. Three skip frequency ranges can be set.	08.09~08.14

# Chapter 4 Parameters | VIII



#### **Carrier Frequency Setting**

Applications	Purpose	Functions	Related Parameters	
General application	Low noise	The carrier frequency can be increased when required to reduce motor noise.	02.03	

#### Keep Running when Frequency Command is Lost

Applications	Purpose	Functions	Related Parameters
Air conditioners	For continuous operation	When the frequency command is lost by system malfunction, the AC motor drive can still run. Suitable for intelligent air conditioners.	02.06

# **Output Signal during Running**

Applications	Purpose	Functions	Related Parameters
General application	Provide a signal for running status	Signal available to stop braking (brake release) when the AC motor drive is running. (This signal will disappear when the AC motor drive is freerunning.)	03.00~03.01

#### **Output Signal in Zero Speed**

Applications	Purpose	Functions	Related Parameters	
General application	Provide a signal for running status	When the output frequency is lower than the min. output frequency, a signal is given for external system or control wiring.	03.00~03.01	

#### **Output Signal at Desired Frequency**

Applications	Purpose	Functions	Related Parameters
General application	Provide a signal for running status	When the output frequency is at the desired frequency (by frequency command), a signal is given for external system or control wiring (frequency attained).	03.00~03.01



# **Output Signal for Base Block**

Applications	Purpose	Functions	Related Parameters	
General application	Provide a signal for running status	When executing Base Block, a signal is given for external system or control wiring.	03.00~03.01	

# **Overheat Warning for Heat Sink**

Applications	Purpose	Functions	Related Parameters	
General application	For safety	When heat sink is overheated, it will send a signal for external system or control wiring.	03.00~03.01	

# **Multi-function Analog Output**

Applications	Purpose	Functions	Related Parameters	
General application	Display running status	The value of frequency, output current/voltage can be read by connecting a frequency meter or voltage/current meter.	03.06	



# 4.3 Description of Parameter Settings

Group 0: User Parameters

			,
00.00	Identity C	ode of the AC Motor Drive	
	Settings	Read Only	Factory setting: ##
00.01	Rated Cu	rrent Display of the AC Mo	otor Drive
	Settings	Read Only	Factory setting: #.#

- Pr. 00.00 displays the identity code of the AC motor drive. The capacity, rated current, rated voltage and the max, carrier frequency relate to the identity code. Users can use the following table to check how the rated current, rated voltage and max. carrier frequency of the AC motor drive correspond to the identity code.
- Ш Pr.00.01 displays the rated current of the AC motor drive. By reading this parameter the user can check if the AC motor drive is correct

115V Series				230V Series						
kW	0.2	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
HP	0.25	0.5	1.0	2.0	3.0	5.0	7.5	10	15	20
Pr.00.00	0	2	4	6	8	10	12	14	16	18
Rated Output Current (A)	1.6	2.5	4.2	7.5	11.0	17	25	33	45	65
Max. Carrier Frequency		15kHz								

 $\mathbf{m}$ 

460V Series											
kW	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22
HP	0.5	1.0	2.0	3.0	5.0	7.5	10	15	20	25	30
Pr.00.00	3	5	7	9	11	13	15	17	19	21	23
Rated Output Current (A)	1.5	2.5	4.2	5.5	8.5	13	18	24	32	38	45
Max. Carrier Frequency						15kHz					

#### 00.02 Parameter Reset

Factory Setting: 0

- Settings 0 Parameter can be read/written
  - 1 All parameters are read-only
  - 6 Clear PLC program (NOT for VFD\*E\*C models)
  - 9 All parameters are reset to factory settings (50Hz, 230V/400V or 220V/380V depends on Pr.00.12)
  - 10 All parameters are reset to factory settings (60Hz, 115V/220V/440V)

	This parameter allows the user to reset all parameters to the factory settings except the fault
	records (Pr.06.08 ~ Pr.06.12).
	50Hz: Pr.01.00 and Pr.01.01 are set to 50Hz and Pr.01.02 will be set by Pr.00.12.
	60Hz: Pr.01.00 and Pr.01.01 are set to 60Hz and Pr.01.02 is set to 115V, 230V or 460V.
Ш	When Pr.00.02=1, all parameters are read-only. To write all parameters, set Pr.00.02=0.
Ш	When Pr.00.02=6, it clears all PLC program. But this function is NOT for VFD*E*C models.
Ш	When the parameter settings are abnormal, all parameters can be reset to factory setting by
	setting Pr.00.02 to 9 or 10.
Ш	When Pr.00.02=9, all parameters are reset to factory setting for 50Hz users and voltage will be
	different by Pr.00.12 setting.
Ш	When Pr.00.02=10, all parameters are reset to factory setting for 60Hz users.



 $\Box$ 

When Pr.00.02=9 or 10, all parameter are reset to factory setting but it doesn't clear all PLC program. Only Pr.00.02=6 can clear all PLC program.

Related parameter: Pr.00.12 (50Hz Base Voltage Selection)

#### ✓ Start-up Display Selection 00.03 Factory Setting: 0 Settings 0 Display the frequency command value (Fxxx) 1 Display the actual output frequency (Hxxx) Display the output current in A supplied to the motor 2 (Axxx) 3 Display the content of user-defined unit (Uxxx) FWD/REV command 5 PLCx (PLC selections: PLC0/PLC1/PLC2) (NOT for VFD\*E\*C models)

be	This parameter	determines	the start-up	display pa	age after p	power is a	applied to	the drive.

For setting 5, PLC0: disable, PLC1: run PLC, PLC2: read/write PLC programs into AC motor drive.

Please refer to Pr.00.04 for multi-function display.

Related parameter: Pr.00.04 (Content of Multi-function Display)



#### 00.04

#### ✓ Content of Multi-function Display

				Factory Setting: 0
	Settings	0	Display the content of user-defined unit (Uxxx)	88 8
		1	Display the counter value which counts the number of pulses on TRG terminal (c)	c 20
		2	Display PLC D1043 value (C) (NOT for VFD*E*C models)	0.5
		3	Display the actual DC BUS voltage in VDC of the AC motor drive (u)	03 10
		4	Display the output voltage in VAC of terminals U/T1, V/T2, W/T3 to the motor (E) $$	8888
		5	Display PID analog feedback signal value in $\%$ (b)	b 0.0
		6	Display the power factor angle in $^{\circ}$ of terminals U/T1, V/T2, W/T3 to the motor (n)	n 9 0.0
		7	Display the output power in kW of terminals U, V and W to the motor (P) $$	P0.00
		8	Display the estimated value of torque in Nm as it relates to current (t) $$	£0.00
		9	Display the signal of AVI analog input terminal in V (I)	1 8.8
		10	Display the signal of ACI analog input terminal in mA or display the signal of AVI2 analog input terminal in V (i) $$	<i>E</i> 0.0
		11	Display the temperature of IGBT (h) in $^{\circ}\text{C}$	h 30.0
		12	Display AVI3/ACI2 level (I.)	t 0.0
		13	Display AVI4/ACI3 level (i.)	<i>E. 0.0</i>
		14	Display PG speed in RPM (G)	5 28
		15	Display motor number 00~03 (M)	88 8
١٨/	han DrOO	na :-	act to 02, the display is according to the cotting of Dr00 0	4

- When Pr00.03 is set to 03, the display is according to the setting of Pr00.04. Ш
- When Pr.00.04 is set to 0, please refer to Pr.00.05 for details.
- $\square$ Related parameter: Pr.00.05 (User Defined Coefficient K)





Please refer to Appendix B.8 KPE-LE02 for the 7-segment LED Display of the Digital Keypad.

00.05	✓ User Def	ined Coefficient K	Unit: 0. 1
	Settings	0. 1 to d 160.0	Factory Setting: 1.0

Ш The coefficient K determines the multiplying factor for the user-defined unit.

The display value is calculated as follows:

U (User-defined unit) = Actual output frequency \* K (Pr.00.05)

#### Example:

If user wants to use RPM to display the motor speed when 4-polse motor runs at 60Hz. The user can display the motor speed by setting Pr.00.04 to 0. The application is shown as follows. From the formula of motor speed, user-defined unit (U) (RPM) = 60X120/4=1800 (disregard slip). Therefore, User Defined Coefficient K is 30.0.



Formula of motor speed  $n = f \times \frac{120}{D}$ 

n: speed (RPM) (revolution per minute)

P: pole number of motor

f: operation frequency (Hz)

00.06	Power Boa	Power Board Software Version					
	Settings	Read Only					
	Display	#.##					
00.07	Control Boa	ard Software Version					
	Settings	Read Only					
	Display	#.##	_				
00.08	Password	Input	Unit: 1				
	Settings	0 to 9999	Factory Setting: 0				
	Display	0~2 (times of wrong password)					


Ш The function of this parameter is to input the password that is set in Pr.00.09. Input the correct password here to enable changing parameters. You are limited to a maximum of 3 attempts.

#### Chapter 4 Parameters | Value |

After 3 consecutive failed attempts, a blinking "codE" will show up to force the user to restart the AC motor drive in order to try again to input the correct password.

Related parameter: Pr.00.09 (Password Set)

Password Decode Flow Chart



00.09	Password Se	t		Unit: 1
	Settings	0 to 9999		Factory Setting: 0
	Display	0	No password set or successful input in Pr. 00.08	8
		1	Password has been set	

To set a password to protect your parameter settings.

If the display shows 0, no password is set or password has been correctly entered in Pr.00.08. All parameters can then be changed, including Pr.00.09.

The first time you can set a password directly. After successful setting of password the display will show 1

Be sure to record the password for later use.

To cancel the parameter lock, set the parameter to 0 after inputting correct password into Pr. 00.08.

The password consists of min. 1 digits and max. 4 digits.



Ш How to make the password valid again after decoding by Pr.00.08:

Method 1: Re-input original password into Pr.00.09 (Or you can enter a new password if you want to use a changed or new one).

Method 2: After rebooting, password function will be recovered.

Ш To lock parameters, you can set Pr.00.02 to 1 or Pr.04.05~04.08 to 17 to prevent changing of parameters settings by unqualified personnel. Please note that it is without password set.

#### 00.10 Control Method

Factory Setting: 0

Settinas 0 V/f Control

> Vector Control 1

- This parameter determines the control method of the AC motor drive.  $\Omega$
- Control of V/f (Voltage/frequency)
  - 1. To operate by the change of frequency and voltage without changing the mechanical characteristic of motor: it can run by open-loop method and also can use with PG card (refer to Appendix B) to run by close-loop method. In this control, it gets the change of the electromagnetic torque of rotor and the load torque from the change of slip ratio.
  - 2. The V/f control is the constant value control mode. Although it prevents the main questions of the decreasing frequency and increasing magnetic field, the magnetic field is decreasing with frequency. In such circumstance, insufficient motor torque will occur when the magnetic field weakens in the low frequency. At this moment, it can get the best operation with Pr.07.02 setting(Torque Compensation) to get the torque compensation.

common applications: pump, conveyor belt, compressor and treadmill

- Ш Vector control:
  - 1. To operate by the change of frequency and voltage without changing the mechanical characteristic of motor: it can run by open-loop method and also can use with PG card (refer to Appendix B) to run by close-loop method. In this mode, it is coordinate change. The physical essence is the relativity of motion. That means the change of rotor current only has relation with electromagnetic torque and the change of stator current only has relation with electromagnetic torque. This is the characteristic of vector control.
  - 2. The vector control can eliminate the relation between electromagnetic current vector and armature flux. Thus, it can control the current vector and armature flux independently to raise

# Chapter 4 Parameters | V

the transient response of the AC motor drive.

Applications: textile equipment, press equipment, life equipment and drilling machine.

Related parameter: Pr.07.02 (Torque Compensation (Motor 0))

00.11	Reserved			
00.12	50Hz Bas	e Volta	age Selection	
				Factory Setting: 0
	Settings	0	230V/400V	

This parameter determines the base voltage for 50Hz.


220V/380V

- When Pr.00.02 is set to 9, the base voltage for 50Hz will set by Pr.00.12.
- Related parameter: Pr.00.02 (Parameter Reset)

Group 1: Basic Parameters

01.00	Maximum	Output Frequency (Fmax)	Unit: 0.01
	Settings	50.00 to 600.0 Hz	Factory Setting: 60.00

- This parameter determines the AC motor drive's Maximum Output Frequency, All the AC motor drive frequency command sources (analog inputs 0 to +10V and 4 to 20mA) are scaled to correspond to the output frequency range.
- ш Please note that output frequency may be not in this setting range due to parameter setting:
  - 1. Pr.00.10 is set to 0; when enabling Pr.07.03 (Slip Compensation) in V/f mode, it may be not in this setting range.
  - 2. Pr.00.10 is set to 1: The AC motor drive will auto compensate slip in vector mode, so it also may be not within this setting range.
- Ш Related parameters: 00.10 (Control Method), 04.12(Min AVI Frequency), 04.14(Max AVI Frequency), 04.16(Min ACI Frequency), 04.18(Max ACI Frequency), 04.19(ACI/AVI2 Selection), 04.21(Min AVI2 Frequency), 04.23(Max AVI2 Frequency) and 07.03(Slip Compensation (Used without PG) (Motor 0))



01.01	Maximum Vo	oltage Frequency (Fbase) (Motor 0)	Unit: 0.01
	Settings	0.10 to 600.0Hz	Factory Setting: 60.00

 $\Box$ This value should be set according to the rated frequency of the motor as indicated on the motor nameplate. Maximum Voltage Frequency determines the v/f curve ratio. For example, if the drive is rated for 460 VAC output and the Maximum Voltage Frequency is set to 60Hz, the drive will maintain a constant ratio of 7.66 V/Hz (460V/60Hz=7.66V/Hz). This parameter value must be equal to or greater than the Mid-Point Frequency (Pr.01.03).

# Chapter 4 Parameters | VZZZZZZ

- If this parameter setting is less than the rated frequency of the motor, it may cause over current and damage the motor or trigger the over current protection.
- If this parameter setting is greater than the rated frequency of the motor, it may cause insufficient motor torque.
- Related parameters: Pr.01.02(Maximum Output Voltage (Vmax) (Motor 0)), Pr.01.03(Mid-Point Frequency (Fmid) (Motor 0)), Pr.01.04(Mid-Point Voltage (Vmid) (Motor 0)), Pr.01.05(Minimum Output Frequency (Fmin) (Motor 0)) and Pr.01.06(Minimum Output Voltage (Vmin) (Motor 0)).

01.02	Maximur	n Output Voltage (V	max) (Motor 0)	Unit: 0.1
	Settings	115V/230V series	0.1 to 255.0V	Factory Setting: 220.0
		460V series	0.1 to 510.0V	Factory Setting: 440.0

- This parameter determines the Maximum Output Voltage of the AC motor drive. The Maximum Output Voltage setting must be smaller than or equal to the rated voltage of the motor as indicated on the motor nameplate. This parameter value must be equal to or greater than the Mid-Point Voltage (Pr.01.04).
- If the output voltage of the AC motor drive is smaller than this setting, the output voltage can't reach this setting due to input voltage limit.
- If this setting is greater than the rated voltage of the motor, it may cause over current of the motor output to damage motor or trigger the over current protection.
- If this setting is smaller than the rated voltage of the motor, it may cause the insufficient motor torque.
- Related parameters: Pr.01.01(Maximum Voltage Frequency (Fbase) (Motor 0)), Pr.01.03(Mid-Point Frequency (Fmid) (Motor 0)), Pr.01.04(Mid-Point Voltage (Vmid) (Motor 0)), Pr.01.05(Minimum Output Frequency (Fmin) (Motor 0)) and Pr.01.06(Minimum Output Voltage (Vmin) (Motor 0)).

01.03	Mid-Point Frequency (Fmid) (Motor 0)	Unit: 0.01
	Settings 0.10 to 600.0Hz	Factory Setting: 1.50

This parameter sets the Mid-Point Frequency of the V/f curve. With this setting, the V/f ratio between Minimum Frequency and Mid-Point frequency can be determined. This parameter must be equal to or greater than Minimum Output Frequency (Pr.01.05) and equal to or less than Maximum Voltage Frequency (Pr.01.01).


	cause motor overheat and				
	damage motor or trigger the over current protection.				
Ш	Please note that unsuitable setting may cause insufficient motor torque.				
Ш	When it is vector control, the settings of Pr.01.03, Pr.01.04 and Pr.01.06 are invalid.				
Ш	This setting must be greater than Pr.01.05.				
Ш	Related parameters: Pr.01.01(Maximum Voltage Frequency (Fbase	e) (Motor 0)),			
	Pr.01.02(Maximum Output Voltage (Vmax) (Motor 0)), Pr,01.04(Mid	d-Point Voltage (Vmid)			
	(Motor 0)), Pr.01.05(Minimum Output Frequency (Fmin) (Motor 0))	and Pr.01.06(Minimum			
	Output Voltage (Vmin) (Motor 0)).				
01	Mid-Point Voltage (Vmid) (Motor 0)	Unit: 0.1			
	Settings 115V/230V series 0.1 to 255.0V	Factory Setting: 10.0			
	460V series 0.1 to 510.0V	Factory Setting: 20.0			
Ш	This parameter sets the Mid-Point Voltage of any V/f curve. With the	is setting, the V/f ratio			
	between Minimum Frequency and Mid-Point Frequency can be det	ermined.			
Ш	This parameter must be equal to or greater than Minimum Output V	/oltage (Pr.01.06).			
Ш	Related parameters: Pr.01.01(Maximum Voltage Frequency (Fbase	e) (Motor 0)),			
	Pr.01.02(Maximum Output Voltage (Vmax) (Motor 0)), Pr,01.03(Mid	d-Point Frequency (Fmid)			
	(Motor 0)), Pr.01.05(Minimum Output Frequency (Fmin) (Motor 0))	and Pr.01.06(Minimum			
	Output Voltage (Vmin) (Motor 0)).				
01	Minimum Output Frequency (Fmin) (Motor 0)	Unit: 0.01			
	Settings 0.10 to 600.0Hz	Factory Setting: 1.50			
Ш	This parameter sets the Minimum Output Frequency of the AC mot	or drive. If the frequency			
	command is greater than this setting, the AC motor drive will accele	erate to the frequency			
	command by the accel./decel. time. If the frequency command is le	ss than this setting, the AC			
	motor drive will be ready without output voltage.				
Ш	Please note that unsuitable setting may cause over current to dama	age motor or trigger the			
	over current protection.				
Ш	When Pr.08.04 is set to 1(Operation continues after momentary por	wer loss, speed search			
	starts with the Master Frequency reference value.), it won't operate	by V/f curve.			
Ш	Related parameters: Pr.01.01(Maximum Voltage Frequency (Fbase	e) (Motor 0)),			
	Pr.01.02(Maximum Output Voltage (Vmax) (Motor 0)), Pr,01.03(Mid	d-Point Frequency (Fmid)			

#### Chapter 4 Parameters | Value

(Motor 0)), Pr.01.04(Mid-Point Voltage (Vmid) (Motor 0)) and Pr.01.06(Minimum Output Voltage (Vmin) (Motor 0))

01.06	Minimum Output Voltage (Vmin) (Motor 0)		in) (Motor 0)	Unit: 0.1
	Settings	115V/230V series	0.1 to 255.0V	Factory Setting: 10.0
		460V series	0.1 to 510.0V	Factory Setting: 20.0

- This parameter sets the Minimum Output Voltage of the AC motor drive.
- If the setting is too large, it may cause over current to damage motor or trigger the over current protection.
- If the setting is too small, it may cause insufficient motor torque.
- The settings of Pr.01.01 to Pr.01.06 have to meet the condition of Pr.01.02  $\geq$  Pr.01.04  $\geq$  Pr.01.06 and Pr.01.01  $\geq$  Pr.01.03  $\geq$  Pr.01.05. By this condition, V/f curve is shown in the following figure.
- In vector control mode (Pr.00.10 is set to 1), Pr.01.03, Pr.01.04 and Pr.01.06 are disabled. But Pr.01.05 is still the minimum output frequency.
- The V/f curve of motor 0 to motor 3 can be selected by setting the multi-function input terminals MI3~MI6 (Pr.04.05 to Pr.04.08) to 27 and 28. To set the voltage and frequency for each motor, please refer to Pr.01.01~01.06 for motor 0 (factory setting), Pr.01.26~01.31 for motor 1. Pr.01.32~01.37 for motor 2 and Pr.01.38~01.43 for motor 3.
- Related parameters: Pr.01.01(Maximum Voltage Frequency (Fbase) (Motor 0)),
  Pr.01.02(Maximum Output Voltage (Vmax) (Motor 0)), Pr,01.03(Mid-Point Frequency (Fmid)
  (Motor 0)), Pr.01.04(Mid-Point Voltage (Vmid) (Motor 0)) and Pr.01.05 (Minimum Output Frequency (Fmin) (Motor 0)).





01	.07 Output Frequency Upper Limit	Unit: 0.1
	Settings 0.1 to 120.0%	Factory Setting: 110.0
	This parameter must be equal to or greater than the Output Frequer	ncy Lower Limit (Pr.01.08).
	The Maximum Output Frequency (Pr.01.00) is regarded as 100%.	
	Output Frequency Upper Limit value = (Pr.01.00 * Pr.01.07)/100.	
	The max. output frequency of the AC motor drive will be limited by the	nis setting. If the setting of
	frequency command is greater than Pr.01.07, the output frequency	will be equal to or less than
	Pr.01.07.	
	When enabling Pr.07.03 or Pr.10.00~10.13, the output frequency of	the AC motor drive may
	exceed the frequency command but it is still limited by this setting.	
	Related parameters: Pr.01.00(Maximum Output Frequency (Fmax))	and Pr.01.08(Output
	Frequency Lower Limit).	
01	Output Frequency Lower Limit	Unit: 0.1
	Settings 0.0 to 100.0%	Factory Setting: 0.0
Ш	The Output Frequency Lower Limit value = (Pr.01.00 * Pr.01.08) /10	00.
	This setting will limit the min. output frequency of the AC motor drive	e. When the frequency
	command of the AC motor drive or the frequency calculated by feed	back control is less than
	this setting, the output frequency of the AC motor drive will be limited	d by this setting.
	After starting running, the AC motor drive will accelerate from Pr.01.	05 (Minimum Output
	Frequency (Fmin) (Motor 0)) to the setting frequency by V/f curve ar	nd won't be limited by this
	setting.	
	The Upper/Lower Limits are to prevent operation errors and machin-	e damage.
	If the Output Frequency Upper Limit is 50Hz and the Maximum Outp	out Frequency is 60Hz, the
	Output Frequency will be limited to 50Hz.	
	If the Output Frequency Lower Limit is 10Hz, and the Minimum Outp	out Frequency (Pr.01.05) is
	set to 1.0Hz, then any Command Frequency between 1.0-10Hz will	generate a 10Hz output
	from the drive. If the command frequency is less than 1.0Hz, drive w	vill be in ready status
	without output.	
	This parameter must be equal to or less than the Output Frequency	Upper Limit (Pr.01.07).

# Output frequency 01.07 Output frequency 01.08

Output frequency

lower limit

	01.09		ation Time 1 (Taccel 1)	Unit: 0.1/0.01
ĺ	01.10	✓ Deceleration	ation Time 1 (Tdecel 1)	Unit: 0.1/0.01
	01.11		ation Time 2 (Taccel 2)	Unit: 0.1/0.01
	01.12			Unit: 0.1/0.01
		Settings	0.1 to 600.0 sec / 0.01 to 600.0 sec	Factory Setting: 10.0


- Acceleration/deceleration time 1 or 2 can be switched by setting the external terminals MI3~ MI12(MI7~MI12 are optional) to 7 (set Pr.04.05~Pr.04.08 to 7 or Pr.11.06~Pr.11.11 to 7). The factory settings are acceleration time 1.
- The Acceleration Time is used to determine the time required for the AC motor drive to ramp from 0 Hz to Maximum Output Frequency (Pr.01.00). The Deceleration Time is used to determine the time required for the AC motor drive to decelerate from the Maximum Output Frequency (Pr.01.00) down to 0 Hz.
- If the setting of the acceleration/deceleration time is too short, it may trigger the protection (Pr.06.01(Over-Current Stall Prevention during Accel) or Pr.06.00(Over-Voltage Stall Prevention)) and make the actual acceleration/deceleration time be larger than this setting.
- If the setting of the acceleration time is too short, it may cause over-current during acceleration and damage the motor or trigger the protection function.
- If the setting of the deceleration time is too short, it may cause over-current during deceleration or over voltage of the AC motor drive and damage the motor or trigger the protection function.
- It can use suitable brake resistor to decelerate the AC motor drive in short time and prevent internal over voltage. Refer to Appendix B for brake resistor.
- When enabling Pr.01.17(Acceleration S-Curve) and Pr.01.18(Deceleration S-Curve), the actual acceleration/deceleration time will be longer than the setting.

Frequency

command



Ш Related parameters: Pr.01.16(Auto acceleration / deceleration (refer to Accel/Decel time setting)), Pr.01.17(Acceleration S-Curve), Pr.01.18(Deceleration S-Curve), Pr.04.05(Multifunction Input Terminal (MI3)), Pr.04.06(Multi-function Input Terminal (MI4)), Pr.04.07(Multifunction Input Terminal (MI5)) and Pr.04.08(Multi-function Input Terminal (MI6))




#### 01.19 Accel/Decel Time Unit

Factory Setting: 0

Settings	0	Unit: 0.1 sec
	1	Unit: 0.01 sec

- ш The Acceleration/Deceleration Time 1, 2, 3, 4 are selected according to the Multi-function Input Terminals Settings. See Pr.04.05 to Pr.04.08 for more details.
- Ш In the diagram shown below, the Acceleration/Deceleration Time of the AC motor drive is the time between 0 Hz to Maximum Output Frequency (Pr.01.00). Suppose the Maximum Output Frequency is 60 Hz. Minimum Output Frequency (Pr.01.05) is 1.0 Hz. and Acceleration/Deceleration Time is 10 seconds. The actual time for the AC motor drive to accelerate from start-up to 60 Hz and to decelerate from 60Hz to 1.0Hz is in this case 9.83 seconds. ((60-1) \* 10/60=9.83secs).




01.13	✓ Jog Acce	eleration Time	Unit: 0.1/0.01
	Settings	0.1 to 600.0/0.01 to 600.0 sec	Factory Setting: 1.0
01.14	✓ Jog Deceleration Time		Unit: 0.1/0.01
	Settings	0.1 to 600.0/0.01 to 600.0 sec	Factory Setting: 1.0
01.15			Unit: 0.01
	Settings	0.10 to Fmax (Pr.01.00)Hz	Factory Setting: 6.00

- Only external terminal JOG (MI3 to MI12) can be used. Please set one of MI3~MI12 (MI7~MI12 are optional) to 8 for JOG operation. When the Jog command is "ON", the AC motor drive will accelerate from Minimum Output Frequency (Pr.01.05) to Jog Frequency (Pr.01.15). When the Jog command is "OFF", the AC motor drive will decelerate from Jog Frequency to zero.
- The used Accel/Decel time is set by the Jog Accel/Decel time (Pr.01.13, Pr.01.14).
- Before using the JOG command, the drive must be stopped first. And during Jog operation, other operation commands are not accepted, except commands via the FORWARD, REVERSE and STOP keys on the digital keypad.







The definition of JOG Accel./Decel. Time

#### 01.16 ∧ Auto-Acceleration / Deceleration

Factory Setting: 0

- Settinas O Linear acceleration / deceleration
  - 1 Auto acceleration, linear Deceleration,
  - 2 Linear acceleration, auto Deceleration.
  - 3 Auto acceleration / deceleration (set by load)
  - Auto acceleration / deceleration (set by Accel/Decel Time setting)
- $\Box$ Linear acceleration/deceleration: the acceleration/deceleration that acts according to the acceleration/deceleration time set by Pr.01.09~01.12.
- With Auto acceleration / deceleration it is possible to reduce vibration and shocks during starting/stopping the load.
- Ш When Pr.01.16 is set to 3 Auto acceleration / deceleration (set by load): During Auto acceleration the torque is automatically measured and the drive will accelerate to the set frequency with the fastest acceleration time and the smoothest starting current. During Auto deceleration, regenerative energy is measured and the motor is smoothly stopped
- When this parameter is set to 04 Auto acceleration / deceleration (set by Accel/Decel Time setting): the actual accel/decel time will be equal to or more than parameter Pr.01.09 ~Pr 01 12

with the fastest deceleration time

### Chapter 4 Parameters | Value

- Auto acceleration/deceleration makes the complicated processes of tuning unnecessary. It makes operation efficient and saves energy by acceleration without stall and deceleration without brake resistor.
- In applications with brake resistor or brake unit, the deceleration time is the shortest. It is NOT recommended to use Auto deceleration function, or it will extend the deceleration time.
- Related parameters: Pr.01.09(Accel Time 1), Pr.01.10(Decel Time 1), Pr.01.11(Accel Time 2) and Pr.01.12(Decel Time 2).

<b>01.17</b> Acce	leration S-Curve	Unit: 0.1/0.01
<b>01.18</b> Dece	leration S-Curve	Unit: 0.1/0.01
		Factory Setting: 0
Settir	ngs 0.0	S-curve disabled

This parameter is used to ensure smooth acceleration and deceleration via S-curve.

The S-curve is disabled when set to 0.0 and enabled when set to 0.1 to 10.0/0.01 to 10.00.

Setting 0.1/0.01 gives the quickest and setting 10.0/10.00 the longest and smoothest S-curve.


The AC motor drive will not follow the Accel/Decel Times in Pr.01.09 to Pr.01.12.

The diagram below shows that the original setting of the Accel/Decel Time is only for reference when the S-curve is enabled. The actual Accel/Decel Time depends on the selected S-curve (0.1 to 10.0).

The total Accel. Time=Pr.01.09 + Pr.01.17 or Pr.01.11 + Pr.01.17

0.1 to 10.0/0.01 to 10.00

The total Decel. Time=Pr.01.10 + Pr.01.18 or Pr.01.12 + Pr.01.18




Acceleration/deceleration Characteristics

Related parameters: Pr.01.09(Accel Time 1), Pr.01.10(Decel Time 1), Pr.01.11(Accel Time 2) and Pr.01.12(Decel Time 2).

S-curve enabled (10.0/10.00 is the smoothest)

		Chapter 4 Parameters
01.20	Delay Time at 0Hz for Simple Position	Unit: 0.01
01.21	Delay Time at 10Hz for Simple Position	Unit: 0.01
01.22	Delay Time at 20Hz for Simple Position	Unit: 0.01
01.23	Delay Time at 30Hz for Simple Position	Unit: 0.01
01.24	Delay Time at 40Hz for Simple Position	Unit: 0.01
01.25	Delay Time at 50Hz for Simple Position	Unit: 0.01
	Settings 0.00 to 600.00 sec	Factory Setting: 0.00

- This simple position function is calculated by the measure of operation distance. When the multi-function input terminal is set to 25 and it is ON, it will start to decelerate after getting the delay time from Pr.01.20 to Pr.01.25 and get the final position.
- This is simple position function NOT the precision position function.



$$S = n \times \left(\frac{t_x + (t_x + t_2)}{2}\right)$$

$$n = f \times \frac{120}{p}$$

- S: operation distance
- n: rotation speed(revolution/second)
- tx: delay time (sec)
- t2: deceleration time(sec)

- n: rotation speed(revolution/second)
- P: pole number of motor
- f: operation frequency

Assume that the radius of the 4-pole motor is r and rotation speed is n (rpm).




### Example 1:

Assume that motor speed is 50Hz, the delay time at 50Hz is 2 sec (Pr.01.25=2) and the deceleration time from 50Hz to 0Hz is 10 seconds.

The rotation speed  $n = 120 \times 50 / 4 \text{ (rpm/min)} = 25 \text{ rpm/sec}$ 

The revolution numbers = (25 X (2+12))/2 = 175 (revolutions)





Therefore, the distance = revolution numbers X circumference = 175 X  $2\pi$  r It also means that the motor will stop to the original position after 175 circles.


#### $\Box$ Example 2:

Assume that motor speed is 1.5Hz, the delay time at 10Hz is 10 sec (Pr.01.21=10) and the deceleration time from 60Hz to 0Hz is 40 seconds.

The delay time at 1.5Hz is 1.5 sec and the deceleration from 1.5Hz to 0Hz is 1 sec.

The rotation speed  $n = 120 \times 1.5 / 4 (rpm/min) = 1.5/2 rpm/sec = 0.75 rpm/sec$ 

The revolution numbers = (1.5/2X (1.5+2.5))/2 = 1.5 (revolutions)



Therefore, the distance = revolution numbers X circumference = 1.5 X  $2\pi$  r It also means that the motor will stop after running 1.5 circles.

01.26	Maximun	n Voltage Frequenc	y (Fbase) (Motor 1)	Unit: 0.01
	Settings	0.10 to 60	00.0Hz	Factory Setting: 60.00
01.27	Maximun	n Output Voltage (V	max) (Motor 1)	Unit: 0.1
	Settings	115V/230V series	0.1 to 255.0V	Factory Setting: 220.0
		460V series	0.1 to 510.0V	Factory Setting: 440.0
01.28	Mid-Poin	t Frequency (Fmid)	(Motor 1)	Unit: 0.01
	Settings	0.10 to 600.0Hz		Factory Setting: 1.50
01.29	Mid-Poin	t Voltage (Vmid) (M	otor 1)	Unit: 0.1
	Settings	115V/230V series	0.1 to 255.0V	Factory Setting: 10.0
		460V series	0.1 to 510.0V	Factory Setting: 20.0

	Chapter 4 Parameters
01.30 Minimum Output Frequency (Fmin) (Motor 1)	Unit: 0.01
Settings 0.10 to 600.0Hz	Factory Setting: 1.50
01.31 Minimum Output Voltage (Vmin) (Motor 1)	Unit: 0.1
Settings 115V/230V series 0.1 to 255.0V	Factory Setting: 10.0
460V series 0.1 to 510.0V	Factory Setting: 20.0
<b>01.32</b> Maximum Voltage Frequency (Fbase) (Motor 2)	Unit: 0.01
Settings 0.10 to 600.0Hz	Factory Setting: 60.00
01.33 Maximum Output Voltage (Vmax) (Motor 2)	Unit: 0.1
Settings 115V/230V series 0.1 to 255.0V	Factory Setting: 220.0
460V series 0.1 to 510.0V	Factory Setting: 440.0
01.34 Mid-Point Frequency (Fmid) (Motor 2)	Unit: 0.01
Settings 0.10 to 600.0Hz	Factory Setting: 1.50
01.35 Mid-Point Voltage (Vmid) (Motor 2)	Unit: 0.1
Settings 115V/230V series 0.1 to 255.0V	Factory Setting: 10.0
460V series 0.1 to 510.0V	Factory Setting: 20.0
01.36 Minimum Output Frequency (Fmin) (Motor 2)	Unit: 0.01
Settings 0.10 to 600.0Hz	Factory Setting: 1.50
01.37 Minimum Output Voltage (Vmin) (Motor 2)	Unit: 0.1
Settings 115V/230V series 0.1 to 255.0V	Factory Setting: 10.0
460V series 0.1 to 510.0V	Factory Setting: 20.0
01.38 Maximum Voltage Frequency (Fbase) (Motor 3)	Unit: 0.01
Settings	Factory Setting: 60.00
01.39 Maximum Output Voltage (Vmax) (Motor 3)	Unit: 0.1
Settings 115V/230V series 0.1 to 255.0V	Factory Setting: 220.0
460V series 0.1 to 510.0V	Factory Setting: 440.0
01.40 Mid-Point Frequency (Fmid) (Motor 3)	Unit: 0.01
Settings 0.10 to 600.0Hz	Factory Setting: 1.50
01.41 Mid-Point Voltage (Vmid) (Motor 3)	Unit: 0.1
Settings 115V/230V series 0.1 to 255.0V	Factory Setting: 10.0
460V series 0.1 to 510.0V	Factory Setting: 20.0
01.42 Minimum Output Frequency (Fmin) (Motor 3)	Unit: 0.01
Settings 0.10 to 600.0Hz	Factory Setting: 1.50
01.43 Minimum Output Voltage (Vmin) (Motor 3)	Unit: 0.1
Settings 115V/230V series 0.1 to 255.0V	Factory Setting: 10.0
460V series 0.1 to 510.0V	Factory Setting: 20.0
· · · · · · · · · · · · · · · · · · ·	

# Chapter 4 Parameters | Variation

- The V/f curve of motor 0 to motor 3 can be selected by setting the multi-function input terminals MI3~MI6 (Pr.04.05 to Pr.04.08) to 27 and 28. To set the voltage and frequency for each motor, please refer to Pr.01.01~01.06 for motor 0 (factory setting), Pr.01.26~01.31 for motor 1, Pr.01.32~01.37 for motor 2 and Pr.01.38~01.43 for motor 3.
- Related parameters: Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi-function Input Terminal (MI4)), Pr.04.07(Multi-function Input Terminal (MI5)) and Pr.04.08(Multi-function Input Terminal (MI6))



Group 2: Operation Method Parameters

02.00	✓ Source of First Master Frequency Command				
			Factory Setting: 1		
02.09	<b>02.09</b> ✓ Source of Second Master Frequency Command				
			Factory Setting: 0		
	Settings	0	Digital keypad UP/DOWN keys or Multi-function Inputs UP/DOWN. Last used frequency saved. (Digital keypad is optional)		
		1	0 to +10V from AVI		
		2	4 to 20mA from ACI or 0 to +10V from AVI2		
		3	RS-485 (RJ-45)/USB communication		
		4	Digital keypad potentiometer		
		5	CANopen communication		

- ш These parameters set the Master Frequency Command Source of the AC motor drive.
- Ш The factory setting for master frequency command is 1. (digital keypad is optional, please refer to Appendix B for details.)
- Ш Setting 2: use the ACI/AVI switch on the AC motor drive to select ACI or AVI2. When setting to AVI, AVI2 is indicated. Please note the ACI/AVI switch on the AC motor drive. Switch to ACI for 4 to 20mA analog current signal (ACI) (Pr.04.19 should be set to 0) and AVI for analog voltage signal (AVI2) (Pr.04.19 should be set to 1).
- When the 3<sup>rd</sup> switch on the upper-right corner is set to be ON as shown in the following Ш diagram, the source of first master frequency command (Pr.02.00) will force setting to 2. This setting(Pr.02.00) can't be changed till the 3<sup>rd</sup> switch is set to be OFF.



- Ш When the AC motor drive is controlled by external terminal, please refer to Pr.02.05 for details.
- Ш PR.02.09 is only valid when one of Pr.04.05~04.08 is set to 22. When setting 22 is activated, the source of the frequency command is the setting of Pr.02.09. The factory setting of the source of frequency command is the first frequency command. Only one of the source of first master frequency command and second master frequency command can be enable at one time
- Ш Related parameters: Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi-function Input Terminal (MI4)), Pr.04.07(Multi-function Input Terminal (MI5)), Pr.04.08(Multi-function Input Terminal (MI6)) and Pr.04.19 (ACI/AVI2 Selection)



	_			
02.01	✓ Source of First Operation Command			
			Factory Setting: 1	
	Settings	0	Digital keypad (Digital keypad is optional)	
		1	External terminals. Keypad STOP/RESET enabled.	
		2	External terminals. Keypad STOP/RESET disabled.	
		3	RS-485 (RJ-45)/USB communication. Keypad STOP/RESET enabled.	
		4	RS-485 (RJ-45)/USB communication. Keypad STOP/RESET disabled.	
		5	CANopen communication. Keypad STOP/RESET disabled.	

- $\Box$ The factory setting for source of first operation command is 1. (digital keypad is optional.)
- $\Box$ When the AC motor drive is controlled by external terminal, please refer to Pr.02.05/Pr.04.04 for details

#### 02.10 Command Factory Setting: 0 Settinas 0 First Master Frequency Command Only 1 First Master Frequency + Second Master Frequency First Master Frequency - Second Master Frequency

- $\Box$ It can be used to add or subtract the first frequency set in Pr.02.00 and the second frequency set in Pr.02.09 to meet the customers' application. For example, if the master frequency is the first frequency, speed source, controlled by ACI (DC 4~20mA) and the second frequency, press source, is controlled by AVI(DC 0~+10V). These two frequencies can be added or subtracted by Pr.02.10.
- $\square$ Related parameters: Pr.02.00(Source of First Master Frequency Command) and Pr.02.09(Source of Second Frequency Command).

02.02	Stop Metho	od		
				Factory Setting: 0
	Settings	0	STOP: ramp to stop	E.F.: coast to stop
		1	STOP: coast to stop	E.F.: coast to stop
		2	STOP: ramp to stop	E.F.: ramp to stop
		3	STOP: coast to stop	E.F.: ramp to stop



Ш When the 2<sup>nd</sup> switch on the upper-right corner is set to be ON as shown in the following diagram, the motor stop method (Pr.02.02) will force setting to 1. This setting (Pr.02.02) can't be changed till the 2nd switch is set to be OFF.



Ш E.F. is external fault. It can be triggered by setting one of Pr.04.05~04.08 to 14. When the AC motor drive receives the trigger, it will stop output immediately and display EF on the keypad. The motor won't run till the fault is cleared (enter "RESET).

Ш The parameter determines how the motor is stopped when the AC motor drive receives a valid stop command or detects External Fault.

Ramp: the AC motor drive decelerates to Minimum Output Frequency (Pr.01.05)

according to the deceleration time(Pr.01.10 and Pr.01.12) and then stops.

Coast: the AC motor drive stops the output instantly upon command, and the motor


free runs until it comes to a complete standstill.


The motor stop method is usually determined by the characteristics of the motor load and how frequently it is stopped.

- It is recommended to use "ramp to stop" for safety of personnel or to prevent (1) material from being wasted in applications where the motor has to stop after the drive is stopped. The deceleration time has to be set accordingly.
- (2) If motor free running is allowed or the load inertia is large, it is recommended to select "coast to stop". For example: blowers, punching machines, centrifuges and pumps.
- Ш Related parameters: Pr.01.10(Decel Time 1), Pr.01.12(Decel Time 2), Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi-function Input Terminal (MI4)), Pr. 04.07(Multi-function Input Terminal (MI5)) and Pr.04.08(Multi-function Input Terminal (MI6))



The digital keypad is optional. Please refer to Appendix B for details. When using without this optional keypad, the FAULT LED will be ON once there is error messages or warning messages from the external terminals.





02.03	PWM Carrier Frequency Selections	Unit: 1
-------	----------------------------------	---------

115V/230V/460V Series		
Power	0.25 to 15hp (0.2kW to 11kW)	
Setting Range	1 to 15 kHz	
Factory Setting	8 kHz	

This parameter determines the PWM carrier frequency of the AC motor drive.

			Cha	pter 4 Parameters	VED-E
Carrier Frequency	Acoustic Noise	Electromagnetic Noise or leakage current	Heat Dissipation	Current Wave	
1kHz	Significant	Minimal <b>↑</b>	Minimal †	-VVV ∱ Minimal	
8kHz					
15kHz	<b>↓</b> Minimal	<b>↓</b> Significant	↓ Significant		t

- From the table, we see that the PWM carrier frequency has a significant influence on the electromagnetic noise, AC motor drive heat dissipation, and motor acoustic noise.
- The PWM carrier frequency will be decreased automatically by heat sink temperature and output current of the AC motor drive. It is used as a necessary precaution to prevent the AC motor drive from overheating and thus extends IGBT's life. If the user wants to fix carrier within the rated range and won't change by the change of the surrounding temperature and frequently load. Please refer to Pr.02.18 for Selection of Carrier Modulation.
- Related parameters: Pr.02.18(Selection of Carrier Modulation) and Pr.03.08(Fan Control).

## 02.04 Motor Direction Control

0-44:---

Factory Setting: 0

Settings	U	Forward/Reverse operation enabled
	1	Reverse operation disabled
	2	Forward operation disabled

- This parameter is used to disable one direction of rotation of the AC motor drive direction of rotation to prevent damage due to operation errors.
- The motor direction also can be limited by setting one of Pr.04.05~04.08 to 21.
- Related parameters: Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi-function Input Terminal (MI4)), Pr. 04.07(Multi-function Input Terminal (MI5)) and Pr.04.08(Multi-function Input Terminal (MI6))

#### 02.05 Line Start Lockout

Factory Setting: 1

### Settings


- Disable. Operation status is not changed even if operation command source Pr.02.01 is changed.
- 1 Enable. Operation status is not changed even if operation command source Pr.02.01 is changed.
- Disable. Operation status will change if operation command source Pr.02.01 is changed.
- 3 Enable. Operation status will change if operation command source Pr.02.01 is changed.

# Chapter 4 Parameters | Variation

This parameter determines the response of the drive upon power on and operation command source is changed.

Pr.02.05	Start lockout (Run when power is ON)	Operation status when operation command source is changed
0	Disable (AC motor drive will run)	Keep previous status
1	Enable (AC motor drive doesn't run)	Keep previous status
2	Disable (AC motor drive will run)	Change according to the new operation command source
3	Enable (AC motor drive doesn't run)	Change according to the new operation command source

- When the operation command source is from external terminal and operation command is ON (NPN mode: MI1/MI2-DCM=closed, PNP mode: MI1/MI2+24V=closed, please refer to chapter 2 wiring for details), the AC motor drive will operate according to Pr.02.05 after power is applied. <For terminals MI1 and MI2 only>
  - 1. When Pr.02.05 is set to 0 or 2, AC motor drive will run immediately.
  - When Pr.02.05 is set to 1 or 3, AC motor drive will remain stopped until operation command is received after previous operation command is cancelled.






- When the operation command source isn't from the external terminals, independently from whether the AC motor drive runs or stops, the AC motor drive will operate according to Pr.02.05 if the two conditions below are both met.
  - 1 When operation command source is changed to external terminal (Pr.02.01=1 or 2)
  - 2 The status of terminal and AC motor drive is different

And the operation of the AC motor drive will be:

- When setting 0 or 1, the status of AC motor drive is not changed by the terminal status.
- 2 When setting 2 or 3, the status of AC motor drive is changed by the terminal status.



- Ш When Pr.02.05 is set to 1 or 3, it does not guarantee that the motor will never run under this condition. It is possible the motor may be set in motion by a malfunctioning switch.
- Related parameters: Pr.02.01(Source of First Operation Command)

02.06	Loss of ACI Signal (4-20mA)			
			Factory Setting: 0	
	Settings	0	Decelerate to 0Hz	
		1	Coast to stop and display "AErr"	
		2	Continue operation by the last frequency command	


- $\Omega$ This parameter determines the behavior when ACI is lost.
- $\Box$ When setting to 1, it will display warning message "AErr" on the keypad(optional) in case of loss of ACI signal and execute the setting. The AC motor drive will stop outputting immediately, the motor will free run to stop. Please press "RESET" key to clear it.

# Chapter 4 Parameters | Variation

- When setting 0 or 2, it will display warning message "AErr" on the keypad(optional) in case of loss of ACI signal and execute the setting. If it is set to 0, the motor will decelerate to 0Hz by the setting of deceleration time (Pr.01.10/Pr.01.12). If it is set to 2, the motor will continue to run. For these two settings, the warning message will stop blinking when ACI signal is recovered. Please press "RESET" key to clear it.
- Related parameters: Pr.01.10(Decel Time 1) and Pr.01.12(Decel Time 2)


02.07	Up/Down I	Mode	
			Factory Setting: 0
	Settings	0	By digital keypad up/down keys mode
		1	Based on Accel/Decel Time acc. to Pr.01.09 to 01.12
		2	Constant speed (acc. to Pr. 02.08)
		3	Pulse input unit (acc. to Pr. 02.08)

- This parameter determines the increase/decrease of the master frequency when operated via the Multi-function Inputs when Pr.04.05~Pr.04.08 are set to 10 (Up command) or 11 (Down command).
- When Pr.02.07 is set to 0, it uses the external terminals UP/DOWN key to increase/decrease the frequency (F) as shown at the right of the following figure. Its function is the same as the UP/DOWN key on the digital keypad. In this mode, it also can use UP/DOWN key on the keypad to control.




When Pr.02.07 is set to 1: increase/decrease the frequency by acceleration/deceleration settings(Pr.01.09~01.12). It is valid only when the AC motor drive is running.

When Pr.02.07 is set to 2: use multi-function input terminal ON/OFF to increase/decrease the frequency by Pr.02.08.



When Pr.02.07 is set to 3: increase/decrease the frequency by Pr.02.08 (unit: pulse input).

Every ON after OFF is regarded as a input pulse.



Related parameters: Pr.02.08(Accel/Decel Rate of Change of UP/DOWN Operation with Constant Speed), Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi-function Input Terminal (MI5)), Pr.04.08(Multi-function Input Terminal (MI6))

02.08	Accel/Dece Constant S	el Rate of Change of UP/DOWN Operation with Speed	Unit: 0.01
·-	Settings	0.01~10.00 Hz/2ms	Factory Setting: 0.01

# Chapter 4 Parameters | Variation

This parameter determinates the constant speed When Pr.02.08 is set to 2 or 3.

_		
02	// // // // // // // // // // // // //	Unit: 0.01
	Settings 0.00 to 600.0Hz	Factory Setting: 60.00
	This parameter can be used to set frequency command or read keypa	ad frequency command.
Ш	Related parameters: Pr.02.12 (Communication Frequency Command	)
02	<b>★</b> Communication Frequency Command	Unit: 0.01
	Settings 0.00 to 600.0Hz	Factory Setting: 60.00
	This parameter can be used to set frequency command or read comm	nunication frequency
	command.	
	It can use this parameter for remote control via communication.	
02	The Selections for Saving Keypad or Communication Frequency Command	
		Factory Setting: 0
	Settings 0 Save Keypad & Communication Frequency	
	1 Save Keypad Frequency only	
	2 Save Communication Frequency only (Not for	VFD*E*C model)
	This parameter is used to save keypad or RS-485 frequency commar	ıd.
	Setting 0: After the AC motor drive is power off, save keypad and con	nmunication frequency in
	the AC motor drive.	
	Setting 1: After the AC motor drive is power off, only save keypad free	quency in the AC motor
	drive and won't save communication frequency.	
	Setting 2: After the AC motor drive is power off, only save communication	ation frequency in the AC
	motor drive and won't save keypad frequency.	
	The keypad or communication frequency only can be saved when Pr.	02.00/Pr.02.09=0 (the
	source of frequency is from keypad) or Pr.02.00/Pr.02.09=3(the source	e of frequency is from
	communication).	
	Related parameters: Pr.02.00(Source of First Master Frequency Com	mand) and
	Pr.02.09(Source of Second Frequency Command).	



#### 02.14 Initial Frequency Selection (for keypad & RS485/USB)

Factory Setting: 0

Factory display: 1

Settings By Current Freq Command 0

> 1 By Zero Freq Command

2 By Frequency Display at Stop

02.15	Initial Freque	ency Setpoint (for keypad & RS485/USB)	Unit: 0.01
	Settings	0.00 ~ 600.0Hz	Factory Setting: 60.00

 $\Box$ These parameters are used to determinate the frequency at stop:

When setting Pr.02.14 to 0: the initial frequency will be current frequency.

When setting Pr.02.14 to 1: the initial frequency will be 0.

When setting Pr.02.14 to 2: the initial frequency will be Pr.02.15.

#### 02.16 Display the Master Freq Command Source

Settinas Read Only

Ш You can read the master frequency command source by this parameter.

Display Value Bit		Function
1	1 Bit0=1 Master Freq Command Source by First Freq Source (Pr.02.00).	
2	Bit1=1	Master Freq Command Source by Second Freq Source (Pr.02.09).
4 Bit2=1		Master Freq Command Source by Multi-input function
8 Bit3=1		Master Freq Command Source by PLC Freq command (NOT for VFD*E*C models)

- $\square$ When it displays 4, it means that the master frequency command source is from multi-input function. Thus, when Pr.04.05~04.08 are set to 1(Multi-Step speed command 1), 2(Multi-Step speed command 2), 3(Multi-Step speed command 3), 4(Multi-Step speed command 4), 8(Joq Operation), 10(Up: Increment master frequency) and 11(Down: Decrement master frequency), it displays 4 in Pr.02.16.
- Ш Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi-function Input Terminal (MI4)), Pr.04.07(Multi-function Input Terminal (MI5)), Pr.04.08(Multi-function Input Terminal (MI6))



#### 02.17 Display the Operation Command Source

Settings Read Only Factory display: 4

You can read the operation source by this parameter.

Display Value	play Value Bit Function	
1 Bit0=1 Operation Command Source by Digital Keypad		Operation Command Source by Digital Keypad
2	Bit1=1	Operation Command Source by RS485 communication
4 Bit2=1 Operation Command Source by External Terminal		Operation Command Source by External Terminal
8 Bit3=1 Operation Command Source by Multi-input function		Operation Command Source by Multi-input function
16 Bit4=1 (NOT for VFD*E*C m		Operation Command Source by PLC Operation Command (NOT for VFD*E*C models)
		Operation Command Source by CANopen Communication Interface

- m When it displays 8, it means that the operation command source is from multi-input function. Thus, when Pr.04.05~04.08 are set to 8(Jog Operation), 18(Operation command selection (external terminals)), 19(Operation command selection(keypad)), 20(Operation command selection (communication)) and 21(FWD/REV command), it will display 8 in Pr.02.17.
- Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi-function Input Terminal (MI4)), Pr.04.07(Multi-function Input Terminal (MI5)), Pr.04.08(Multi-function Input Terminal (MI6))

#### Selection for Carrier Modulation 02.18


Factory Setting: 0

- Settings 0 By carrier modulation of load current and temperature
  - 1 By carrier modulation of load current
- $\Box$ Setting 0: The PWM carrier frequency (Fc) will be decreased automatically by heat sink temperature and output current of the AC motor drive. Please refer to the following figure for the decreasing the PWM carrier frequency. It is used as a necessary precaution to prevent the AC motor drive from overheating and thus extends IGBT's life. Example for 460V models: Assume the carrier frequency to be 15kHz, the ambient temperature is 35 degrees C with a single AC motor drive(mounting method A). If the output current exceeds 80% \* rated current,





the AC motor drive will decrease the carrier frequency automatically according to the following figure. If output current is 100% \* rated current, the carrier frequency will decrease from 15kHz to 12kHz.

## Mounting method



#### $\Box$ The relation between rated current and carrier frequency






For 460V Series

Setting 1: to prevent the AC motor drive from overheating and thus extends IGBT's life and also prevent carrier change and motor noise due to surrounding temperature and frequently load change, it needs to use this setting. Please refer to the following figure for the selection of carrier frequency and rated current. For example, when carrier frequency should be kept in 15Hz, the rated current of the AC motor drive must be 65%. That means the rated current for over load is 150% \* 65% =97.5%. Thus, the rated current should be within the range of the following figure to keep the carrier frequency at a fix frequency.

Related parameter: Pr.02.03 (PWM Carrier Frequency Selections)





# **Group 3: Output Function Parameters**

03.00	Multi-function Output Relay (RA1, RB1, RC1)	
		Factory Setting: 8
03.01	Multi-function Output Terminal MO1	
		Factory Setting: 1

Settings	Function	Description
0	No Function	
1	AC Drive Operational	Active when the drive is ready or RUN command is "ON".
2	Master Frequency (F) Attained	Active when the output frequency(H) of AC motor drive reaches the output frequency(F) setting.
3	Zero Speed	Active when Command Frequency is lower than the Minimum Output Frequency.
4	Over-Torque Detection(OL2)	Active as long as over-torque is detected. (Refer to Pr.06.03 ~ Pr.06.05)
5	Baseblock (B.B.) Indication	Active when the output of the AC motor drive is shut off during baseblock. Base block can be forced by Multi-function input (setting 09).
6	Low-Voltage Indication	Active when low voltage(Lv) is detected.
7	Operation Mode Indication	Active when operation command is controlled by external terminal.
8	Fault Indication	Active when a fault occurs (oc, ov, oH, oL, oL1, EF, cF3, HPF, ocA, ocd, ocn, GFF).
9	Desired Frequency 1 Attained	Active when the desired frequency 1(Pr.03.02) is attained.
10	Terminal Count Value Attained	Active when the internal counter reaches Terminal Count Value.
11	Preliminary Count Value Attained	Active when the internal counter reaches Preliminary Count Value.
12	Over Voltage Stall supervision	Active when the Over Voltage Stall function(Pr.06.00) operating




Settings	Function	Description
13	Over Current Stall supervision	Active when the Over Current Stall function(Pr.06.01, Pr.06.02) operating
14	Heat Sink Overheat Warning	When heatsink overheats, it will signal to prevent OH turn off the drive. When it is higher than 85°C (185°F), it will be ON.
15	Over Voltage supervision	Active when the DC-BUS voltage exceeds level
16	PID supervision	Active when the PID feedback signal is abnormal (Refer to Pr.10.12 and Pr.13.)
17	Forward command	Active when the direction command is FWD
18	Reverse command	Active when the direction command is REV
19	Zero Speed Output Signal	Active when the drive is standby or stop
20	Communication Warning (FbE,Cexx, AoL2, AUE, SAvE)	Active when there is a Communication Warning
21	Brake Control (Desired Frequency Attained)	Active when output frequency ≥Pr.03.11. Deactivated when output frequency ≤Pr.03.12 after STOP command.
22	Drive Ready	Active when the drive is on and no abnormality detected.
23	Desired Frequency 2 Attained	Active when the desired frequency 1(Pr.03.14) is attained.

03.02	Desired Frequency 1 Attained Unit: 0.01			
03.14	Desired Fro	equency 2 Attained	Unit: 0.01	
	Settings	0.00 to 600.0 Hz	Factory Setting: 0.00	

- If a multi-function output terminal is set to function as Desired Frequency Attained 1(Pr.03.00 Ш to Pr.03.01=09), then the output will be activated when the output frequency reaches Pr.03.02 setting.
- Ш If a multi-function output terminal is set to function as Desired Frequency Attained 2(Pr.03.00 to Pr.03.01=23), then the output will be activated when the output frequency reaches Pr.03.14 setting.



Related parameters: Pr.03.00(Multi-function Output Relay (RA1, RB1, RC1)) and



output timing chart of multiple function terminals(Pr.03.00/Pr.03.01) when setting to frequency attained or zero speed indication



When the output frequency reaches the setting frequency, the detection ranges for the multi-function output terminals are: ±2Hz (from OFF to ON) and ±4Hz (from ON to OFF). The detection range for the output frequency reaches the desired frequency is -2Hz.

03.03					
			Factory Setting: 0		
	Settings	0	Analog Frequency Meter (0 to Maximum Output Frequency)		
		1	Analog Current Meter (0 to 250% of rated AC motor drive current)		

- This parameter sets the function of the AFM output 0~+10VDC (ACM is common). Refer to Pr.03.04 for applications.
- Related parameters: Pr.01.00(Maximum Output Frequency (Fmax)) and Pr.03.04(Analog Output Gain)

03.04	∧ Analog (	Output Gain	Unit: 1
	Settings	1 to 200%	Factory Setting: 100

Ш This parameter sets the voltage range of the analog output signal AFM.

### Chapter 4 Parameters | Value |

- When Pr.03.03 is set to 0, the analog output voltage is directly proportional to the output frequency of the AC motor drive. With Pr.03.04 set to 100%, the Maximum Output Frequency (Pr.01.00) of the AC motor drive corresponds to +10VDC on the AFM output.
- Similarly, if Pr.03.03 is set to 1, the analog output voltage is directly proportional to the output current of the AC drive. With Pr.03.04 set to 100%, then 2.5 times the rated current corresponds to +10VDC on the AFM output.



Any type of voltmeter can be used. If the meter reads full scale at a voltage less than 10V, Pr. 03.04 should be set using the following formula:

Pr. 03.04 = ((meter full scale voltage)/10) x 100%

For Example: When using the meter with full scale of 5 volts, adjust Pr.03.04 to 50%. If Pr.03.03 is set to 0, then 5VDC will correspond to Maximum Output Frequency.

03	.05 Terminal Count Value	Unit: 1
	Settings 0 to 9999	Factory Setting: 0
Ф	This parameter sets the count value of the internal counter. To incre	ease the internal counter,
	one of Pr.04.05 to 04.08 should be set to 12. It can be used in the c	ounter control application.
	Upon completion of counting, the specified output terminal will be ac	ctivated. (Pr.03.00 to
	Pr.03.01 set to 10). (the count value will be reset after reaching the	setting of Pr.03.05)
	Related parameters: Pr.03.00(Multi-function Output Relay (RA1, RB	31, RC1)), Pr.03.01(Multi-
	function Output Terminal MO1), Pr.04.05(Multi-function Input Terminal MO1)	nal (MI3)), Pr.04.06(Multi-
	function Input Terminal (MI4)), Pr.04.07(Multi-function Input Terminal	al (MI5)) and
	Pr.04.08(Multi-function Input Terminal (MI6))	




When the display shows c555, the drive has counted 555 times. If display shows c555•, it means that real counter value is between 5,550 and 5,559.

03.06	Preliminary	/ Count Value	Unit: 1
	Settings	0 to 9999	Factory Setting: 0

When the counter value counts from c1 to this value, the corresponding multi-function output terminal will be activated



- This parameter sets the count value of the internal counter. To increase the internal counter, one of Pr.04.05 to 04.08 should be set to 12. Upon completion of counting, the specified output terminal will be activated. (Pr.03.00 to Pr.03.01 set to 11).
- Ш It can be used as an indication for the AC motor drive run in low speed to stop.
- Related parameters: Pr.03.00(Multi-function Output Relay (RA1, RB1, RC1)), Pr.03.01(Multifunction Output Terminal MO1), Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multifunction Input Terminal (MI4)), Pr.04.07(Multi-function Input Terminal (MI5)) and Pr.04.08(Multi-function Input Terminal (MI6)
- Ш Example: The timing diagram for Pr.03.05=5 and Pr.03.06=3



#### 03.07 EF Active when Terminal Count Value Attained

Factory Setting: 0

# Settings

- 0 Terminal count value attained, no EF display
- Terminal count value attained. EF active
- $\Box$ The E.F. is external fault. It needs to set one of Pr.04.05~Pr.04.08 to 14 to active the terminal.
- $\Box$ If this parameter is set to 1 and the desired value of counter is attained, the AC drive will treat it as a fault. The drive will stop and show the "EF" message on the display. If this parameter is set to 0 and the desired value of counter is attained, the AC drive will continue run.
- Ш It is used for choosing stop the AC motor drive or not when the desired value of counter is attained.



The digital keypad is optional. When using without the keypad, the "FAULT" LED will be ON when there is fault message or warning indication set by external terminals.

በ3 በጸ	Fan	Control	

		Factory Setting: 0
Settings	0	Fan always ON
	1	1 minute after AC motor drive stops, fan will be OFF
	2	Fan ON when AC motor drive runs, fan OFF when AC motor drive stops
	3	Fan ON when preliminary heatsink temperature attained
This parameter determines the operation mode of the cooling fan.		
Setting 0: fan will be ON after the AC motor drive is power on.		

- Setting 1: fan runs when the AC motor drive runs and 1 minute after the AC motor drive stops, fan will stop.
- Setting 2: fan runs when the AC motor drive runs and stops when the AC motor drive stops.
- Setting 3: fan will auto detect the temperature of heatsink and operate by the temperature.

  When heatsink temperature is higher than 60°C, fan will run and the fan will stop once the heatsink temperature is lower than 40°C.

# 103.09 The Digital Output Used by PLC (NOT for VFD\*E\*C models)


Bit6=1: MO6/RA6 used by PLC Bit7=1: MO7/RA7 used by PLC

Settings	Read Only	Factory display: 0
	Bit0=1: RLY used by PLC	
	Bit1=1: MO1 used by PLC	
	Bit2=1: MO2/RA2 used by PLC	
	Bit3=1: MO3/RA3 used by PLC	
	Bit4=1: MO4/RA4 used by PLC	
	Bit5=1: MO5/RA5 used by PLC	


The equivalent 8-bit is used to display the status (used or not used) of each digital output. The value that Pr.03.09 displays is the result after converting 8-bit binary into decimal value.



For standard AC motor drive, it only has 2-bit (bit0 and bit1). When extension card is installed, the number of the digital output terminals will increase according to the extension card. The maximum number of the digital output terminals is shown as follows.




Ш For example: when Pr.03.09 is set to 3 (decimal) = 00000011 (binary) that indicates Relay1 and MO1 are used by PLC. (Pr.03.09= 20+21=3)



# 03.10 The Analog Output Used by PLC (NOT for VFD\*E\*C models) Settinas Read Only Factory display: 0 Bit0=1: AFM used by PLC Bit1=1: AO1 used by PLC Bit2=1: AO2 used by PLC

The equivalent 1-bit is used to display the status (used or not used) of each analog output. The value that Pr.03.10 displays is the result after converting 1-bit binary into decimal value.




For Example:

If Pr.03.10 displays 1, it means that AFM is used by PLC.

03.11	Brake Rele	ase Frequency	Unit: 0.01
	Settings	0.00 to 20.0Hz	Factory Setting: 0.00
03.12	Brake Enga	age Frequency	Unit: 0.01
-	Settings	0.00 to 20.0Hz	Factory Setting: 0.00


- These two parameters are used to set control of mechanical brake via the output terminals (Relay or MO1) by setting Pr.03.00~03.01.
- When Pr.03.00~03.01 is set to 21, the multi-function output terminal will be activated when the output frequency reaches Pr.03.11. When the AC motor drive stops and the output frequency reaches Pr.03.12, this multi-function output terminal will be activated.
- Related parameters: Pr.03.00(Multi-function Output Relay (RA1, RB1, RC1)) and Pr.03.01(Multi-function Output Terminal MO1)



# Example:

When using Pr.03.11 and Pr.03.12 are used in life equipment as above figure. The timing figure is shown as follows. The DC brake is used before start-up and after stop. It can have high output torque at the beginning of start-up. The Brake Release Frequency (Pr.03.11) can be set by the requirement. The Brake Engage Frequency (Pr.03.12) can be set by requirement to be used when stopping near 0Hz to prevent vibration of counterforce for smooth operation.





#### 03.13 Display the Status of Multi-function Output Terminals

Settings Read Only Factory display: 255

Bit0: RLY Status

Bit1: MO1 Status

Bit2: MO2/RA2 Status

Bit3: MO3/RA3 Status


Bit4: MO4/RA4 Status

Bit5: MO5/RA5 Status

Bit6: MO6/RA6 Status

Bit7: MO7/RA7 Status

- $\Box$ When all output external terminals aren't activated, Pr.03.13 will display 255 (11111111).
- $\Omega$ For standard AC motor drive (without extension card), the multi-function output terminals are falling-edge triggered and Pr.03.13 will display 3 (11) for no action.




# Chapter 4 Parameters | Variation

For Example:

If Pr.03.13 displays 2, it means Relay 1 is active.

The display value 2 =bit 1 X 21

When extension card is installed, the number of the multi-function output terminals will increase according to the extension card. The maximum number of the multi-function output terminals is shown as follows.






Group 4: Input Function Parameters

	•			
04.00		otentio	meter Bias	Unit: 0. 1
	Settings	0.0 to	100.0%	Factory Setting: 0.0
04.01		otentio	meter Bias Polarity	
				Factory Setting: 0
	Settings	0	Positive Bias	
		1	Negative Bias	
04.02		otentio	meter Gain	Unit: 0.1
	Settings	0.1 to	200.0%	Factory Setting: 100.0
04.03	Keypad Potentiometer Negative Bias, Reverse Motion Enable/Disable			
				Factory Setting: 0
	Settings	0	No Negative Bias Command	
		1	Negative Bias: REV Motion Enabled	
∩ Dr	.04.0004.03	oro uo	and for those applications that use analogy	roltage signal to adjust the

Pr.04.00~04.03 are used for those applications that use analog voltage signal to adjust the setting frequency. Please refer to the following examples for the details of keypad potentiometer (optional, 0~10V or ±10V).

### Example 1: Standard application

This is the most used setting. The user only needs to set Pr.02.00 to 04. The frequency command comes from keypad potentiometer.




### Example 2: Use of bias

This example shows the influence of changing the bias. When the input is 0V the output frequency is 10 Hz. At mid-point a potentiometer will give 40 Hz. Once the Maximum Output Frequency is reached, any further increase of the potentiometer or signal will not increase the output frequency. (To use the full potentiometer range, please refer to Example 3.) The value of external input voltage/current 0-8.33V corresponds to the setting frequency 10-60Hz. Thus, the center of the keypad potentiometer is


### Chapter 4 Parameters | Value |

40Hz and the value of external input voltage/current 8.33~10V corresponds to the setting frequency 60Hz. Please refer to example 3 for this part.




Example 3: Use of bias and gain for use of full range

This example also shows a popular method. The whole scale of the potentiometer can be used as desired. In addition to signals of 0 to 10V, the popular voltage signals also include signals of 0 to 5V, or any value under 10V. Regarding the setting, please refer to the following examples.



#### Example 4: Use of 0-5V potentiometer range via gain adjustment


This example shows a potentiometer range of 0 to 5 Volts. Instead of adjusting gain as example below, you can set Pr. 01.00 to 120Hz to achieve the same results.






#### Example 5: Use of negative bias in noisy environment

In this example, a 1V negative bias is used. In noisy environments it is advantageous to use negative bias to provide a noise margin (1V in this example).




Example 6: Use of negative bias in noisy environment and gain adjustment to use full potentiometer range

In this example, a negative bias is used to provide a noise margin. Also a potentiometer frequency gain is used to allow the Maximum Output Frequency to be reached.




Example 7: Use of 0-10V potentiometer signal to run motor in FWD and REV direction

In this example, the input is programmed to run a motor in both forward and reverse direction. The motor will be idle when the potentiometer position is at mid-point of its scale. Using the settings in this example disables the external FWD and REV controls.



### Example 8: Use negative slope


In this example, the use of negative slope is shown. Negative slopes are used in applications for control of pressure, temperature or flow. The sensor that is connected to the input generates a large signal (10V) at high pressure or flow. With negative slope settings, the AC motor drive will slow stop the motor. With these settings the AC motor drive will always run in only one direction (reverse). This can only be changed by exchanging 2 wires to the motor.




04.11	Minimum AV	/I Voltage	Unit: 0.1
	Settings	0.0 to 10.0V	Factory Setting: 0.0
04.12	Minimum AV	/I Frequency (percentage of Pr.01.00)	Unit: 0.1
	Settings	0.0 to 100.0%	Factory Setting: 0.0
04.13	Maximum A	VI Voltage	Unit: 0.1
•	Settings	0.0 to 10.0V	Factory Setting: 10.0
04.14	Maximum A	VI Frequency (percentage of Pr. 01.00)	Unit: 0.1
•	Settings	0.0 to 100.0%	Factory Setting: 100.0
04.15	Minimum AC	CI Current	Unit: 0.1
	Settings	0.0 to 20.0mA	Factory Setting: 4.0
04.16	Minimum AC	CI Frequency (percentage of Pr. 01.00)	Unit: 0.1
	Settings	0.0 to 100.0%	Factory Setting: 0.0

	_		Chapter 4 Parameters
04.17	Maximum A	ACI Current	Unit: 0.01
	Settings	0.0 to 20.0mA	Factory Setting: 20.0
04.18	Maximum A	ACI Frequency (percentage of Pr. 01.00)	Unit: 0.1
	Settings	0.0 to 100.0%	Factory Setting: 100.0
04.19	ACI Termin	al Mode Selection	
			Factory Setting: 0
	Settings	0 ACI	
		1 AVI2	
04.20	Minimum A	VI2 Voltage	Unit: 0.1
	Settings	0.0 to 10.0V	Factory Setting: 0.0
04.21	Minimum A	VI2 Frequency (percentage of Pr.1-00)	Unit: 0.1
	Settings	0.0 to 100.0%	Factory Setting: 0.0
04.22	Maximum A	AVI2 Voltage	Unit: 0.1
	Settings	0.0 to 10.0V	Factory Setting: 10.0
04.23	Maximum A	AVI2 Frequency (percentage of Pr.1-00)	Unit: 0.1
	Settings	0.0 to 100.0%	Factory Setting: 100.0

- Please note the ACI/AVI switch on the AC motor drive. Switch to ACI for 4 to 20mA analog current signal (ACI) (Pr.04.19 should be set to 0) and AVI for analog voltage signal (AVI2) (Pr.04.19 should be set to 1). When ACi/AVI switch is not set by Pr.04.19, the keypad (optional) will display fault code "AErr" and needs to press "RESET" to clear it.
- The above parameters are used to set the analog input reference values. The min and max frequencies are based on Pr.01.00 (during open-loop control) as shown in the following.





04.04 Multi-function Input Terminal (MI1, MI2) 2-wire/ 3-wire Operation Control Modes


Factory Setting: 0

Settings 0 2-wire: FWD/STOP, REV/STOP

1 2-wire: FWD/REV. RUN/STOP

2 3-wire Operation

# There are three different types of control modes:






04.04	External Terminal	
2 3-wire	STOP RUN MI1:("CLOSE":RUN) MI3:("OPEN":STOP) MI2:("OPEN": FWD) ("CLOSE": REV) DCM VFD-	

04.05	Multi-function Input Terminal (MI3)	
		Factory Setting: 1
04.06	Multi-function Input Terminal (MI4)	
		Factory Setting: 2
04.07	Multi-function Input Terminal (MI5)	
		Factory Setting: 3
04.08	Multi-function Input Terminal (MI6)	
		Factory Setting: 4

Settings	Function	Description
0	No Function	Any unused terminals should be programmed to 0 to insure they have no effect on operation.
1	Multi-Step Speed Command 1	These four inputs select the multi-speed defined by Pr.05.00 to
2	Multi-Step Speed Command 2	Pr.05.14 as shown in the diagram at the end of this table.
3	Multi-Step Speed Command 3	NOTE: Pr.05.00 to Pr.05.14 can also be used to control output speed by programming the AC motor drive's internal PLC function. There are 17 step speed frequencies (including
4	Multi-Step Speed Command 4	Master Frequency and Jog Frequency) to select for application.
5	External Reset	The External Reset has the same function as the Reset key on the Digital keypad. After faults such as O.H., O.C. and O.V. are cleared this input can be used to reset the drive.





Settings	Function	Description		
Settings 9	External Base Block (Refer to Pr. 08.06)	Parameter value 09 programs a Multi-function Input Terminals for external Base Block control.  NOTE: When a Base-Block signal is received, the AC motor drive will block all output and the motor will free run. When base block control is deactivated, the AC drive will start its speed search function and synchronize with the motor speed, and then accelerate to Master Frequency.  external base block  Speed search starts  Speed detection		
		output voltage with last frequency command  output voltage  B.B. time (08.07)		
10	UP: Increase Master Frequency	Increase/decrease the Master Frequency each time an input is received or continuously when the input stays active. When both		
11	DOWN: Decrease Master Frequency	inputs are active at the same time, the Master Frequency increase/decrease is halted. Please refer to Pr.02.07, 02.08. This function is also called "motor potentiometer".		
12	Counter Trigger	Parameter value 12 programs one of the Multi-function Input Terminals MI3~MI6 (Pr.04.05~Pr.04.08) to increment the AC drive's internal counter. When an input is received, the counter is incremented by 1.		
13	Counter Reset	When active, the counter is reset and inhibited. To enable counting the input should be OFF. Refer to Pr.03.05 and 03.06.		


Settings	Function	Description		
14	External Fault	Parameter value 14 programs one of the Multi-function Input Terminals MI3~MI6 (Pr.04.05~Pr.04.08) to be External Fault (E.F.) inputs.  voltage frequency setting frequency  NIx-GND ON OFF ON Reset OPF ON Command		
15	PID function disabled	When an input ON with this setting is ON, the PID function will be disabled.		
16	Output Shutoff Stop	AC motor drive will stop output and the motor free run if one of these settings is enabled. If the status of terminal is changed, AC motor drive will restart from 0Hz.  voltage frequency setting frequency  operation ON OFF ON  command		
17	Parameter lock enable	When this setting is enabled, all parameters will be locked and write parameters is disabled.		

Settings	Function	Description	
18	Operation Command Selection (Pr.02.01 setting/external terminals)	ON: Operation command via Ext. Terminals  OFF: Operation command via Pr.02.01 setting  When the settings 18, 19 and 20 are ON at the same time, the priority should be setting 18 > setting 19 > setting 20.	
19	Operation Command Selection (Pr 02.01 setting/Digital Keypad)	ON: Operation command via Digital Keypad  OFF: Operation command via Pr.02.01 setting  When the settings 18, 19 and 20 are ON at the same time, the priority should be setting 18 > setting19 > setting20.	
20	Operation Command Selection (Pr 02.01 setting/ Communication)	ON: Operation command via Communication  OFF: Operation command via Pr.02.01 setting  When the settings 18, 19 and 20 are ON at the same time, the priority should be setting 18 > setting19 > setting20.	
21	Forward/Reverse	This function has top priority to set the direction for running (If "Pr.02.04=0")	
22	Source of second frequency command enabled	Used to select the first/second frequency command source. Refer to Pr.02.00 and 02.09.  ON: 2 <sup>nd</sup> Frequency command source  OFF: 1 <sup>st</sup> Frequency command source	
23	Run/Stop PLC Program (PLC1) (NOT for VFD*E*C models)	ON: Run PLC Program OFF: Stop PLC Program When AC motor drive is in STOP mode and this function is enabled, it will display PLC1 in the PLC page and execute PLC program. When this function is disabled, it will display PLC0 in the PLC page and stop executing PLC program. The motor will be stopped by Pr.02.02. When operation command source is external terminal, the keypad cannot be used to change PLC status. And this function will be invalid when the AC Motor drive is in PLC2 status.	

Chapter 4 Parameters | VIII

Settings	Function	Description
23	Quick Stop (ONLY for VFD*E*C models)	It is only valid when Pr.02.01 is set to 5 in VFD*E*C models.
24	Download/Execute/ Monitor PLC Program (PLC2) (NOT for VFD*E*C models)	When AC motor drive is in STOP mode and this function is enabled, it will display PLC2 in the PLC page and you can download/execute/monitor PLC. When this function is disabled, it will display PLC0 in the PLC page and stop executing PLC program. The motor will be stopped by Pr.02.02.  When operation command source is external terminal, the keypad cannot be used to change PLC status. And this function will be invalid when the AC Motor drive is in PLC1 status.
25	Simple position function	This function should be used with Pr.01.20~Pr.01.25 for simple position. Refer to Pr.01.25 for details.
26	OOB (Out of Balance Detection)	The OOB (Out Of Balance Detection) function can be used with PLC for washing machine. When this setting is enabled, it will get $\Delta\theta$ value from the settings of Pr.08.21 and Pr.08.22. PLC or host controller will decide the motor speed by this t $\Delta\theta$ value (Pr.08.23)
27	Motor selection (bit 0)	When this setting is enabled, it can be used for motor selection (Pr. 01.01~01.06, 01.26~01.43, 07.18~07.38, 07.00~07.06).
28	Motor selection (bit 1)	For example: MI1=27, MI2=28  When MI1 and MI2 are OFF, it selects motor 0.  When MI1 is ON and MI2 is OFF, it selects motor 1.  When MI1 is OFF and MI2 is ON, it selects motor 2.  When MI1 and MI2 are ON, it selects motor 3.


#### 




	MI6=4	MI5=3	MI4=2	MI3=1
Master frequency	OFF	OFF	OFF	OFF
1 <sup>st</sup> speed	OFF	OFF	OFF	ON
2 <sup>nd</sup> speed	OFF	OFF	ON	OFF
3 <sup>rd</sup> speed	OFF	OFF	ON	ON
4 <sup>th</sup> speed	OFF	ON	OFF	OFF
5 <sup>th</sup> speed	OFF	ON	OFF	ON
6 <sup>th</sup> speed	OFF	ON	ON	OFF
7 <sup>th</sup> speed	OFF	ON	ON	ON
8 <sup>th</sup> speed	ON	OFF	OFF	OFF
9 <sup>th</sup> speed	ON	OFF	OFF	ON
10 <sup>th</sup> speed	ON	OFF	ON	OFF
11 <sup>th</sup> speed	ON	OFF	ON	ON
12 <sup>th</sup> speed	ON	ON	OFF	OFF
13 <sup>th</sup> speed	ON	ON	OFF	ON
14 <sup>th</sup> speed	ON	ON	ON	OFF
15 <sup>th</sup> speed	ON	ON	ON	ON

04.09	Multi-functio	n Input Contact Selection	Unit: 1
	Settings	0 to 4095	Factory Setting: 0

- This parameter can be used to set the status of multi-function terminals (MI1~MI6 (N.O./N.C.) for standard AC motor drive).
- ☐ The MI1~MI3 setting will be invalid when the operation command source is external terminal (2/3wire).




- The Setting method: It needs to convert binary number (6-bit) to decimal number for input.
- For example: if setting MI3, MI5, MI6 to be N.C. and MI1, MI2, MI4 to be N.O. The setting value Pr.04.09 should be bit5X2<sup>5</sup>+bit4X2<sup>4</sup>+bit2X2<sup>2</sup>= 1X2<sup>5</sup>+1X2<sup>4</sup>+1X2<sup>2</sup>= 32+16+4=52 as shown in the following.



The setting value =  $bit5x2^5 + bit4x2^4 + bit2x2^2$ =  $1x2^5 + 1x2^4 + 1x2^2$ = 32 + 16 + 4 = 52Setting 04.09

When extension card is installed, the number of the multi-function input terminals will increase according to the extension card. The maximum number of the multi-function input terminals is shown as follows.



04.10 Digital Terr	minal Input Debouncing Time	Unit: 2ms
Settings	1 to 20	Factory Setting: 1

- Ш This parameter is used to set the response time of digital input terminals MI1~MI6.
- $\square$ This parameter is to delay the signals on digital input terminals. 1 unit is 2 msec, 2 units are 4 msec, etc. The delay time is to debounce noisy signals that could cause the digital terminals to malfunction.
- Ш The AC motor drive will check the status of multi-function input terminals every 2ms. It will only confirm the command and change the status when the input terminals status is changed. Thus, the delay time from command input to execution is 2msec+ (Pr.04.10+1) X 2ms. Suppose that Pr.04.10 is set to 4, the delay time will be 12ms.

#### 04.24 The Digital Input Used by PLC (NOT for VFD\*E\*C models) Settings Read Only Factory display: 0




Display


Bit0=1: MI1 used by PLC Bit1=1: MI2 used by PLC Bit2=1: MI3 used by PLC Bit3=1: MI4 used by PLC Bit4=1: MI5 used by PLC Bit5=1: MI6 used by PLC Bit6=1: MI7 used by PLC Bit7=1: MI8 used by PLC Bit8=1: MI9 used by PLC Bit9=1: MI10 used by PLC Bit10=1: MI11 used by PLC

Bit11=1: MI12 used by PLC


For standard AC motor drive (without extension card), the equivalent 6-bit is used to display the status (used or not used) of each digital input. The value for Pr.04.24 to display is the result after converting 6-bit binary into decimal value.




For example: when Pr.04.24 is set to 52 (decimal) = 110100 (binary) that indicates MI3, MI5 and MI6 are used by PLC.



When extension card is installed, the number of the digital input terminals will increase according to the extension card. The maximum number of the digital input terminals is shown as follows





# **04.25** The Analog Input Used by PLC (NOT for VFD\*E\*C models)

Settings Read Only Factory display: 0


Display Bit0=1: AVI used by PLC

Bit1=1: ACI/AVI2 used by PLC

Bit2=1: Al1 used by PLC

Bit3=1: Al2 used by PLC

The equivalent 2-bit is used to display the status(used or not used) of each analog input. The value for Pr.04.25 to display is the result after converting 2-bit binary into decimal value.



## 04.26 Display the Status of Multi-function Input Terminal

Settings Read Only Factory display: 63

Display Bit0: MI1 Status

Bit1: MI2 Status

Bit2: MI3 Status

Bit3: MI4 Status

Bit4: MI5 Status



Bit5: MI6 Status

Bit6: MI7 Status

Bit7: MI8 Status


Bit8: MI9 Status

Bit9: MI10 Status

Bit10: MI11 Status

Bit11: MI12 Status


 $\mathbf{m}$ The multi-function input terminals are falling-edge triggered. For standard AC motor drive (without extension card), there are MI1 to MI6 and Pr.04.26 will display 63 (111111) for no action.




#### Ш For Example:

If Pr.04.26 displays 52, it means MI1, MI2 and MI4 are active.

The display value  $52 = 32 + 16 + 4 = 1 \times 2^5 + 1 \times 2^4 + 1 \times 2^2 = bit 6 \times 2^5 + bit 5 \times 2^4 + bit 3 \times 2^2$ 




When extension card is installed, the number of the multi-function input terminals will increase according to the extension card. The maximum number of the multi-function input terminals is shown as follows




04.27	Internal/Extern	nal Multi-function Input Terminals Selection	Unit: 1
	Settings	0 to 4095	Factory Setting: 0


- This parameter is used to select the terminals to be internal terminal or external terminal. You can activate internal terminals by Pr.04.28. A terminal cannot be both internal terminal and external terminal at the same time.
- For standard AC motor drive (without extension card), the multi-function input terminals are MI1 to MI6 as shown in the following.



- The Setting method is convert binary number to decimal number for input.
- For example: if setting MI3, MI5, MI6 to be internal terminals and MI1, MI2, MI4 to be external terminals. The setting value should be bit5X2<sup>5</sup>+bit4X2<sup>4</sup>+bit2X2<sup>2</sup>= 1X2<sup>5</sup>+1X2<sup>4</sup>+1X2<sup>2</sup>= 32+16+4=52 as shown in the following.




When extension card is installed, the number of the multi-function input terminals will increase according to the extension card. The maximum number of the multi-function input terminals is shown as follows.




04.28	✓ Internal	Terminal Status	Unit: 1
	Settings	0 to 4095	Factory Setting: 0

- This parameter is used to set the internal terminal action via keypad(optional), communication or PLC.
- For standard AC motor drive (without extension card), the multi-function input terminals are MI1 to MI6 as shown in the following.






 $\square$ For example, if setting MI3, MI5 and MI6 to be ON, Pr.04.28 should be set to bit $5X2^5$ +bit $4X2^4$ +bit $2X2^2$ =  $1X2^5$ + $1X2^4$ + $1X2^2$ = 32+16+4=52 as shown in the following.



 $\square$ When extension card is installed, the number of the multi-function input terminals will increase according to the extension card. The maximum number of the multi-function input terminals is shown as follows.



#### Chapter 4 Parameters | Wazzala

Group 5: Multi-step Speeds Parameters

05.00		Unit: 0.01
05.01		Unit: 0.01
05.02		Unit: 0.01
05.03		Unit: 0.01
05.04		Unit: 0.01
05.05	★6th Step Speed Frequency	Unit: 0.01
05.06		Unit: 0.01
05.07	₩8th Step Speed Frequency	Unit: 0.01
05.08	✓ 9th Step Speed Frequency	Unit: 0.01
05.09		Unit: 0.01
05.10		Unit: 0.01
05.11		Unit: 0.01
05.12		Unit: 0.01
05.13		Unit: 0.01
05.14		Unit: 0.01
	Settings 0.00 to 600.0Hz	Factory Setting: 0.00

- The Multi-function Input Terminals (refer to setting 1~4 of Pr.04.05 to 04.08) are used to select one of the AC motor drive Multi-step speeds(max. 15 speeds). The speeds (frequencies) are determined by Pr.05.00 to 05.14 as shown in the following.
- $\hfill \Box$  The operation time of multi-step speeds can be set by PLC program.
- The run/stop command can be controlled by the external terminal/digital keypad/communication via Pr.02.01.
- $\hfill \Box$  Each one of multi-step speeds can be set within 0.0~600.0Hz during operation.
- These parameters can be applied in small machinery, food processing machinery, washing equipment to control the operation procedure. It can be used instead of traditional circuit, such as relay, switch or counter.
- Explanation for the timing diagram for multi-step speeds and external terminals
   The Related parameter settings are:
  - 1. Pr.05.00~05.14: setting multi-step speeds (to set the frequency of each step speed)
  - 2. Pr.04.05~04.08: setting multi-function input terminals (multi-step speed 1~4)
  - 3. The repeat operation setting of 1st-15th step speed frequency: can use PLC program to control. Please refer to Appendix D How to use PLC function for details.




- 4. The operation direction setting of 1st-15th step speed frequency: can use PLC program to control. Please refer to Appendix D How to use PLC function for details.
- 5. The operation time setting of 1st-15th step speed frequency: can use PLC program to control. Please refer to Appendix D How to use PLC function for details.

#### Operations:

Once the AC motor drive receives "RUN" command, it will operate by parameters settings and PLC program till the 15th step speed frequency is completed.

- If it is repeat operation by PLC program, the AC motor drive will operate by the settings from Pr.05.00→Pr.05.01→.... → Pr.05.14→Pr.05.00→Pr.05.01..till the operation command is OFF.
- Related parameters: Pr.01.15(Jog Frequency), Pr.01.07(Output Frequency Upper Limit), Pr.01.08(Output Frequency Lower Limit), Pr.04.05(Multi-function Input Terminal (MI3)). Pr.04.06(Multi-function Input Terminal (MI4)), Pr.04.07(Multi-function Input Terminal (MI5)) and Pr.04.08(Multi-function Input Terminal (MI6))






	MI6=4	MI5=3	MI4=2	MI3=1
Master frequency	OFF	OFF	OFF	OFF
1 <sup>st</sup> speed	OFF	OFF	OFF	ON
2 <sup>nd</sup> speed	OFF	OFF	ON	OFF
3 <sup>rd</sup> speed	OFF	OFF	ON	ON
4 <sup>th</sup> speed	OFF	ON	OFF	OFF
5 <sup>th</sup> speed	OFF	ON	OFF	ON
6 <sup>th</sup> speed	OFF	ON	ON	OFF
7 <sup>th</sup> speed	OFF	ON	ON	ON
8 <sup>th</sup> speed	ON	OFF	OFF	OFF
9 <sup>th</sup> speed	ON	OFF	OFF	ON
10 <sup>th</sup> speed	ON	OFF	ON	OFF
11 <sup>th</sup> speed	ON	OFF	ON	ON
12 <sup>th</sup> speed	ON	ON	OFF	OFF
13 <sup>th</sup> speed	ON	ON	OFF	ON
14 <sup>th</sup> speed	ON	ON	ON	OFF
15 <sup>th</sup> speed	ON	ON	ON	ON



Group 6: Protection Parameters

06.00	Over-Vo	Itage Stall Prevention	Unit: 0.1	
	Settings	115V/230V series	330.0 to 410.0V	Factory Setting: 390.0
		460V series	660.0 to 820.0V	Factory Setting: 780.0
		0	Disable Over-voltage Stall Prevention (with brake unit or brake resistor)	


- Ш During deceleration, the DC bus voltage may exceed its Maximum Allowable Value due to motor regeneration. When this function is enabled, the AC motor drive will not decelerate further and keep the output frequency constant until the voltage drops below the preset value again.
- Ш With moderate inertia load, over-voltage stall prevention will not occur and the real deceleration time will be equal to the setting of deceleration time. The AC drive will automatically extend the deceleration time with high inertia loads. If the deceleration time is critical for the application, a brake resistor or brake unit should be used.
- Ш When the function of over-voltage stall prevention is activated, the deceleration time of the AC motor drive will be larger than the setting.
- Ш When the deceleration time is obstruction in the application, it is not suitable to use this function. The solution are:
  - 1 moderate increase the deceleration time.
  - 2. used with a brake resistor (refer to appendix B for details) to consume the regenerative energy by heat.
- Ш Related parameters: Pr.01.10(Decel Time 1), Pr.01.12(Decel Time 2), Pr.03.00(Multi-function Output Relay (RA1, RB1, RC1)) and Pr.03.01(Multi-function Output Terminal MO1)



06.01	Over-Curre	ent Stall Prevention during Acceleration	Unit: 1
	Settings	20 to 250%	Factory Setting: 170
		0: disable	


- $\hfill \square$  A setting of 100% is equal to the Rated Output Current of the drive.
- During acceleration, the AC drive output current may increase abruptly and exceed the value specified by Pr.06.01 due to rapid acceleration or excessive load on the motor. When this function is enabled, the AC drive will stop accelerating and keep the output frequency constant until the current drops below the maximum value.
- When it stalls due to the small motor power or operate with factory setting, please decrease the setting of Pr.06.01.
- When the acceleration time is obstruction in the application, it is not suitable to use this function. The solution are:
  - 1. moderate increase the acceleration time
  - 2. setting Pr.01.16 (Auto acceleration / deceleration (refer to Accel/Decel time setting)) to 1, 3 or 4.

Ш Related parameters: Pr.01.09(Accel Time 1), Pr.01.11(Accel Time 2), Pr.01.16(Auto acceleration / deceleration (refer to Accel/Decel time setting)), Pr.03.00(Multi-function Output Relay (RA1, RB1, RC1)), Pr.03.01(Multi-function Output Terminal MO1) and Pr.06.03(Over-Torque Detection Mode (OL2))



06.02	06.02 Over-current Stall Prevention during Operation			
	Settings	20 to 250%	Factory Setting: 170	
		0: disable		

- $\square$ The over-current stall prevention during operation function is a protection. When the motor runs with constant speed, the AC motor drive will decrease the output frequency automatically when momentary overload.
- Ш If the output current exceeds the setting specified in Pr.06.02 when the drive is operating, the drive will decrease its output frequency by Pr.01.10/Pr.01.12 to prevent the motor stall. If the output current is lower than (Pr.06.02 setting -rated current X 5%), the drive will accelerate again by Pr.01.09/Pr.01.11 to catch up with the set frequency command value.
- Ш Related parameter: Pr.06.03 Over-Torque Detection Mode (OL2)



over-current stall prevention during operation



Please do not set the over-current stall prevention to a small value to prevent over-low torque.

06.03 Over-Toro	06.03 Over-Torque Detection Mode (OL2)				
		Factory Setting: 0			
Settings	0	Over-Torque detection disabled.			
	1	Over-Torque detection enabled during constant speed operation. After over-torque is detected, keep running until OL1 or OL occurs.			
	2	Over-Torque detection enabled during constant speed operation. After over-torque is detected, stop running.			
	3	Over-Torque detection enabled during acceleration. After over- torque is detected, keep running until OL1 or OL occurs.			
	4	Over-Torque detection enabled during acceleration. After over-torque is detected, stop running.			

- This parameter determines the operation mode of the drive after the over-torque (OL2)
- This parameter determines the operation mode of the drive after the over-torque (OL2) is detected via the following method:
  - 1. if the output current exceeds the over-torque detection level (Pr.06.04) and the detection time is longer than the setting of Pr.06.05 Over-Torque Detection Time, the warning message "OL2" is displayed on digital keypad (optional). It needs to press "RESET" to clear the warning message.
  - 2. If a Multi-function Output Terminal is set to over-torque detection (Pr.03.00~03.01=04), the output is on. Please refer to Pr.03.00~03.01 for details.

1/200			
17:33			

- Setting 1 or 2: it is used to detect with constant speed. For setting 2, it will free run to stop after over-torque is detected.
- Setting 3 or 4: it is used to detect during acceleration. For setting 4, it will free run to stop after over-torque is detected.
- Related parameters: Pr.03.00(Multi-function Output Relay (RA1, RB1, RC1)), Pr.03.01(Multi-function Output Terminal MO1), Pr.06.01(Over-Current Stall Prevention during Accel), Pr.06.02(Over-Current Stall Prevention during Operation) Pr.06.04(Over-Torque Detection Level) and Pr.06.05(Over-Torque Detection Time)

06.04	✓ Over-Toro	que Detection Level (OL2)	Unit: 1
	Settings	10 to 200%	Factory Setting: 150


06.05	Over-Torque	Detection Time (OL2)	Unit: 0.1
	Settings	0.1 to 60.0 sec	Factory Setting: 0.1

- Pr.06.04 is proportional to the Rated Output Current of the drive.
- Pr.06.05 sets the time for how long over-torque must be detected before "OL2" is displayed.
- The method to detect over-torque is shown as follows:
  - 1. when output current exceeds over-torque detection level (Pr.06.04)
  - 2. when over-torque time exceeds over torque detection time (Pr.06.05)
  - If a Multi-function Output Terminal is set to over-torque detection (Pr.03.00~03.01=04), the output is on. Please refer to Pr.03.00~03.01 for details.
- For general motor, the output torque and output current of the AC motor drive will in proportion in V/f control. Thus, it can use the output current of the AC motor drive to limit the output torque of motor.
- Related parameters: Pr.03.00(Multi-function Output Relay (RA1, RB1, RC1)) and Pr.03.01(Multi-function Output Terminal MO1)

06.0	6 Electronic Thermal Overload Relay Selection (OL1)				
			Factory Setting: 2		
	Settings	0	Operate with a Standard Motor (self-cooled by fan)		
		1	Operate with a Special Motor (forced external cooling)		
		2	Operation disabled		
m	This accounts is used to set the accounting selection of the electronic theoretic and selection				

This parameter is used to set the operation selection of the electronic thermal overload relay.

- This function is used to protect the motor from overloading or overheating. When the motor (self-cooled by fan) operates in low frequency, overload is seldom happened. Refer to the following figure for the application.
- When the rated current of motor is less than drive's or bad design of the motor heat dissipation, it can use this parameter to limit the output current of the AC motor drive to prevent motor from overheating or damage.
- Setting 0: the electronic thermal relay is used for standard motor(heatsink is fixed on rotor shaft). When operating in low speed, the motor heat dissipation function will be bad. Thus, it needs to decrease the action time of the electronic thermal relay to ensure the motor life.
- Setting 1: the electron thermal relay is used for special motor(heatsink uses independent power). The heat dissipation function has no direction relation with rotation speed. Thus, the electronic thermal relay is still held in low speed to ensure the motor load ability in low speed.
- In the frequent power ON/OFF applications, it can't use this parameter (even set to 0 or 1) for protection due to this function will be reset once the power is OFF. Thus, it needs to add the thermal relay on each motor when an AC motor drive is connected with several motors.
- Setting 0 or 1: when the electronic thermal relay protection is enabled in low speed operation, the AC motor drive will display "OL1" and free run to stop. It needs to press "RESET" to clear the warning message.
- Related parameter: Pr.06.07(Electronic Thermal Characteristic)





When the standard motor operates in low speed with rated current, the motor overload protection will occur easily. Thus, please use the special motor when operates in low speed with rated current.


Refer to Appendix C.3 How to choose a suitable motor for motor selection.

	_		Chapter 4 Parameters	V/527-E
06.07	Electronic Th	ermal Characteristic		Unit: 1
	Settings	30 to 600 sec	Factory	Setting: 60

- The parameter determines the time required for activating the I<sup>2</sup>t electronic thermal protection function by the output frequency/current of the AC motor drive and operation time to prevent motor from overheating.
- The electronic thermal overload relay acts by Pr.06.06 setting:
  - 1. Pr.06.06 is set to 0(Operate with a Standard Motor (self-cooled by fan)): when the output current is greater than (Pr.07.00 Motor Rated Current (Motor 0)X (the corresponding motor rated current % of motor rated frequency in standard motor figure in Pr.06.06) X150%), the AC motor drive will start to count time. When accumulated time exceeds Pr.06.07(Electronic Thermal Characteristic) setting, the electronic thermal overload relay protection (OL1) will be ON.
  - 2. Pr.06.06 is set to 1(Operate with a Special Motor (forced external cooling)): when the output current is greater than (Pr.07.00 Motor Rated Current (Motor 0)X (the corresponding motor rated current % of motor rated frequency in special motor figure in Pr.06.06) X150%), the AC motor drive will start to count time. When accumulated time exceeds Pr.06.07(Electronic Thermal Characteristic) setting, the electronic thermal overload relay protection (OL1) will be ON.
- The actual action time of electronic thermal characteristic will be adjusted by the output current of the AC motor drive (motor load rate %). For large current, it needs short time to activate the I<sup>2</sup>t electronic thermal protection function. For small current, it needs long time to activate the I<sup>2</sup>t electronic thermal protection function as shown in the following figure.
- Related parameters: Pr.06.06(Electronic Thermal Overload Relay Selection) and Pr,07.00(Motor Rated Current (Motor 0))



Please refer to Pr.06.06(Electronic Thermal Overload Relay Selection (OL1)) for curve figure of standard motor and special motor.





06.08	Present Fault Record
06.09	Second Most Recent Fault Record
06.10	Third Most Recent Fault Record
06.11	Fourth Most Recent Fault Record
06.12	Fifth Most Recent Fault Record

		Factory Setting: 0
Readings	0	No fault
	1	Over-current (oc)
	2	Over-voltage (ov)
	3	IGBT Overheat (oH1)
	4	Power Board Overheat (oH2)
	5	Overload(oL)
	6	Overload (oL1)
	7	Motor Overload (oL2)
	8	External Fault (EF)
	9	Hardware protection failure (HPF)
	10	Current exceeds 2 times rated current during accel.(ocA)
	11	Current exceeds 2 times rated current during decel.(ocd)
	12	Current exceeds 2 times rated current during steady state operation (ocn)
	13	Reserved
	14	Phase-loss (PHL)
	15	Reserved
	16	Auto accel/decel failure (CFA)
	17	Software/password protection (codE)
	18	Power Board CPU WRITE Failure (cF1.0)
	19	Power Board CPU READ Failure (cF2.0)
	20	CC, OC Hardware protection failure (HPF1)
	21	OV Hardware protection failure (HPF2)
	22	GFF Hardware protection failure (HPF3)
	23	OC Hardware protection failure (HPF4)
	24	U-phase error (cF3.0)
	25	V-phase error (cF3.1)
	26	W-phase error (cF3.2)
	27	DCBUS error (cF3.3)
	28	IGBT Overheat (cF3.4)

Chapter 4 Parameters	VFD-E	
	29	Power Board Overheat (cF3.5)
	30	Control Board CPU WRITE failure (cF1.1)
	31	Contrsol Board CPU READ failure (cF2.1)
	32	ACI signal error (AErr)
	33	Reserved
	34	Motor PTC overheat protection (PtC1)
	35-39	Reserved
	40	Communication time-out error of control board and power board (CP10)
	41	dEb error
	42	ACL (Abnormal Communication Loop)

In Pr.06.08 to Pr.06.12 the five most recent faults that occurred, are stored. After removing the cause of the fault, use the reset command to reset the drive.



#### Group 7: Motor Parameters

Ш

07	.00 Motor Rate	d Current (Motor 0)	Unit: 1
	Settings	30% FLA to 120% FLA	Factory Setting: FLA
Ω.	Use the followi	ng formula to calculate the percentage va	alue entered in this parameter:

- (Motor Current / AC Drive Current) x 100% with Motor Current=Motor rated current in A on type shield AC Drive Current=Rated current of AC drive in A (see Pr.00.01)
- Pr.07.00 must be greater than Pr.07.01. Example: Suppose that the rated current of 460V/2.0HP(1.5kW) is 4.2A with the factory setting 4.2A. The range that user can set is from 1.3A(4.2X30%) to 5.0A(4.2X120%). But when Pr.07.00 is set to less than 1.7A(4.2X40%), it needs to set Pr.07.01 to be less than 30% FLA first. In this way, Pr.07.00 is greater than Pr.07.01.
- Ш Pr.07.00 and Pr.07.01 must be set if the drive is programmed to operate in Vector Control mode (Pr.00.10 = 1). They also must be set if the "Electronic Thermal Overload Relay" (Pr.06.06) or "Slip Compensation" (Pr.07.03 and Pr.07.06) functions are selected.
- Ш The full-load current should be less than the rated current of the AC motor drive and should be greater than 1/2 rated current of the AC motor drive.
- ш Related parameters: Pr.00.01(Rated Current Display of the AC motor drive), Pr.06.06(Electronic Thermal Overload Relay Selection), Pr.06.07(Electronic Thermal Characteristic), Pr.07.01(Motor No-Load Current (Motor 0)), Pr.07.03(Slip Compensation (Used without PG) (Motor 0)) and Pr.07.06(Motor Rated Slip (Motor 0))

07.01	Motor No-loa	ad Current (Motor 0)	Unit: 1
	Settings	0% FLA to 99% FLA	Factory Setting: 0.4*FLA

- Ш This parameter is used to set the motor no-load current. The user must input motor no-load current by the motor nameplate. The factory setting be set to 40% X the rated current of the AC motor drive (refer to Pr.00.01 Rated Current Display of the AC motor drive).
  - Example: Suppose that the rated current of 460V/2.0hp(1.5kW) is 4.2A with factory setting 4.2A. The motor no-load current is 1.7A(4.2X40%) and it should set Pr.07.01 to 1.7.
- This parameter must be set if the "Electronic Thermal Overload Relay" (Pr.06.06) or "Slip Ш Compensation"(Pr.07.03 and Pr.07.06) functions are selected.

# Chapter 4 Parameters | Visit |

- If the motor no-load current can't be read from the nameplate, operating the AC motor drive after unloading and read it from the digital keypad (optional, refer to Appendix B for details).
- The setting value must be less than Pr.07.00 (Motor Rated Current).
- Related parameters: Pr.00.01(Rated Current Display of the AC motor drive), Pr.07.00(Motor Rated Current (Motor 0)), Pr.07.03(Slip Compensation (Used without PG) (Motor 0)) and Pr.07.06(Motor Rated Slip (Motor 0))

07.02	✓ Torque Co	ompensation (Motor 0)	Unit: 0.1
	Settings	0.0 to 10.0	Factory Setting: 0.0

- For the induction motor characteristic, parts of the drive output voltage will be absorbed by the impedance of stator windings when motor load is large. In this circumstance, the output current will be too large and output torque is insufficient due to the motor voltage at inductance end of motor is insufficient and insufficient air-gap magnetic field. Using this parameter, it will auto adjust output voltage by the load to get the best operation with the air-gap magnetic field is held.
- In V/f control mode, the voltage will decrease by the decreasing frequency. It will cause lower torque in low speed due to less AC impedance and constant DC resistor. Thus, this parameter can be set for the AC drive increase its voltage output to obtain a higher torque in low speed.
- Too high torque compensation can overheat the motor.
- This parameter is only used for V/f control mode.
- Related parameters: Pr.00.10(Control Method) and Pr.07.08(Torque Compensation Time Constant).

07.03	✓ Slip Com	pensation (Used without PG) (Motor 0)	Unit: 0.01
	Settings	0.00 to 10.00	Factory Setting: 0.00

- When the induction motor generates the electromagnetic torque, it needs the necessary slip.

  But the slip can be ignored when it needs only 2-3% slip in higher speed. When the drive operates, the slip and synchronous frequency are in reverse proportion. That is, the slip will be increased with the decreasing synchronous frequency. The slip affects the motor speed seriously in low speed because the motor may stop and can't run with load when the synchronous frequency is too low.
- While driving an asynchronous motor, increasing the load on the AC motor drive will cause an increase in slip and decrease in speed.



- Ш This parameter may be used to compensate the slip by increasing the output frequency. When the output current of the AC motor drive is bigger than the motor no-load current (Pr.07.01), the AC drive will adjust its output frequency according to this parameter.
- Ш When Pr.00.10 is set from V/f mode to vector mode, this parameter will be set to 1.00 automatically. When Pr.00.10 is set from vector mode to V/f mode, this parameter will be set to 0.00. Please using this function after load is added and acceleration with gradual increasing compensation. That is, add the output frequency with Pr.07.06(Motor Rated Slip (Motor 0)) X Pr.07.03(Slip Compensation (Used without PG) (Motor 0)) on the output frequency

Unit· 1

Factory Setting: 0

Settings

- 0 Disable
- 1 Auto Tuning R1 (motor doesn't run)
- 2 Auto Tuning R1 + No-load Test (with running motor)
- ш Start Auto Tuning by pressing RUN key after this parameter is set to 1 or 2.

When setting to 1, it will only auto detect R1 value and Pr.07.01 must be input manually. When set to 2, the AC motor drive should be unloaded and the values of Pr.07.01 and Pr.07.05 will be set automatically.

- Ш The steps for AUTO-Tuning are:
  - 1. Make sure that all the parameters are set to factory settings and the motor wiring is correct
  - 2. Make sure the motor has no-load before executing auto-tuning and the shaft is not connected to any belt or gear motor.
  - 3. Fill in Pr.01.01, Pr.01.02, Pr.07.00, Pr.07.04 and Pr.07.06 with correct values.
  - 4 After Pr.07.04 is set to 2, the AC motor drive will execute auto-tuning immediately after receiving a "RUN" command. (Note: The motor will run!). The total auto tune time will be 15 seconds + Pr.01.09 + Pr.01.10. Higher power drives need longer Accel/Decel time (factory setting is recommended). After executing Auto-tune. Pr.07.04 is set to 0.
  - After executing, please check if there are values filled in Pr.07.01 and Pr.07.05. If not, 5. please press RUN key after setting Pr.07.04 again.
  - 6. Then you can set Pr.00.10 to 1 and set other parameters according to your application requirement.

Related parameters: Pr.01.01(Maximum Voltage Frequency (Fbase) (Motor 0)),
Pr.01.02(Maximum Output Voltage (Vmax) (Motor 0)), Pr.07.00(Motor Rated Current (Motor 0)), Pr.07.01(Motor No-Load Current (Motor 0)), Pr.07.05(Motor Line-to-line Resistance R1 (Motor 0)) and Pr.07.06(Motor Rated Slip (Motor 0))



- 1. In vector control mode it is not recommended to have motors run in parallel.
- It is not recommended to use vector control mode if motor rated power exceeds the rated power of the AC motor drive.

07.05	Motor Line-	to-line Resistance R1 (Motor 0)	Unit: 1
	Settings	0 to 65535 m $\Omega$	Factory Setting: 0

The motor auto tune procedure will set this parameter. The user may also set this parameter without using Pr.07.04.

07.06	Motor Rated	Slip (Motor 0)	Unit: 0.01
	Settings	0.00 to 20.00Hz	Factory Setting: 3.00

- It can be used to set the motor rated slip. Users need to input the actual rated rpm shown on the nameplate of the motor.
- Refer to the rated rpm and the number of poles on the nameplate of the motor and use the following equation to calculate the rated slip.

Rated Slip (Hz) =  $F_{base}$  (Pr.01.01 base frequency) – (rated rpm x motor pole/120)

Example: Assume that the rated frequency of the motor is 60Hz with 4 poles and the rated rpm is 1650rpm. The rated slip calculated by the formula should be 60Hz-(1650X4/120)=5Hz.

- This parameter has relation with Pr.07.03(Slip Compensation (Used without PG) (Motor 0)). To get the best slip compensation effect, it needs to input the correct setting. The incorrect setting may cause the invalid function and even damage the motor and drive.
- Related parameter: Pr.07.03(Slip Compensation (Used without PG) (Motor 0))

07.07	Slip Comper	nsation Limit	Unit: 1
	Settings	0 to 250%	Factory Setting: 200

This parameter sets the upper limit of the compensation frequency (the percentage of Pr.07.06).



Example: when Pr.07.06=5Hz and Pr.07.07=150%, the upper limit of the compensation frequency is 7.5Hz. Therefore, for a 50Hz motor, the max. output is 57.5Hz.

- Ш If the motor speed is lower than the target speed and the speed isn't changed after adjusting Pr.07.03 setting, it may reach the upper limit of the compensation frequency and need to increase Pr.07.07 setting.
- Ш Related parameters: Pr.07.03(Slip Compensation (Used without PG) (Motor 0)) and Pr.07.06(Motor Rated Slip (Motor 0))

07.08	Torque Com	pensation Time Constant	Unit: 0.01
	Settings	0.01 ~10.00 sec	Factory Setting: 0.30

Ш It is usually applied in those heavy load applications which the motor current is changed frequently. The current is changed for the current compensation to increase the output torque. Because the frequent current change will cause the machine vibration, it can increase Pr.07.08 setting to solve this problem at this moment.

07.09 Slip	Compensation Time Constant	Unit: 0.01
Set	ings 0.05 ~10.00 sec	Factory Setting: 0.20

- Ш It is usually applied in those heavy load applications which the motor speed is changed frequently. The speed is changed for the speed compensation to reach the synchronous speed. Because the frequent speed change will cause the machine vibration, it can increase Pr.07.09 setting to solve this problem at this moment...
- Ш Too long time constants (set Pr.07.08 and Pr.07.09 to 10) give slow response; too short values can give unstable operation. Please set by your applications.

Unit: 1	ive Motor Operation Time (Min.)	7.10 Accumulati
Factory Display: 0	0	Settings
	0~1439	Displays
Unit: 1	ive Motor Operation Time (Day)	7.11 Accumulati
Factory Display: 0	0	Settings
	0 ~65535	Displays

Ш Pr.07.10 and Pr.07.11 are used to record the motor operation time. They can be cleared by setting to 0 and time is less than 1 minute is not recorded.

When setting Pr.07.11 to 0, it will reset the accumulative motor operation time and the record will be reset to 0

07.12 Motor PTC Overheat Protection			Unit: 1
			Factory Setting: 0
Settings	s 0	Disable	
	1	Enable	
<b>07.14</b> Motor F	07.14 Motor PTC Overheat Protection Level		Unit: 0.1
Settings	0.1	~10.0V	Factory Setting: 2.4

- When the motor is running at low frequency for a long time, the cooling function of the motor fan will be lower. To prevent overheating, it needs to have a Positive Temperature Coefficient thermoistor on the motor and connect its output signal to the drive's corresponding control terminals
- When the source of first/second frequency command is set to AVI (02.00=1/02.09=1), it will disable the function of motor PTC overheat protection (i.e. Pr.07.12 cannot be set to 1). Only one of the source of first master frequency command and second master frequency command can be enable at one time.
- If temperature exceeds the setting level, motor will be coast to stop and Grant is displayed. When the temperature decreases below the level of (Pr.07.15-Pr.07.16) and Grant is stops blinking, you can press RESET key to clear the fault.
- Pr.07.14 (overheat protection level) must exceed Pr.07.15 (overheat warning level).
- The PTC uses the AVI-input and is connected via resistor-divider as shown below.

The voltage between +10V to ACM: lies within 10.4V~11.2V.

The impedance for AVI is around  $47k\Omega$ .

Recommended value for resistor-divider R1 is 1~10k Ω.

Please contact your motor dealer for the curve of temperature and resistance value for PTC.

Refer to following calculation for protection level and warning level.

Protection level

$$Pr.07.14 = V_{+10} * (R_{PTC1} / / 47K) / [R1 + (R_{PTC1} / / 47K)]$$

Warning level

Definition:

V+10: voltage between +10V-ACM, Range 10.4~11.2VDC

RPTC1: motor PTC overheat protection level. Corresponding voltage level set in Pr.07.14,

RPTC2: motor PTC overheat warning level. Corresponding voltage level set in Pr.07.15,


47kΩ: is AVI input impedance, R1: resistor-divider (recommended value: 1~20kΩ)

Take the standard PTC thermistor as example: if protection level is  $1330\Omega$ , the voltage between +10V-ACM is 10.5V and resistor-divider R1 is  $4.4k\Omega$ . Refer to following calculation for Pr.07.14 setting.

1330//47000=(1330\*47000)/(1330+47000)=1293.4

$$10.5^*1293.4/(4400+1293.4) = 2.38(V) = 2.4(V)$$

Therefore, Pr.07.14 should be set to 2.4.



Related parameters: Pr.02.00(Source of First Master Frequency Command), Pr.02.09(Source of Second Frequency Command), Pr.07.13(Input Debouncing Time of the PTC Protection), Pr.07.15(Motor PTC Overheat Warning Level), Pr.07.16(Motor PTC Overheat Reset Delta Level) and Pr.07.17(Treatment of the Motor PTC Overheat)

		=	
Unit: 0.1	Motor PTC Overheat Warning Level		
Factory Setting: 1.2	~10.0V	Settings 0.1	
Unit: 0.1	Motor PTC Overheat Reset Delta Level		
Factory Setting: 0.6	~5.0V	Settings 0.1	
	Treatment of the motor PTC Overheat		
Factory Setting: 0			
	Warn and RAMP to stop	Settings 0	
	Warn and COAST to stop	1	
	Warn and keep running	2	

- If temperature exceeds the motor PTC overheat warning level (Pr.07.15), the drive will act according to Pr.07.17 and display on the keypad.
- Setting Pr.07.17 to 0: When the motor PTC overheat protection is activated, it will display on the digital keypad and the motor will stop to 0Hz by Pr.01.10/Pr.01.12 setting.
- Setting Pr.07.17 to 1: When the motor PTC overheat protection is activated, it will display Pt C on the digital keypad and the motor will free run to stop.
- Setting Pr.07.17 to 2: When the motor PTC overheat protection is activated, it will display Pt C on the digital keypad and the motor will keep running.
- If the temperature decreases below the result (Pr.07.15 minus Pr.07.16), the warning display Pt C will disappear.

# NOTE

The digital keypad is optional. Please refer to Appendix B for details. When using without this optional keypad, the FAULT LED will be ON once there is error messages or warning messages from the external terminals

07.13	Input Debouncing Time of the PTC Protection		Unit: 2
	Settings	0~9999 (is 0-19998ms)	Factory Setting: 100



Ш This parameter is to delay the signals on PTC analog input terminals. 1 unit is 2 msec, 2 units are 4 msec, etc.

07.18	Motor Rate	ed Current (Motor 1)	Unit: 1
	Settings	30% FLA to 120% FLA	Factory Setting: FLA
07.19	Motor No-l	oad Current (Motor 1)	Unit: 1
•	Settings	0% FLA to 90% FLA	Factory Setting: 0.4*FLA
07.20	✓ Torque (	Compensation (Motor 1)	Unit: 0.1
	Settings	0.0 to 10.0	Factory Setting: 0.0
07.21		npensation (Used without PG) (Motor 1)	Unit: 0.01
	Settings	0.00 to 10.00	Factory Setting: 0.00
07.22	Motor Line	t-to-line Resistance R1 (Motor 1)	Unit: 1
	Settings	0 to 65535 m $\Omega$	Factory Setting: 0
07.23	Motor Rate	ed Slip (Motor 1)	Unit: 0.01
	Settings	0.00 to 20.00Hz	Factory Setting: 3.00
07.24	Motor Pole	e Number (Motor 1)	Unit: 1
	Settings	2 to 10	Factory Setting: 4
07.25	Motor Rate	ed Current (Motor 2)	Unit: 1
	Settings	30% FLA to 120% FLA	Factory Setting: FLA
07.26	Motor No-I	oad Current (Motor 2)	Unit: 1
	Settings	0% FLA to 90% FLA	Factory Setting: 0.4*FLA
07.27	★Torque (	Compensation (Motor 2)	Unit: 0.1
	Settings	0.0 to 10.0	Factory Setting: 0.0
07.28		npensation (Used without PG) (Motor 2)	Unit: 0.01
	Settings	0.00 to 10.00	Factory Setting: 0.00
07.29	Motor Line	t-to-line Resistance R1 (Motor 2)	Unit: 1
	Settings	0 to 65535 m $\Omega$	Factory Setting: 0
07.30	Motor Rate	ed Slip (Motor 2)	Unit: 0.01
	Settings	0.00 to 20.00Hz	Factory Setting: 3.00
07.31	Motor Pole	e Number (Motor 2)	Unit: 1
	Settings	2 to 10	Factory Setting: 4
07.32	Motor Rate	ed Current (Motor 3)	Unit: 1
	Settings	30% FLA to 120% FLA	Factory Setting: FLA
07.33	Motor No-I	oad Current (Motor 3)	Unit: 1
	Settings	0% FLA to 90% FLA	Factory Setting: 0.4*FLA

Chapter 4 Farameters
<b>07.34 //</b> Torque C
Settings
<b>07.35</b>
Settings
07.36 Motor Line-
Settings
07.37 Motor Rate
Settings
07.38 Motor Pole
Settings
com com

The motor 0 to motor 3 can be selected by setting the multi-function input terminals MI3~MI6 (Pr.04.05 to Pr.04.08) to 27 and 28.



#### Group 8: Special Parameters

08	08.00 DC Brake Current Level		Unit: 1	
•	Settings	0 to 100%	Factory Setting: 0	
00	This naramete	sets the level of DC Brake Curre	ent output to the motor during start-up and	

- This parameter sets the level of DC Brake Current output to the motor during start-up and stopping. When setting DC Brake Current, the Rated Current (Pr.00.01) is regarded as 100%. It is recommended to start with a low DC Brake Current Level and then increase until proper holding torque has been achieved.
- Ш Related parameters: Pr.08.01(DC Brake Time during Start-up) and Pr.08.02(DC Brake Time during Stopping)

08.01 DC Brake Time during Start-up		Time during Start-up	Unit: 0.1
	Settings	0.0 to 60.0 sec	Factory Setting: 0.0


- Ш The motor may keep running due to external factor or itself inertia. The over current may damage the motor or activate the drive's protection when running the drive suddenly. This parameter can output a DC current with a torque to force the motor to stop for a stable start.
- Ш This parameter determines the duration of the DC Brake current after a RUN command. When the time has elapsed, the AC motor drive will start accelerating from the Minimum Frequency (Pr.01.05). The DC brake is invalid when Pr.08.01 is set to 0.

08.02 DC Brake Time during Stopping		Unit: 0.1
Settings	0.0 to 60.0 sec	Factory Setting: 0.0

- $\square$ The motor may keep running due to external factor or itself inertia and can't stop by requirement. This parameter can output a DC current with a torque to force the motor to stop after the drive stops outputting to ensure the motor is stop.
- Ш This parameter determines the duration of the DC Brake current during stopping. If stopping with DC Brake is desired, Pr.02.02 Stop Method must be set to 0 or 2 for Ramp to Stop. The DC brake is invalid when Pr.08.02 is set to 0.0.
- Ш Related parameters: Pr.02.02(Stop Method) and Pr.08.03(Start-Point for DC Brake)

08.03	08.03 Start-Point for DC Brake		Unit: 0.01
:	Settings	0.00 to 600.0Hz	Factory Setting: 0.00

Ш This parameter determines the frequency when DC Brake will begin during deceleration.



#### **DC Brake Time**

- DC Brake during Start-up is used for loads that may move before the AC drive starts, such as fans and pumps. Under such circumstances, DC Brake can be used to hold the load in position before setting it in motion.
- DC Brake during stopping is used to shorten the stopping time and also to hold a stopped load in position, such as cranes and cutting machines. For high inertia loads, a brake resistor for dynamic brake may also be needed for fast decelerations. Refer to appendix B for the information of brake resistors.

	ynamic brake may also be needed for fast decelerations. Refer to appendix B for the information of brake resistors.				
08.04	08.04 Momentary Power Loss Operation Selection  Factory Setting: 0				

#### Settings

- Operation stops (coast to stop) after momentary power loss.
- Operation continues after momentary power loss, speed search starts with the Last Frequency.
- 2 Operation continues after momentary power loss, speed search starts with the minimum frequency.
- This parameter determines the operation mode when the AC motor drive restarts from a momentary power loss.
- The power connected to the AC motor drive may be off temporarily with unknown factors. This parameter can restart the drive after momentary power loss.
- Setting 1: the drive will operate by the last frequency before momentary power loss. It will accelerate to the master frequency after the drive output frequency and the motor rotor's speed are synchronous. It is recommended to use this setting for those motor loads which have a large inertia and small resistance to save time by restarting without waiting the flywheel stops completely, such as machinery equipment with a large-inertia flywheel.

Setting 2: the drive will operate by the min. frequency. It will accelerate to the master
frequency after the drive output frequency and motor rotor speed are synchronous. It is
recommended to use this setting for those motor loads which have a small inertia and large
resistance.

- Ш When using with PG card, the speed search will start with the actual motor speed detected by the drive and accelerate to the setting frequency (setting 1 and 2 are invalid at this moment).
- Ш Related parameters: Pr.08.05(Maximum Allowable Power Loss Time), Pr.08.07(Baseblock Time for Speed Search (BB)) and Pr.08.08(Current Limit for Speed Search)


08.05	Maximum A	Allowable Power Loss Time	Unit: 0.1
	Settings	0.1 to 20.0 sec	Factory Setting: 2.0

- Ш If the duration of a power loss is less than this parameter setting, the AC motor drive will act by Pr.08.04 setting. If it exceeds the Maximum Allowable Power Loss Time, the AC motor drive output is then turned off (coast stop).
- The selected operation after power loss in Pr.08.04 is only executed when the maximum allowable power loss time is ≤20 seconds and the AC motor drive displays "Lu". But if the AC motor drive is powered off due to overload, even if the maximum allowable power loss time is ≤20 seconds, the operation mode as set in Pr.08.04 is not executed. In that case it

#### starts up normally. 08.06 Base Block Speed Search Factory Setting: 1 Settings 0 Disable 1 Speed search starts with last frequency 2 Speed search starts with minimum output frequency (Pr.01.05)

- Ш This parameter determines the AC motor drive restart method after External Base Block is enabled(one of Pr.04.05~04.08 is set to 9).
- Ш The speed search actions between Pr.08.04 and Pr.08.06 are the same.
- ш The priority of Pr.08.06 is higher than Pr.08.04. That is, Pr.08.04 will be invalid after Pr.08.06 is set and the speed search will act by Pr.08.06.
- Ш Related parameters: Pr.08.07(Baseblock Time for Speed Search (BB)), Pr.04.05(Multi-function Input Terminal (MI3)), Pr.04.06(Multi-function Input Terminal (MI4)), Pr.04.07(Multi-function Input Terminal (MI5)) and Pr.04.08(Multi-function Input Terminal (MI6))

ш






Fig 2: B.B. Speed Search with Min. Output Frequency Upward Timing Chart


08.07	Baseblock Time for Speed Search (BB)		Unit: 0.1
	Settings	0.1 to 5.0 sec	Factory Setting: 0.5

- When momentary power loss is detected, the AC motor drive will block its output and then wait for a specified period of time (determined by Pr.08.07, called Base-Block Time) before resuming operation. This parameter should be set at a value to ensure that any residual regeneration voltage from the motor on the output has disappeared before the drive is activated again.
- This parameter also determines the waiting time before resuming operation after External Baseblock and Auto Restart after Fault (Pr.08.15).
- When using a PG card with PG (encoder), speed search will begin at the actual PG (encoder) feedback speed.



08.08 Current Limit for Speed Search		t for Speed Search	Unit: 1
	Settings	30 to 200%	Factory Setting: 150

- It limits the drive output current during speed search.
- ш When executing speed search, the V/f curve will be by the setting in the group 01.
- Ш The level of speed search will affect the speed synchronization time. The larger setting is set and the faster it will reach the speed synchronization. But too large setting may cause overload.
- Ш When Pr.08.04 is set to 1: When the speed searches downward, the output frequency starts with the master frequency. The output voltage and output current will be increased from 0. When the output current reaches Pr.08.08 setting, the output frequency continuous searches downward. When the output frequency, output voltage and V/f setting frequency are the same, it will be regarded as the synchronization reached and accelerate to the master frequency by V/f curve.
- When Pr.08.04 is set to 2: When the speed searches upward, it will accelerate by V/f curve.



Momentary Power Loss Operation


08.09	Skip Frequency 1 Upper Limit	Unit: 0.01
08.10	Skip Frequency 1 Lower Limit	Unit: 0.01
08.11	Skip Frequency 2 Upper Limit	Unit: 0.01
08.12	Skip Frequency 2 Lower Limit	Unit: 0.01
08.13	Skip Frequency 3 Upper Limit	Unit: 0.01
08.14	Skip Frequency 3 Lower Limit	Unit: 0.01
	Settings 0.00 to 600.0Hz	Factory Setting: 0.00

 $\omega$ These parameters are used to set the frequencies that are inhibited to operate. This function can be used to prevent the resonance generated from the original frequency of the machines.

#### Chapter 4 Parameters | Value |

It keeps the drive from running at the resonance frequency of machinery or load system or other inhibition frequency. There are three frequency areas can be set.

- These parameters set the Skip Frequencies. It will cause the AC motor drive never to remain within these frequency ranges with continuous frequency output. These six parameters should be set as follows Pr.08.09 ≥ Pr.08.10 ≥ Pr.08.11 ≥ Pr.08.12 ≥ Pr.08.13 ≥ Pr.08.14. When it is set to 0.0, the skip frequency is invalid.
- The frequency command (F) can be set within the range of skip frequency. At this moment, the output frequency (H) will be less than the lower limit of skip frequency.
- When the drive accelerates/decelerates, the output frequency will pass the range of skip frequency.



Unit: 1	tart After Fault	08.15 Auto Resta
Factory Setting: 0	0 to 10	Settings
	0 Disable	

- Only after an over-current OC or over-voltage OV fault occurs, the AC motor drive can be reset/restarted automatically up to 10 times.
- Setting this parameter to 0 will disable automatic reset/restart operation after any fault has occurred.
  - When enabled, the AC motor drive will restart with speed search, which starts at the frequency before the fault. To set the waiting time before restart after a fault, please set Pr. 08.07 Base Block Time for Speed Search.
- When the fault times exceeds Pr.08.15 setting, the drive will refuse to restart and the user needs to press "RESET" for continuous operation.



Related parameter: Pr.08.16 (Auto Reset Time at Restart after Fault)


<b>08.16</b> Au	to Reset Time at Restart after F	Fault Unit: 0.1
Se	ttings 0.1 to 6000 sec	Factory Setting: 60.0

- Ш This parameter is used to set the auto reset time at restart after fault. After restarting for fault, if there is no fault for over Pr.08.16 setting from the restart for the previous fault, the auto reset times for restart after fault will be reset to Pr.08.15 setting..
- Ш This parameter should be used in conjunction with Pr.08.15. For example: If Pr.08.15 is set to 10 and Pr.08.16 is set to 600s (10 min), and if there is no fault for over 600 seconds from the restart for the previous fault, the auto reset times for restart after fault will be reset to 10.
- Related parameter: Pr.08.15(Auto Restart After Fault)

#### 08.17 Automatic Energy-saving

Factory Setting: 0

- n Settinas Energy-saving operation disabled 1 Energy-saving operation enabled
- $\Box$ When Pr.08.17 is set to 1, the acceleration and deceleration will operate with full voltage. During constant speed operation, it will auto calculate the best voltage value by the load power for the load. This function is not suitable for the ever-changing load or near full-load during operation.
- The max, energy saving is in the stable load output. At this moment, the output voltage is almost 70% of the rated voltage.





	40		D 1 (1) (1) (1)					
08	.18 Automatic	Voltage	Regulation (AVR)					
	o			ory Setting: 0				
	Settings	0	AVR function enabled					
		1	AVR function disabled					
		2	AVR function disabled for deceleration  AVR function disabled for stop					
Ω	The rated volta		ne motor is usually 230V/200VAC 50Hz/60Hz and the input	voltage of				
		•	ay vary between 180V to 264 VAC 50Hz/60Hz. Therefore, v	ū				
			thout AVR function, the output voltage will be the same as t					
			tor runs at voltages exceeding the rated voltage with 12% -	•				
	ū		and it can be damaged due to higher temperature, failing in					
	unstable torqu			iodiation and				
ш	•		tically regulates the AC motor drive output voltage to the Ma	ximum				
			.02). For instance, if Pr.01.02 is set at 200 VAC and the inp					
	_	-	nen the Maximum Output Voltage will automatically be redu	=				
	maximum of 200VAC.							
	Setting 0: whe	n AVR	function is enabled, the drive will calculate the output voltag	e by actual				
	DC-bus voltag	e. The	output voltage won't be changed by DC bus voltage.					
	Setting 1: whe	n AVR	function is disabled, the drive will calculate the output voltag	je by DC-bus				
	voltage. The o	utput vo	oltage will be changed by DC bus voltage. It may cause insu	ufficient/over				
	current.							
	Setting 2: the	drive wi	Il disable the AVR during deceleration, such as operated fro	m high speed				
	to low speed.							
	Setting 3: the	drive wi	Il disable the AVR function at stop to accelerate the brake.					
	When the mot	or ramp	s to stop, the deceleration time is longer. When setting this	parameter to				
	2 with auto acc	celeration	on/deceleration, the deceleration will be quicker.					
	Related param	neter: P	r.01.16(Auto acceleration / deceleration (refer to Accel/Dece	el time				
	setting))							
08	Software E			Unit: 0.1				
	(the Action	Level	of the Brake resistor)					

115/230V series: 370.0 to 430.0V

460V series: 740.0 to 860.0V

Settings

Factory Setting: 380.0

Factory Setting: 760.0



- Ш This parameter sets the DC-bus voltage at which the brake chopper is activated. Users can choose the suitable brake resistor to have the best deceleration. Refer to appendix B for the information of the brake resistor.
- Ш This parameter will be invalid for Frame A models (VFD002E11A/21A/23A. VFD004E11A/21A/23A/43A. VFD007E21A/23A/43A and VFD022E23A/43A) without brake chopper for which BUE brake unit must be used.

08.20		ation Coefficient for Motor Instability	Unit: 0.1
	Settings	0.0~5.0	Factory Setting: 0.0

- Ш In V/f control mode, the drift current may cause slight motor vibration in the slip compensation or torque compensation. It can be ignored if this slight vibration doesn't affect the application.
- Ш The drift current will occur in a specific zone of the motor and it will cause serious motor vibration. It is recommended to use this parameter (the recommended value is 2.0) to improve this situation greatly.
- Ш The drift current zone of the high-power motors is usually in the low frequency area.
- Ш It is recommended to set to more than 2.0.

08.21	OOB Sam	pling Time	Unit: 0.1
•	Settings	0.1 to 120.0 sec	Factory Setting: 1.0
08.22	Number of	OOB Sampling Times	Unit: 1
	Settings	0.00 to 32	Factory Setting: 20
08.23	OOB Aver	age Sampling Angle	
	Settings	Read-only	Factory Setting: #.#

- Ш The OOB (Out Of Balance Detection) function can be used with PLC for washing machine. When multi-function input terminal is enabled (MI=26), it will get  $\Delta\theta$  value from the settings of Pr.08.21 and Pr.08.22. PLC or the host controller will decide the motor speed by this t Δθ value (Pr.08.23). When  $\Delta\theta$  value is large, it means unbalanced load. At this moment, it needs to lower the frequency command by PLC or the host controller. On the other hand, it can be high-speed operation.
- Ш Related parameters: Pr.04.05(Multi-function Input Terminal (MI3)), 04.06(Multi-function Input Terminal (MI4)), Pr.04.07(Multi-function Input Terminal (MI5)) and Pr.04.08(Multi-function Input Terminal (MI6))


#### 08.24 DEB Function

Factory Setting: 0

Settings	0	Disable
	1	Fnable

08.2	DEB Retur	n Time	Unit: 1
	Settings	0~250 sec	Factory Setting: 0


- The DEB (Deceleration Energy Backup) function is the AC motor drive decelerates to stop after momentary power loss. When the momentary power loss occurs, this function can be used for the motor to decelerate to 0 speed with deceleration stop method. When the power is on again, motor will run again after DEB return time. (for high-speed axis application)
- Related parameter: Pr.08.04(Momentary Power Loss Operation Selection)
- Status 1: Insufficient power supply due to momentary power-loss/unstable power (due to low voltage)/sudden heavy-load



NOTE

When Pr.08.24 is set to 0, the AC motor drive will be stopped and won't re-start at the power-on again.


#### Status 2: unexpected power off, such as momentary power loss



#### Chapter 4 Parameters | Value

#### Group 9: Communication Parameters

There is a built-in RS-485 serial interface, marked RJ-45 near to the control terminals. The pins are defined below:



The pins definition for VFD\*E\*C models, please refer to chapter E.1.2.

Each VFD-E AC motor drive has a pre-assigned communication address specified by Pr.09.00. The RS485 master then controls each AC motor drive according to its communication address.

09.00		ation Address	
	Settings	1 to 254	Factory Setting: 1

If the AC motor drive is controlled by RS-485 serial communication, the communication address for this drive must be set via this parameter. And the communication address for each AC motor drive must be different and unique.

09.	.01 // Transmi								
				Factory Setting: 1					
	Settings	0	Baud rate 4800 bps (bits / second)						
		1	Baud rate 9600 bps						
		2	Baud rate 19200 bps						
		3	Baud rate 38400 bps						
Ω.	This paramete	r is use	d to set the transmission speed between the RS4	R5 master (PLC, PC					

This parameter is used to set the transmission speed between the RS485 master (PLC, PC, etc.) and AC motor drive.

09.02								
				Factory Setting: 3				
	Settings	0	Warn and keep operating					
		1	Warn and RAMP to stop					
		2	Warn and COAST to stop					
		3	No warning and keep operating					

 $\hfill \Box$  This parameter is set to how to react if transmission errors occur.

- Setting 0: when transmission errors occur, it will display warning message "cEXX" on the digital keypad and the motor will keep running. The warning message can be cleared after the communication is normal.
- Setting 1: when transmission errors occur, it will display warning message "cEXX" on the digital keypad and the motor will stop by the deceleration time (Pr.01.10/01.12). It needs to press "RESET" to clear the warning message.
- Setting 2: When transmission errors occur, it will display warning message "cEXX" on the digital keypad and the motor will free run to stop immediately. It needs to press "RESET" to clear the warning message.
- Setting 3: When transmission errors occur, it won't display any warning message on the digital keypad and the motor will still keep running.
- See list of error messages below (see section 3.6 in Pr.09.04)



The digital keypad is optional. Please refer to Appendix B for details. When using without this optional keypad, the FAULT LED will be ON once there is error messages or warning messages from the external terminals.

UĐ.	.03			OIII. 0.1
	Settings	0.0 t	o 120.0 sec	Factory Setting: 0.0
		0.0	Disable	
Ш	If Pr.09.03 is n	ot equa	I to 0.0, Pr.09.02=0~2, and there is no commun	nication on the bus during
	the Time Out of	detection	n period (set by Pr.09.03), "cE10" will be shown	on the keypad.
09.	.04	nication	Protocol	
				Factory Setting: 0
	Settings	0	Modbus ASCII mode, protocol <7,N,2>	
		1	Modbus ASCII mode, protocol <7,E,1>	
		2	Modbus ASCII mode, protocol <7,0,1>	
		3	Modbus RTU mode, protocol <8,N,2>	
		4	Modbus RTU mode, protocol <8,E,1>	
		5	Modbus RTU mode, protocol <8,0,1>	

Linit∙ ∩ 1

- Chapter 4 Parameters | Variation
  - 6 Modbus RTU mode, protocol <8,N,1>
  - 7 Modbus RTU mode, protocol <8,E,2>
  - 8 Modbus RTU mode, protocol <8,0,2>
  - 9 Modbus ASCII mode, protocol <7,N,1>
  - 10 Modbus ASCII mode, protocol <7.E.2>
  - 11 Modbus ASCII mode, protocol <7,0,2>

#### $\square$ 1. Control by PC or PLC

★A VFD-E can be set up to communicate in Modbus networks using one of the following modes: ASCII (American Standard Code for Information Interchange) or RTU (Remote Terminal Unit). Users can select the desired mode along with the serial port communication protocol in Pr.09.04.

#### **★**Code Description:

The CPU will be about 1 second delay when using communication reset. Therefore, there is at least 1 second delay time in master station.

#### ASCII mode:

Each 8-bit data is the combination of two ASCII characters. For example, a 1-byte data:

64 Hex, shown as '64' in ASCII, consists of '6' (36Hex) and '4' (34Hex).

Chara	acter 'C	' '1'	'2'	'3'	'4'	'5'	'6'	'7'
ASCII	code 30	H 31l	1 32H	33H	34H	35H	36H	37H

Character	'8'	·9	'A'	'B'	,C,	'D'	'E'	'F'
ASCII code	38H	39H	41H	42H	43H	44H	45H	46H

#### RTU mode:


Each 8-bit data is the combination of two 4-bit hexadecimal characters. For example, 64 Hex

#### Ш 2 Data Format


10-bit character frame (For ASCII):

— 7-bit character — 11-bit character frame parity bit

bit



bit



#### 3. Communication Protocol

3.1 Communication Data Frame:

#### **ASCII mode:**

STX	Start character ':' (3AH)
Address Hi	Communication address:
Address Lo	8-bit address consists of 2 ASCII codes
Function Hi	Command code:
Function Lo	8-bit command consists of 2 ASCII codes
DATA (n-1)	Contents of data:
to	Nx8-bit data consist of 2n ASCII codes
DATA 0	n<=20, maximum of 40 ASCII codes

LRC CHK Hi	LRC check sum:
LRC CHK Lo	8-bit check sum consists of 2 ASCII codes
END Hi	End characters:
END Lo	END1= CR (0DH), END0= LF(0AH)

#### RTU mode:

START	A silent interval of more than 10 ms	
Address	Communication address: 8-bit address	
Function	Command code: 8-bit command	
DATA (n-1) to DATA 0	Contents of data: n×8-bit data, n<=40 (20 x 16-bit data)	
CRC CHK Low	CRC check sum:	
CRC CHK High	16-bit check sum consists of 2 8-bit characters	
END	A silent interval of more than 10 ms	

#### 3.2 Address (Communication Address)

Valid communication addresses are in the range of 0 to 254. A communication address equal to 0, means broadcast to all AC drives (AMD). In this case, the AMD will not reply any message to the master device.

00H: broadcast to all AC drives

01H: AC drive of address 01 0FH: AC drive of address 15

10H: AC drive of address 16

:

FEH: AC drive of address 254

For example, communication to AMD with address 16 decimal (10H):

ASCII mode: Address='1','0' => '1'=31H, '0'=30H

RTU mode: Address=10H

3.3 Function (Function code) and DATA (data characters)

The format of data characters depends on the function code.

03H: read data from register 06H: write single register

08H: loop detection

10H: write multiple registers

The available function codes and examples for VFD-E are described as follows:

(1) 03H: multi read, read data from registers.

Example: reading continuous 2 data from register address 2102H, AMD address is 01H. ASCII mode:

#### Command message:

Command message.			
STX	·.·		
Address	'0'		
Address	'1'		
	'0'		
Function	'3'		
	'2'		
Starting data	'1'		
address	·0'		
	'2'		
	·0'		
Number of data	·0'		
(count by word)	'0'		
	'2'		
LRC Check	,D,		
LIVO OHECK	'7'		
END	CR		
LIND	LF		

#### Response message:

STX '.'  Address '0'		
Address '1'  Function '0'  Number of data (Count by byte) '4'  Content of starting address 2102H '7'  Content of address 2103H '0'  LRC Check '1'  COR	STX	٠.,
Function '0'  Function '0'  Number of data (Count by byte) '4'  Content of starting address 2102H '0'  Content of address 2103H '0'  LRC Check '7'  COP	Addross	'0'
Function '3'  Number of data (Count by byte) '4'  Content of starting address 2102H '0'  Content of address 2103H '0'  LRC Check '7'  COP	Address	'1'
Number of data (Count by byte) '4'  Content of starting address 2102H '0'  Content of address 2103H '0'  LRC Check '1'  COR	- "	'0'
(Count by byte)  Content of starting address 2102H  Content of address 2103H  Content of address	Function	'3'
Content of starting address 2102H '7'  Content of address 2103H '0'  LRC Check '7'  LRC Check '7'  CORD	Number of data	'0'
Content of starting address 2102H '7'  Content of address 2103H '0'  LRC Check '7'  COP	(Count by byte)	<b>'4'</b>
address 2102H 7 '7' 2102H '7' '0' Content of address 2103H '0' LRC Check '1' CP	Contant of starting	'1'
2102H '7' '0' '0' Content of address 2103H '0' LRC Check '7'  CP		'7'
Content of address 2103H '0'  LRC Check '7'  COP		'7'
Content of address 2103H '0' '0'  LRC Check '1' '1'	210211	'0'
2103H '0' '0' LRC Check '7' '1'		'0'
10' LRC Check 7' '1' CR	Content of address	'0'
LRC Check '7'	2103H	΄Ο'
LRC Check '1'		΄Ο'
.1 <sup>'</sup>	LPC Chock	'7'
END CR LF	LING CHECK	'1'
LF LF	END	CR
	LIND	LF

#### RTU mode:

#### Command message:

Address	01H
Function	03H
Starting data	21H
address	02H
Number of data	00H
(count by word)	02H
CRC CHK Low	6FH
CRC CHK High	F7H

#### Pasnonse message

Response message:			
Address	01H		
Function	03H		
Number of data	04H		
(count by byte)			
Content of address	17H		
2102H	70H		
Content of address	00H		
2103H	00H		
CRC CHK Low	FEH		
CRC CHK High	5CH		

(2) 06H: single write, write single data to register.

Example: writing data 6000(1770 H) to register 0100H. AMD address is 01H.

#### ASCII mode:

#### Command message:

STX	٠.,
Address	·0'
Addiess	'1'
Function	'0'
1 unction	'6'

#### Response message:

STX	.,
Address	'0'
Audiess	'1'
Function	'0'
i unction	'6'

#### Command message:

Data address	'0'
	'1'
	'0'
	'0'
Data content	'1'
	'7'
	'7'
	'0'
LRC Check	'7'
	'1'
END	CR
	LF

#### Chapter 4 Parameters | V Response message:

· · · · · · · · · · · · · · · · · · ·	
Data address	'0'
	'1'
	·0'
	'0'
Data content	'1'
	'7'
	'7'
	'0'
LRC Check	'7'
	'1'
END	CR
	LF

#### RTU mode:

#### Command message:

Address	01H
Function	06H
Data address	01H
Data address	00H
Data content	17H
	70H
CRC CHK Low	EEH
CRC CHK High	1FH

#### Response message:

01H
UIII
06H
01H
00H
17H
70H
EEH
1FH

#### (3) 08H: loop detection

This command is used to detect if the communication between master device (PC or PLC) and AC motor drive is normal. The AC motor drive will send the received message to the master device.

#### ASCII mode:

#### Command message:

STX	٠.,
Address	'0'
	'1'
Function	'0'
Function	'8'
	'0'
Data address	'0'
	'0'
	'0'
Data content	'1'
	'7'
	'7'
	'0'
LRC Check	'7'
	'0'
END	CR
	LF

Response message:	
STX	
Address	'0'
Address	'1'
Function	'0'
1 diletion	'8'
	·0'
Data address	'0'
Data addiess	'0'
	'0'
	'1'
Data content	'7'
Data Content	'7'
	'0'
LRC Check	'7'
	'0'
END	CR
	LF



#### RTU mode:

#### Command message:

Address	01H
Function	H80
Data address	00H
Data address	00H
Data content	17H
Data content	70H
CRC CHK Low	EEH
CRC CHK High	1FH

#### Response message:

· -	
Address	01H
Function	08H
Data address	00H
Data address	00H
Data content	17H
Data Content	70H
CRC CHK Low	EEH
CRC CHK High	1FH

(4) 10H: write multiple registers (write multiple data to registers)

Example: Set the multi-step speed,

Pr.05.00=50.00 (1388H), Pr.05.01=40.00 (0FA0H). AC drive address is 01H.

ASCII Mode:

Command message:

STX	4.7
Address 1	'0'
Address 0	'1'
Function 1	'1'
Function 0	'0'
	'0'
Starting data	'5'
address	'0'
	'0'
	'0'
Number of data	'0'
(count by word)	'0'
	'2'
Number of data	'0'
(count by byte)	'4'
The first data	'1'
	'3'
content	'8'
	'8'
	'0'
The second data content	'F'
	'A'
	'0'
LRC Check	'9'
LING GIRCK	'A'
END	CR

Response message:	
STX	٠.,
Address 1	'0'
Address 0	'1'
Function 1	'1'
Function 0	ΰ,
	'0'
Starting data	<b>'</b> 5'
address	ΰ,
	'0'
	'0'
Number of data	'0'
(count by word)	'0'
	'2'
LRC Check	'Ε'
	'8'
END	CR
	LF

#### Command message: LF

#### RTU mode:

Command message:

Address	01H
Function	10H
Starting data	05H
address	00H
Number of data	00H'
(count by word)	02H
Number of data	04
(count by byte)	
The first data	13H
content	88H
The second data	0FH
content	A0H
CRC Check Low	4DH
CRC Check High	D9H

Response message:

. tooponee meesage.	
Address	01H
Function	10H
Starting data address	05H
	00H
Number of data	00H
(count by word)	02H
CRC Check Low	41H
CRC Check High	04H

#### 3.4 Check sum

#### ASCII mode:

LRC (Longitudinal Redundancy Check) is calculated by summing up, module 256, the values of the bytes from ADR1 to last data character then calculating the hexadecimal representation of the 2's-complement negation of the sum.

For example, reading 1 word from address 0401H of the AC drive with address 01H.

STX	"."
Address 1	'0'
Address 0	'1'
Function 1	'0'
Function 0	'3'
	'0'
Starting data address	'4'
Starting data address	'0'
	'1'
	'0'
Number of data	'0'
Number of data	'0'
	'1'
LRC Check 1	'F'
LRC Check 0	'6'
END 1	CR
END 0	LF

01H+03H+04H+01H+00H+01H=0AH, the 2's-complement negation of 0AH is F6H.

RTU mode:

Address	01H
---------	-----



Function	03H
Starting data address	21H
	02H
Number of data	00H
(count by word)	02H
CRC CHK Low	6FH
CRC CHK High	F7H

CRC (Cyclical Redundancy Check) is calculated by the following steps:

Step 1: Load a 16-bit register (called CRC register) with FFFFH.

Step 2: Exclusive OR the first 8-bit byte of the command message with the low order byte of the 16-bit CRC register, putting the result in the CRC register.

Step 3: Examine the LSB of CRC register.

Step 4: If the LSB of CRC register is 0, shift the CRC register one bit to the right with MSB zero filling, then repeat step 3. If the LSB of CRC register is 1, shift the CRC register one bit to the right with MSB zero filling, Exclusive OR the CRC register with the polynomial value A001H, then repeat step 3.

Step 5: Repeat step 3 and 4 until eight shifts have been performed. When this is done, a complete 8-bit byte will have been processed.

Step 6: Repeat step 2 to 5 for the next 8-bit byte of the command message. Continue doing this until all bytes have been processed. The final contents of the CRC register are the CRC value. When transmitting the CRC value in the message, the upper and lower bytes of the CRC value must be swapped, i.e. the lower order byte will be transmitted first.

The following is an example of CRC generation using C language. The function takes two arguments:

Unsigned char\* data ← a pointer to the message buffer

Unsigned char length ← the quantity of bytes in the message buffer

The function returns the CRC value as a type of unsigned integer.

Unsigned int crc chk(unsigned char\* data, unsigned char length){

```
int j;
unsigned int reg_crc=0xFFFF;
while(length--){
 reg crc ^= *data++;
 for(j=0;j<8;j++){
  if(reg_crc & 0x01){ /* LSB(b0)=1 */
   reg crc=(reg crc>>1) ^ 0xA001;
```



```
}else{
    reg_crc=reg_crc >>1;
   }
  }
}
return reg crc;
}
```

#### 3.5 Address list

The contents of available addresses are shown as below:

Content	Address		Function	
AC drive Parameters	GGnnH	GG means parameter group, nn means parameter number, for example, the address of Pr 04.01 is 0401H. Refer to chapter 5 for the function of each parameter. When reading parameter by command code 03H, only one parameter can be read at one time.		
		Bit 0-1	00B: No function 01B: Stop 10B: Run 11B: Jog + Run	
		Bit 2-3	Reserved	
Command Write only	2000H	Bit 4-5	00B: No function 01B: FWD 10B: REV 11B: Change direction	
		Bit 6-7	00B: Comm. forced 1st accel/decel 01B: Comm. forced 2nd accel/decel	
		Bit 8-15	Reserved	
	2001H	Frequency command		
		Bit 0	1: EF (external fault) on	
	2002H	Bit 1	1: Reset	
		Bit 2-15	Reserved	
Status		Error code:		
monitor	2100H	0: No error occurred		
Read only		1: Over-current (oc)		



Content	Address	Function
		2: Over-voltage (ov)
		3: IGBT Overheat (oH1)
		4: Power Board Overheat (oH2)
		5: Overload (oL)
		6: Overload1 (oL1)
		7: Overload2 (oL2)
		8: External fault (EF)
	9: Current exceeds 2 times rated current during accel (ocA)	
		10: Current exceeds 2 times rated current during decel (ocd) Current exceeds 2 times rated current during decel (ocd)
		11: Current exceeds 2 times rated current during steady state operation (ocn)
		12: Ground Fault (GFF)
		13: Low voltage (Lv)
		14: PHL (Phase-Loss)
	2100H	15: Base Block
		16: Auto accel/decel failure (cFA)
		17: Software protection enabled (codE)
		18: Power Board CPU WRITE failure (CF1.0)
		19: Power Board CPU READ failure (CF2.0)
		20: CC, OC Hardware protection failure (HPF1)
		21: OV Hardware protection failure (HPF2)
		22: GFF Hardware protection failure (HPF3)
		23: OC Hardware protection failure (HPF4)
		24: U-phase error (cF3.0)
		25: V-phase error (cF3.1)
		26: W-phase error (cF3.2)
		27: DCBUS error (cF3.3)
		28: IGBT Overheat (cF3.4)
		29: Power Board Overheat (cF3.5)
		30: Control Board CPU WRITE failure (cF1.1)

	1		Chapter 4 Parameters		
Content	Address	Function			
		31: Control Board CPU WRITE failure (cF2.1)			
		32: ACI signal error (AErr)			
		33: Reserved			
		34: Motor	PTC overheat protection (PtC1)		
		35~39: Reserved			
			nunication time-out error of control board and power d (CP10)		
		41: dEb er	ror		
		42: ACL (A	Abnormal Communication Loop)		
		Status of A	AC drive		
			00B: RUN LED is off, STOP LED is on (The AC motor Drive stops)		
		Dit 0 1	01B: RUN LED blinks, STOP LED is on (When AC motor drive decelerates to stop)		
	Bit 2	Bit 0-1	10B: RUN LED is on, STOP LED blinks (When AC motor drive is standby)		
			11B: RUN LED is on, STOP LED is off (When AC motor drive runs)		
		Bit 2	1: JOG command		
2		Bit 3-4	00B: FWD LED is on, REV LED is off (When AC motor drive runs forward)		
			01B: FWD LED is on, REV LED blinks (When AC motor drive runs from reverse to forward)		
			10B: FWD LED blinks, REV LED is on (When AC motor drive runs from forward to reverse)		
			11B: FWD LED is off, REV LED is on (When AC motor drive runs reverse)		
		Bit 5-7	Reserved		
		Bit 8 1: Master frequency Controlled by communinterface			
		Bit 9	1: Master frequency controlled by analog signal		
		Bit 10	Operation command controlled by communication interface		
		Bit 11-15	Reserved		
	2102H	Frequency	command (F)		

Content	Address	Function
	2103H	Output frequency (H)
	2104H	Output current (AXXX.X)
	2105H	Reserved
	2106H	Reserved
	2107H	Reserved
	2108H	DC-BUS Voltage (UXXX.X)
	2109H	Output voltage (EXXX.X)
	210AH	Display temperature of IGBT (°C)
	2116H	User defined (Low word)
	2117H	User defined (High word)

Note: 2116H is number display of Pr.00.04. High byte of 2117H is number of decimal places of 2116H. Low byte of 2117H is ASCII code of alphabet display of Pr.00.04.

#### 3.6 Exception response:

The AC motor drive is expected to return a normal response after receiving command messages from the master device. The following depicts the conditions when no normal response is replied to the master device.

The AC motor drive does not receive the messages due to a communication error; thus, the AC motor drive has no response. The master device will eventually process a timeout condition.

The AC motor drive receives the messages without a communication error, but cannot handle them. An exception response will be returned to the master device and an error message "CExx" will be displayed on the keypad of AC motor drive. The xx of "CExx" is a decimal code equal to the exception code that is described below.

In the exception response, the most significant bit of the original command code is set to 1, and an exception code which explains the condition that caused the exception is returned.

Example of an exception response of command code 06H and exception code 02H:

#### ASCII mode:

STX	.,,
Address Low	'0'
Address High	'1'
Function Low	'8'

#### RTU mode:

Address	01H
Function	86H
Exception code	02H
CRC CHK Low	СЗН

Function High	'6'
Exception code	'0'
Exception code	'2'
LRC CHK Low	'7'
LRC CHK High	'7'
END 1	CR
END 0	LF

Chapter 4 Para	ameters   V=224	Į.
CRC CHK High	A1H	

### The explanation of exception codes:

Exception code	Explanation
01	Illegal function code: The function code received in the command message is not available for the AC motor drive.
02	Illegal data address: The data address received in the command message is not available for the AC motor drive.
03	Illegal data value: The data value received in the command message is not available for the AC drive.
04	Slave device failure: The AC motor drive is unable to perform the requested action.
10	Communication time-out:  If Pr.09.03 is not equal to 0.0, Pr.09.02=0~2, and there is no communication on the bus during the Time Out detection period (set by Pr.09.03), "cE10" will be shown on the keypad.

### 3.7 Communication program of PC:

The following is a simple example of how to write a communication program for Modbus ASCII mode on a PC in C language.

#include<stdio.h>

#include<dos.h>

#include<conio.h>

#include<process.h>

#define PORT 0x03F8 /\* the address of COM1 \*/

/\* the address offset value relative to COM1 \*/

#define THR 0x0000

```
Chapter 4 Parameters | V
        #define RDR 0x0000
        #define BRDL 0x0000
        #define IFR 0x0001
        #define BRDH 0x0001
        #define LCR_0x0003
        #define MCR 0x0004
        #define LSR 0x0005
        #define MSR 0x0006
        unsigned char rdat[60]:
        /* read 2 data from address 2102H of AC drive with address 1 */
        unsigned char tdat[60]={':','0','1','0','3','2','1','0','2', '0','0','2','D','7','\r',\n'};
        void main(){
        int i
        outportb(PORT+MCR,0x08); /* interrupt enable */
        outportb(PORT+IER,0x01); /* interrupt as data in */
        outportb(PORT+LCR,(inportb(PORT+LCR) | 0x80));
        /* the BRDL/BRDH can be access as LCR.b7==1 */
        outportb(PORT+BRDL.12):
                                      /* set baudrate=9600. 12=115200/9600*/
        outportb(PORT+BRDH.0x00):
        outportb(PORT+LCR.0x06):
                                    /* set protocol. <7.N.2>=06H. <7.E.1>=1AH.
        <7.O.1>=0AH. <8.N.2>=07H. <8.E.1>=1BH. <8.O.1>=0BH */
        for(i=0:i<=16:i++){
        while(!(inportb(PORT+LSR) & 0x20)): /* wait until THR empty */
        outportb(PORT+THR.tdat[i]): /* send data to THR */ }
        i=0:
        while(!kbhit()){
        if(inportb(PORT+LSR) & 0x01){ /* b0==1, read data ready */
        rdat[i++]=inportb(PORT+RDR); /* read data form RDR */
        } } }
         Reserved
 09.05
 09.06
         Reserved
 09.07
         Unit: 2ms
         Settings
                      0 ~ 200 (400msec)
                                                                          Factory Setting: 1
```

This parameter is the response delay time after AC drive receives communication command as shown in the following. 1 unit = 2 msec.



09.08 Transmission Speed for USB Card

Factory Setting: 2

- Settings 0 Baud rate 4800 bps 1 Baud rate 9600 bps 2 Baud rate 19200 bps 3 Baud rate 38400 bps 4 Baud rate 57600 bps
- $\Box$ This parameter is used to set the transmission speed for USB card.

#### 09.09 ✓ Communication Protocol for USB Card

			Factory Setting: 1
Settings	0	Modbus ASCII mode, protocol <7,N,2>	
	1	Modbus ASCII mode, protocol <7,E,1>	
	2	Modbus ASCII mode, protocol <7,O,1>	
	3	Modbus RTU mode, protocol <8,N,2>	
	4	Modbus RTU mode, protocol <8,E,1>	
	5	Modbus RTU mode, protocol <8,0,1>	
	6	Modbus RTU mode, protocol <8,N,1>	
	7	Modbus RTU mode, protocol <8,E,2>	
	8	Modbus RTU mode, protocol <8,0,2>	
	9	Modbus ASCII mode, protocol <7,N,1>	
	10	Modbus ASCII mode, protocol <7,E,2>	
	11	Modbus ASCII mode, protocol <7,0,2>	

#### 09.10 Factory Setting: 0 Settings 0 Warn and keep operating 1 Warn and RAMP to stop 2 Warn and COAST to stop 3 No warning and keep operating

## Chapter 4 Parameters | Variation This parameter is set to how to react when transmission errors occurs. $\Box$ Setting 0: when transmission errors occur, it will display warning message "cEXX" on the digital keypad and the motor will keep running. The warning message can be cleared after the communication is normal. Ш Setting 1: when transmission errors occur, it will display warning message "cEXX" on the digital keypad and the motor will stop by the deceleration time (Pr.01.10/01.12). It needs to press "RESET" to clear the warning message. Ш Setting 2: When transmission errors occur, it will display warning message "cEXX" on the digital keypad and the motor will free run to stop immediately. It needs to press "RESET" to clear the warning message. $\Box$ Setting 3: When transmission errors occur, it won't display any warning message on the digital

## NOTE

Ш

keypad and the motor will still keep running.

See list of error messages below (see section 3.6 in Pr.09.04)

The digital keypad is optional. Please refer to Appendix B for details. When using without this optional keypad, the FAULT LED will be ON once there is error messages or warning messages from the external terminals.

09.11		Unit: 0.1		
	Settings	0.0 to	o 120.0 sec	Factory Setting: 0.0
		0.0	Disable	
	_			
09.12	COM port f	or PLC	Communication (NOT for VFD*E*C models)	_
				Factory Setting: 0
	Settings	0	RS485	
		1	USB card	




#### Group 10: PID Control

- A. Common applications for PID control
- 1. Flow control: A flow sensor is used to feedback the flow data and perform accurate flow control.
- 2. Pressure control: A pressure sensor is used to feedback the pressure data and perform precise pressure control.
- 3. Air volume control: An air volume sensor is used to feedback the air volume data to have excellent air volume regulation.
- 4. Temperature control: A thermocouple or thermistor is used to feedback temperature data for comfortable temperature control.
- 5. Speed control: A speed sensor or encoder is used to feedback motor shaft speed or input another machines speed as a target value for closed loop speed control of master-slave operation.

Pr.10.00 sets the PID setpoint source (target value). PID control operates with the feedback signal as set by Pr.10.01 either 0~+10V voltage or 4-20mA current.

#### B. PID control loop:




 $K_n$ : Proportional gain(P)  $T_i$ : Integral time(I)  $T_d$ : Derivative control(D) S: Operator

- C. Concept of PID control
- 1. Proportional gain(P): the output is proportional to input. With only proportional gain control, there will always be a steady-state error.
- 2. Integral time(I): the controller output is proportional to the integral of the controller input. To eliminate the steady-state error, an "integral part" needs to be added to the controller. The integral time decides the relation between integral part and error. The integral part will be increased by time even if the error is small. It gradually increases the controller output to eliminate the error until it is 0. In this way a system can be stable without steady-state error by proportional gain control and integral time control

#### Chapter 4 Parameters | Value |

- 3. Differential control(D): the controller output is proportional to the differential of the controller input. During elimination of the error, oscillation or instability may occur. The differential control can be used to suppress these effects by acting before the error. That is, when the error is near 0, the differential control should be 0. Proportional gain(P) + differential control(D) can be used to improve the system state during PID adjustment.
- D. When PID control is used in a constant pressure pump feedback application:

Set the application's constant pressure value (bar) to be the setpoint of PID control. The pressure sensor will send the actual value as PID feedback value. After comparing the PID setpoint and PID feedback, there will be an error. Thus, the PID controller needs to calculate the output by using proportional gain(P), integral time(I) and differential time(D) to control the pump. It controls the drive to have different pump speed and achieves constant pressure control by using a 4-20mA signal corresponding to 0-10 bar as feedback to the drive.



- 1. Pr.00.04 is set to 5 (Display PID analog feedback signal value (b) (%))
- 2. Pr.01.09 Acceleration Time will be set as required



- 3. Pr.01.10 Deceleration Time will be set as required
- 4. Pr.02.01=1 to operate from the digital keypad
- 5. Pr.10.00=1, the setpoint is controlled by the digital keypad
- 6. Pr.10.01=3(Negative PID feedback from external terminal ACI (4 ~ 20mA)/ AVI2 (0 ~ +10VDC))
- 7. Pr.10.01-10.17 will be set as required
- 7.1 When there is no vibration in the system, increase Pr.10.02(Proportional Gain (P))
- 7.2 When there is no vibration in the system, reduce Pr.10.03(Integral Time (I))
- 7.3 When there is no vibration in the system, increase Pr.10.04(Differential Time(D))
- 8. Refer to Pr.10.00-10.17 for PID parameters settings.

10.00	PID Set Point Selection			
				Factory Setting: 0
	Settings	0	Disable	
		1	Digital keypad UP/DOWN keys	
		2	AVI 0~+10VDC	
		3	ACI 4 ~ 20mA / AVI2 0 ~ +10VDC	
		4	PID set point (Pr.10.11)	

10.01	Input Terminal for PID Feedback		
			Factory Setting: 0
	Settings	0	<b>Positive</b> PID feedback from external terminal AVI (0 ~ +10VDC).
		1	Negative PID feedback from external terminal AVI (0 ~ +10VDC).
		2	Positive PID feedback from external terminal ACI (4 $\sim$ 20mA)/ AVI2 (0 $\sim$ +10VDC).
		3	<b>Negative</b> PID feedback from external terminal ACI (4 $\sim$ 20mA)/ AVI2 (0 $\sim$ +10VDC).

- ш Note that the measured variable (feedback) controls the output frequency (Hz).
- Ш When Pr.10.00=2 or 3, the set point (Master Frequency) for PID control is obtained from the AVI or ACI/AVI2 external terminal (0 to +10V or 4-20mA) or from multi-step speed. When Pr.10.00=1, the set point is obtained from the keypad.
- Ш When Pr.10.01=1 or 3 (Negative feedback): Error (Err) = setpoin(SP) - feedback(FB). When the feedback will be increased by the increasing output frequency, please use this setting.

#### Chapter 4 Parameters | Variation

- When Pr.10.01= to 0 or 2 (Positive feedback): Error (Err) =feedback(FB)- setpoint(SP) When the feedback will be decreased by the increasing output frequency, please use this setting.
- Select input terminal accordingly. Make sure this parameter setting does not conflict with the setting for Pr.10.00 (Master Frequency).
- Related parameters: Pr.00.04 Content of Multi-function Display (set to 5 Display PID analog feedback signal value (b) (%)), Pr. 10.11(Source of PID Set point) and Pr.04.19(ACI/AVI2 Selection)

# Value <t

This parameter is used in conjunction with Pr.10.00 set 4 to input a set point in Hz.

## # Proportional Gain (P) Unit: 0. 1 Settings 0.0 to 10.0 Factory Setting: 1.0

- It is used to eliminate the system error. It is usually used to decrease the error and get the faster response speed. But if setting too large value in Pr.10.02, it may cause the system oscillation and instability.
- It can be used to set the proportional gain to decide the responds speed. The larger value is set in Pr.10.02, the faster response it will get. The smaller value is set in Pr.10.02, the slower response it will get.
- If the other two gains (I and D) are set to zero, proportional control is the only one effective.
- Related parameters: Pr.10.03(Integral Time (I)) and Pr.10.04(Differential Control (D))

10	0.03 ✓ Integral	Time (I)	Unit: 0.01
	Settings	0.00 to 100.0 sec	Factory Setting: 1.00
		0.00 Disable	

- The integral controller is used to eliminate the error during stable system. The integral control doesn't stop working until error is 0. The integral is acted by the integral time. The smaller integral time is set, the stronger integral action will be. It is helpful to reduce overshoot and oscillation to make a stable system. At this moment, the decreasing error will be slow. The integral control is often used with other two controls to become PI controller or PID controller.
- This parameter is used to set the integral time of I controller. When the integral time is long, it will have small gain of I controller, the slower response and bad external control. When the

integral time is short, it will have large gain of I controller, the faster response and rapid external control

- When the integral time is too small, it may cause system oscillation.
- When it is set to 0.0, the integral function is disabled.
- Related parameter: Pr.10.05(Upper Bound for Integral Control)

10.04	✓ Differentia	al Control (D)	Unit: 0.01
	Settings	0.00 to 1.00 sec	Factory Setting: 0.00

The differential controller is used to show the change of system error and it is helpful to preview the change of error. So the differential controller can be used to eliminate the error to improve system state. With the suitable differential time, it can reduce overshoot and shorten adjustment time. However, the differential operation will increase the noise interference. Please note that too large differential will cause big noise interference. Besides, the differential shows the change and the output of the differential will be 0 when there is no change.

Therefore, the differential control can't be used independently. It needs to be used with other two controllers to make a PD controller or PID controller.


- This parameter can be used to set the gain of D controller to decide the response of error change. The suitable differential time can reduce the overshoot of P and I controller to decrease the oscillation and have a stable system. But too long differential time may cause system oscillation.
- The differential controller acts for the change of error and can't reduce the interference. It is not recommended to use this function in the serious interference.

10.05	Upper Bou	nd for Integral Control	Unit: 1
	Settings	0 to 100 %	Factory Setting: 100

- This parameter defines an upper bound or limit for the integral gain (I) and therefore limits the Master Frequency. The formula is: Integral upper bound = Maximum Output Frequency (Pr.01.00) x (Pr.10.05).
- Too large integral value will make the slow response due to sudden load change. In this way, it may cause motor stall or machine damage.
- Related parameter: Pr.01.00(Maximum Output Frequency (Fmax))

10.06	Primary De	elay Filter Time	Unit: 0.1
	Settings	0.0 to 2.5 sec	Factory Setting: 0.0

- It is used to set the time that required for the low-pass filter of PID output. Increasing the setting, it may affect the drive's response speed.
- The frequency output of PID controller will filter after primary delay filter time. It can smooth the change of the frequency output. The longer primary delay filter time is set, the slower response time it will be.
- $\ \square$  The unsuitable primary delay filter time may cause system oscillation.
- PID control can be used for speed, pressure and flow control. It needs to use with the relevant equipment of sensor feedback for PID control. Refer to the following for the closed-loop control diagram.



10.07	PID Outpu	t Frequency Limit	Unit: 1
	Settings	0 to 110 %	Factory Setting: 100

- This parameter defines the percentage of output frequency limit during the PID control. The formula is Output Frequency Limit = Maximum Output Frequency (Pr.01.00) X Pr.10.07 %. This parameter will limit the Maximum Output Frequency. An overall limit for the output frequency can be set in Pr.01.07.
- Related parameter: Pr.01.00(Maximum Output Frequency (Fmax))

10.08	PID Feedba	ck Signal Detection Time	Unit: 0.1
	Settings	0.0 to d 3600 sec	Factory Setting: 60.0

- This parameter defines the time during which the PID feedback must be abnormal before a warning (see Pr.10.09) is given. It also can be modified according to the system feedback signal time.
- If this parameter is set to 0.0, the system would not detect any abnormality signal.

V/500 - 5			
17:27:21:			
17 27 22			

- If it doesn't receive PID feedback signal over Pr.10.08 setting, the feedback signal fault will occur and please refer to Pr.10.09 for the fault treatment.
- Related parameter: Pr.10.09(Treatment of the Erroneous PID Feedback Signals)

	=				
10.09	Treatment of the Erroneous Feedback Signals (for PID feedback error)				
				Factory Setting: 0	
	Settings	0	Warning and RAMP to stop		
		1	Warning and COAST to stop		
		2	Warning and keep operating		

- AC motor drive action when the feedback signals (analog PID feedback) are abnormal according to Pr.10.16.
- Setting Pr.10.09 to 0: When the feedback signal fault occurs, it will display "FbE" on the digital keypad and the motor will stop to 0Hz by Pr.01.10/Pr.01.12 setting. It needs to clear "RESET" to clear the warning message.
- Setting Pr.10.09 to 1: When the feedback signal fault occurs, it will display "FbE" on the digital keypad and the motor will free run to stop. It needs to press "RESET" to clear the warning message.
- Setting Pr.10.09 to 2: When the feedback signal fault occurs, it will display "FbE" on the digital keypad and the motor will keep running. The warning message can be cleared after the feedback signal is normal.
- Related parameters" Pr.10.00(PID Set Point Selection), Pr.10.01(Input Terminal for PID Feedback), Pr.10.12(PID Offset Level) and Pr.10.13(Detection Time of PID Offset)

# NOTE

The digital keypad is optional. Please refer to Appendix B for details. When using without this optional keypad, the FAULT LED will be ON once there is error messages or warning messages from the external terminals.

10.10 Gai	n Over the PID Detection Value	Unit: 0.1
Set	tings 0.0 to 10.0	Factory Setting: 1.0

This is the gain adjustment over the feedback detection value.

#### Chapter 4 Parameters | Variation

- This parameter will affect Pr.00.04(setting 5) directly. That is Pr.00.04(setting 5) Display PID analog feedback signal value (b) (%)= PID detection value X Gain Over the PID Detection Value.
- Related parameters: Pr.00.04(Content of Multi-function Display) and Pr.10.01(Input Terminal for PID Feedback)

10.12	PID Offset L	evel	Unit: 0.1
	Settings	1.0 to 50.0%	Factory Setting: 10.0

This parameter is used to set max. allowable value of PID error.

10.13	Detection <sup>-</sup>	Time of PID Offset	Unit: 0.1
	Settings	0.1 to 300.0 sec	Factory Setting: 5.0

- This parameter is used to set detection of the offset between set point and feedback.
- When the offset is higher than the setting of Pr.10.12 for a time exceeding the setting of Pr.10.13, PID feedback signal fault occurs and operates by the treatment set in Pr.10.09.
- Related parameters: Pr.10.00(PID Set Point Selection), Pr.10.01(Input Terminal for PID Feedback), Pr.10.09(Treatment of the Erroneous PID Feedback Signals) and Pr.10.12(PID Offset Level)

#### 10.17 Minimum PID Output Frequency Selection

Factory Setting: 0

- Settings 0 By PID control
  - 1 By Minimum output frequency (Pr.01.05)
- This is the source selection of minimum output frequency when control is by PID.
- The output of the AC motor drive will refer to this parameter setting. When this parameter is set to 0, the output frequency will output by the calculation of PID. When this parameter is set to 1 and Pr.01.08 is not set to 0, the output frequency=Pr.01.08 setting. Otherwise, the output frequency=Pr.01.05 setting.
- Related parameters: Pr.01.05(Minimum Output Frequency (Fmin) (Motor 0)) and Pr.01.08(Output Frequency Lower Limit)

10.14	Sleep/Wake	e Up Detection Time	Unit: 0.1
	Settings	0.0 to 6550 sec	Factory Setting: 0.0




- Ш If PID frequency is less than the sleep frequency when the drive starts running, the drive will be in sleep mode immediately and won't limit by this parameter.
- Ш Related parameters: Pr.10.15(Sleep Frequency) and Pr.10.16(Wakeup Frequency)


10.15	Sleep Frequ	iency	Unit: 0.01
	Settings	0.00 to 600.0 Hz	Factory Setting: 0.00

- Ш This parameter set the frequency for the AC motor drive to be in sleep mode.
- ш The AC motor drive will stop outputting after being sleep mode, but PID controller keep operating.

10.16	Wakeup F	requency	Unit: 0.01
	Settings	0.00 to 600.0 Hz	Factory Setting: 0.00

- $\Box$ This parameter is used to set the wakeup frequency to restart the AC motor drive after sleep mode.
- Ш The wake up frequency must be higher than sleep frequency.
- $\square$ When the actual output frequency ≤ Pr.10.15 and the time exceeds the setting of Pr.10.14, the AC motor drive will be in sleep mode and the motor will decelerate to stop by Pr.01.10/01.12 setting.
- $\Box$ When the actual frequency command > Pr.10.16 and the time exceeds the setting of Pr.10.14. the AC motor drive will restart.
- $\Omega$ When the AC motor drive is in sleep mode, frequency command is still calculated by PID. When frequency reaches wake up frequency, AC motor drive will accelerate from Pr.01.05 minimum frequency following the V/f curve.






When Pr. 01.05min. output frequency ≤ PID frequency (H) ≤ Pr.01.08 lower bound of frequency and sleep function is enabled (output frequency (H) < Pr.10.15 sleep frequency and time > Pr.10.14 detection time), frequency will be 0 (in sleep mode). If sleep function is disabled, output frequency(H) = Pr.01.08 lower bound frequency.



The common adjustments of PID control are shown as follows:

Example 1: how to have stable control as soon as possible?

Please shorten Pr.10.03 (Integral Time (I)) setting and increase Pr,10.04(Differential Control (D)) setting.




Example 2: How to suppress the oscillation of the wave with long cycle?

If it is oscillation when the wave cycle is longer than integral time, it needs to increase Pr.10.03 setting to suppress the oscillation.








Example 3: How to suppress the oscillation of the wave with short cycle?

When the cycle of oscillation is short and almost equal Differential time setting, it needs to shorten the differential time setting to suppress the oscillation. If Differential time(I) = 0.0, it can not suppress the oscillation. Please reduce Pr.10.02 setting or increase Pr.10.06 setting.

## Response



## Chapter 4 Parameters | Variation



Group 11: Multi-function Input/Output Parameters for Extension Card

Make sure that the extension card is installed on the AC motor drive correctly before using group 11 parameters. See Appendix B for details.

11.00	Multi-function Output Terminal MO2/RA2	
11.01	Multi-function Output Terminal MO3/RA3	
11.02	Multi-function Output Terminal MO4/RA4	
11.03	Multi-function Output Terminal MO5/RA5	
11.04	Multi-function Output Terminal MO6/RA6	
11.05	Multi-function Output Terminal MO7/RA7	
·	Settings 0 to 21	Factory Setting: 0

Settings	Function	Description
0	No Function	
1	AC Drive Operational	Active when the drive is ready or RUN command is "ON".
2	Master Frequency Attained	Active when the AC motor drive reaches the output frequency setting.
3	Zero Speed	Active when Command Frequency is lower than the Minimum Output Frequency.
4	Over-Torque Detection	Active as long as over-torque is detected. (Refer to Pr.06.03 ~ Pr.06.05)
5	Baseblock (B.B.) Indication	Active when the output of the AC motor drive is shut off during baseblock. Base block can be forced by Multi-function input (setting 09).
6	Low-Voltage Indication	Active when low voltage (Lv) is detected.
7	Operation Mode Indication	Active when operation command is controlled by external terminal.
8	Fault Indication	Active when a fault occurs (oc, ov, oH, oL, oL1, EF, cF3, HPF, ocA, ocd, ocn, GFF).

1/577				
17/2772				

Settings	Function	Description		
9	Desired Frequency Attained	Active when the desired frequency (Pr.03.02) is attained.		
10	Terminal Count Value Attained	Active when the counter reaches Terminal Count Value.		
11	Preliminary Count Value Attained	Active when the counter reaches Preliminary Count Value.		
12	Over Voltage Stall supervision	Active when the Over Voltage Stall function operating		
13	Over Current Stall supervision	Active when the Over Current Stall function operating		
14	Heat Sink Overheat Warning	When heatsink overheats, it will signal to prevent OH turn off the drive. When it is higher than 85oC (185oF), it will be ON.		
15	Over Voltage supervision	Active when the DC-BUS voltage exceeds level		
16	PID supervision	Active when the PID function is operating		
17	Forward command	Active when the direction command is FWD		
18	Reverse command	Active when the direction command is REV		
19	Zero Speed Output Signal	Active unless there is an output frequency present at terminals U/T1, V/T2, and W/T3.		
20	Communication Warning (FbE,Cexx, AoL2, AUE, SAvE)	Active when there is a Communication Warning		
21	Brake Control (Desired Frequency Attained)	Active when output frequency ≥Pr.03.14. Deactivated when output frequency ≤Pr.03.15 after STOP command.		
		_		
11.06	Multi-function Input Termi			
11.07	Multi-function Input Termi			
11.08	Multi-function Input Terminal (MI9)			

Multi-function Input Terminal (MI10)

11.09

#### Chapter 4 Parameters |

- 4	chapter 4 i	arameters	Colonia de Carlos de Carlo				
	11.10	Multi-function Input Terminal (MI11)					
	11.11	Multi-function Input Terminal (MI12)					
	•	Settings	0 to 23	Factory Setting: 0			

- Refer to the table below Pr.04.08 for setting the multifunction input terminals.
- Set the corresponding parameter according to the terminal labeled on the extension card.




#### Group 12: Analog Input/Output Parameters for Extension Card

Make sure that the extension card is installed on the AC motor drive correctly before using group 12 parameters. See Appendix B for details.

12.00	Al1 Function	on Sele	ction	
,				Factory Setting: 0
	Settings	0	Disabled	
		1	Source of the 1st frequency	
		2	Source of the 2nd frequency	
		3	PID Set Point (PID enable)	
		4	Positive PID feedback	
		5	Negative PID feedback	
12.01	Al1 Analog	Signal	Mode	
				Factory Setting: 1
	Settings	0	ACI2 analog current (0.0 ~ 20.0mA)	

 $\Box$ Besides parameters settings, the voltage/current mode should be used with the switch.

AVI3 analog voltage (0.0 ~ 10.0V)




Unit: 0.1	Input Voltage	<b>12.02</b> Min. AVI3 I
Factory Setting: 0.0	0.0 to 10.0V	Settings
Unit: 0.1	Scale Percentage	<b>12.03</b> Min. AVI3 S
Factory Setting: 0.0	0.0 to 100.0%	Settings

12.04 Max. AVI3 Input Voltage	Unit: 0.1
Settings 0.0 to 10.0V	Factory Setting: 10.0



Unit: 0.1	Percentage	Max. AVI3 Sc	12.05
Factory Setting: 100.0	to 100.0%	Settings	
Unit: 0.1	urrent	Min. ACI2 Inp	12.06
Factory Setting: 4.0	to 20.0mA	Settings	
Unit: 0.1	<sup>2</sup> ercentage	Min. ACI2 Sc	12.07
Factory Setting: 0.0	to 100.0%	Settings	
Unit: 0.1	Current	Max. ACI2 In	12.08
Factory Setting: 20.0	to 20.0mA	Settings	
Unit: 0.1	Percentage	Max. ACI2 So	12.09
Factory Setting: 100.0	to 100.0%	Settings	
	ection	Al2 Function	12.10
Factory Setting: 0			
	Disabled	Settings	
	Source of the 1st frequency		
	Source of the 2nd frequency		
	PID Set Point (PID enable)		
	Positive PID feedback		
	Negative PID feedback		
	l Mode	Al2 Analog S	12.11
Factory Setting: 1	_		
	ACI3 analog current (0.0 ~ 20.0mA)	Settings	
	AVI4 analog voltage (0.0 ~ 10.0V)		





12.13 Min. AVI4 Scale Percentage Settings 0.0 to 100.0% Factory Setting: 0.  12.14 Max. AVI4 Input Voltage Settings 0.0 to 10.0V Factory Setting: 10.  12.15 Max. AVI4 Scale Percentage Unit: 0. Settings 0.0 to 100.0% Factory Setting: 10.  12.16 Min. ACI3 Input Current Settings 0.0 to 20.0mA Factory Setting: 4.  12.17 Min. ACI3 Scale Percentage Settings 0.0 to 100.0% Factory Setting: 0.  12.18 Max. ACI3 Input Current Settings 0.0 to 20.0mA Factory Setting: 0.  12.18 Max. ACI3 Input Current Settings 0.0 to 20.0mA Factory Setting: 20.  12.19 Max. ACI3 Scale Percentage Unit: 0.	12.12	Min. AVI4	Input Voltage	Unit: 0.1
Settings 0.0 to 100.0%  Factory Setting: 0.  12.14 Max. AVI4 Input Voltage Settings 0.0 to 10.0V  Factory Setting: 10.  12.15 Max. AVI4 Scale Percentage Settings 0.0 to 100.0%  Factory Setting: 100.  12.16 Min. ACI3 Input Current Settings 0.0 to 20.0mA  Factory Setting: 4.  12.17 Min. ACI3 Scale Percentage Settings 0.0 to 100.0%  Factory Setting: 0.  12.18 Max. ACI3 Input Current Settings 0.0 to 20.0mA  Factory Setting: 0.  12.18 Max. ACI3 Input Current Settings 0.0 to 20.0mA  Factory Setting: 20.  12.19 Max. ACI3 Scale Percentage Unit: 0.		Settings	0.0 to 10.0V	Factory Setting: 0.0
Settings 0.0 to 100.0%  Factory Setting: 0.  12.14 Max. AVI4 Input Voltage Unit: 0. Settings 0.0 to 10.0V  Factory Setting: 10.  12.15 Max. AVI4 Scale Percentage Unit: 0. Settings 0.0 to 100.0%  Factory Setting: 100.  12.16 Min. ACI3 Input Current Unit: 0. Settings 0.0 to 20.0mA  Factory Setting: 4.  12.17 Min. ACI3 Scale Percentage Unit: 0. Settings 0.0 to 100.0%  Factory Setting: 0.  12.18 Max. ACI3 Input Current Unit: 0. Settings 0.0 to 20.0mA  Factory Setting: 20.	12 13	Min AVI4	Scale Percentage	Linit: 0.1
Settings 0.0 to 10.0V Factory Setting: 10.  12.15 Max. AVI4 Scale Percentage Unit: 0.  Settings 0.0 to 100.0% Factory Setting: 100.  12.16 Min. ACI3 Input Current Unit: 0.  Settings 0.0 to 20.0mA Factory Setting: 4.  12.17 Min. ACI3 Scale Percentage Unit: 0.  Settings 0.0 to 100.0% Factory Setting: 0.  12.18 Max. ACI3 Input Current Unit: 0.  Settings 0.0 to 20.0mA Factory Setting: 20.	12.10			Factory Setting: 0.0
Settings 0.0 to 10.0V Factory Setting: 10.  12.15 Max. AVI4 Scale Percentage Unit: 0.  Settings 0.0 to 100.0% Factory Setting: 100.  12.16 Min. ACI3 Input Current Unit: 0.  Settings 0.0 to 20.0mA Factory Setting: 4.  12.17 Min. ACI3 Scale Percentage Unit: 0.  Settings 0.0 to 100.0% Factory Setting: 0.  12.18 Max. ACI3 Input Current Unit: 0.  Settings 0.0 to 20.0mA Factory Setting: 20.				· · · · ·
12.15       Max. AVI4 Scale Percentage       Unit: 0.         Settings       0.0 to 100.0%       Factory Setting: 100.         12.16       Min. ACI3 Input Current       Unit: 0.         Settings       0.0 to 20.0mA       Factory Setting: 4.         12.17       Min. ACI3 Scale Percentage       Unit: 0.         Settings       0.0 to 100.0%       Factory Setting: 0.         12.18       Max. ACI3 Input Current       Unit: 0.         Settings       0.0 to 20.0mA       Factory Setting: 20.         12.19       Max. ACI3 Scale Percentage       Unit: 0.	12.14	Max. AVI4	Input Voltage	Unit: 0.1
Settings 0.0 to 100.0%  Factory Setting: 100.  12.16 Min. ACI3 Input Current  Settings 0.0 to 20.0mA  Factory Setting: 4.  12.17 Min. ACI3 Scale Percentage  Settings 0.0 to 100.0%  Factory Setting: 0.  12.18 Max. ACI3 Input Current  Unit: 0.  Settings 0.0 to 20.0mA  Factory Setting: 20.  12.19 Max. ACI3 Scale Percentage  Unit: 0.		Settings	0.0 to 10.0V	Factory Setting: 10.0
Settings 0.0 to 100.0%  Factory Setting: 100.  12.16 Min. ACI3 Input Current  Settings 0.0 to 20.0mA  Factory Setting: 4.  12.17 Min. ACI3 Scale Percentage  Settings 0.0 to 100.0%  Factory Setting: 0.  12.18 Max. ACI3 Input Current  Unit: 0.  Settings 0.0 to 20.0mA  Factory Setting: 20.  12.19 Max. ACI3 Scale Percentage  Unit: 0.	12.45	May AVIIA	Cools Developtors	Lipite 0.4
12.16 Min. ACI3 Input Current Settings 0.0 to 20.0mA  12.17 Min. ACI3 Scale Percentage Settings 0.0 to 100.0%  12.18 Max. ACI3 Input Current Settings 0.0 to 20.0mA  12.19 Max. ACI3 Scale Percentage Unit: 0.  Unit: 0.	12.15			
Settings 0.0 to 20.0mA Factory Setting: 4.  12.17 Min. ACI3 Scale Percentage Unit: 0.  Settings 0.0 to 100.0% Factory Setting: 0.  12.18 Max. ACI3 Input Current Unit: 0.  Settings 0.0 to 20.0mA Factory Setting: 20.		Settings	0.0 to 100.0%	Factory Setting: 100.0
12.17       Min. ACI3 Scale Percentage       Unit: 0.         Settings       0.0 to 100.0%       Factory Setting: 0.         12.18       Max. ACI3 Input Current       Unit: 0.         Settings       0.0 to 20.0mA       Factory Setting: 20.         12.19       Max. ACI3 Scale Percentage       Unit: 0.	12.16	Min. ACI3	Input Current	Unit: 0.1
Settings 0.0 to 100.0% Factory Setting: 0.  12.18 Max. ACI3 Input Current Unit: 0. Settings 0.0 to 20.0mA Factory Setting: 20.  12.19 Max. ACI3 Scale Percentage Unit: 0.		Settings	0.0 to 20.0mA	Factory Setting: 4.0
Settings 0.0 to 100.0% Factory Setting: 0.  12.18 Max. ACI3 Input Current Unit: 0. Settings 0.0 to 20.0mA Factory Setting: 20.  12.19 Max. ACI3 Scale Percentage Unit: 0.	12.17	Min. ACI3	Scale Percentage	Unit: 0.1
Settings 0.0 to 20.0mA Factory Setting: 20.  12.19 Max. ACI3 Scale Percentage Unit: 0.		Settings	0.0 to 100.0%	Factory Setting: 0.0
Settings 0.0 to 20.0mA Factory Setting: 20.  12.19 Max. ACI3 Scale Percentage Unit: 0.	40.40	Man AGIO	January Command	
12.19 Max. ACI3 Scale Percentage Unit: 0.	12.18			
<del>-</del>		Coungs	5.5 to 20.0Hz t	1 actory cetting. 20.0
Settings 0.0 to 100.0% Factory Setting: 100.	12.19	Max. ACI3	Scale Percentage	Unit: 0.1
		Settings	0.0 to 100.0%	Factory Setting: 100.0



#### 12.20 AO1 Terminal Analog Signal Mode


Factory Setting: 0

Settinas 0 AVO1

> 1 ACO1 (analog current 0.0 to 20.0mA)

> ACO1 (analog current 4.0 to 20.0mA)

 $\Box$ Besides parameter setting, the voltage/current mode should be used with the switch.



#### 12.21 AO1 Analog Output Signal

Factory Setting: 0

Settings 0 Analog Frequency

Analog Current (0 to 250% rated current)

 $\mathbf{m}$ This parameter is used to choose analog frequency (0-+10Vdc) or analog current (4-20mA) to correspond to the AC motor drive's output frequency or current.

12.22	AO1 Analog	Output Gain	Unit: 1
	Settings	1 to 200%	Factory Setting: 100

- Ш This parameter is used to set the analog output voltage range.
- $\square$ When Pr.12.21 is set to 0, analog output voltage corresponds to the AC motor drive's output frequency. When Pr.12.22 is set to 100, the max. output frequency (Pr.01.00) setting corresponds to the AFM output (+10VDC or 20mA)
- $\square$ When Pr.12.21 is set to 1, analog output voltage corresponds to the AC motor drive's output current. When Pr.12.22 is set to 100, the 2.5 X rated current corresponds to the AFM output (+10VDC or 20mA)





If the scale of the voltmeter is less than 10V, refer to following formula to set Pr.12.22:

Pr.12.22 = [(full scale voltage)/10]\*100%.

Example: When using voltmeter with full scale (5V), Pr.12.22 should be set to 5/10\*100%=50%. If

Pr.12.21 is set to 0, the output voltage will correspond to the max. output frequency.

#### 12.23 AO2Terminal Analog Signal Mode


Factory Setting: 0

Settings AVO<sub>2</sub>

ACO2 (analog current 0.0 to 20.0mA)

2 ACO2 (analog current 4.0 to 20.0mA)

 $\Box$ Besides parameter setting, the voltage/current mode should be used with the switch.



#### AO2 Analog Output Signal 12.24

Factory Setting: 0

Settinas 0 Analog Frequency

Analog Current (0 to 250% rated current)

12.25 AO2 Analog Output Gain Unit: 1 Settinas 1 to 200% Factory Setting: 100

Setting method for the AO2 is the same as the AO1.

#### Chapter 4 Parameters | Variation



Group 13: PG function Parameters for Extension Card

Pulse generator card (PG card) is mainly applied in the detection components of speed control or position control. It usually makes a closed-loop speed control system with encoder. The AC motor drive is used with encoder and PG card to have a complete speed control and position detection system.

Please make sure that the extension card is installed on the AC motor drive correctly before using group 12 parameters. See Appendix B for details.

13.	.00 PG Input		<del></del>			
	•		Factory Setting: 0			
	Settings	0	Disable PG			
		1	Single phase			
		2	Forward/Counterclockwise rotation			
		3	Reverse/Clockwise rotation			
Ш	There are two	outputs	, 1-phase and 2-phase output, for the encoder output. For the 1-phase			
	output, the enc	oder ou	tput is a group of pulse signal. For the 2-phase output, the encoder can			
	output A and B pulse signals with $90^\circ$ phase difference. The encoder is defined by the timing					
	of A and B pulses as the following figure. It can not only measure the speed but distinguish					
	motor rotation direction by A and B pulse signals.					
	PG card receives A and B pulses from encoder output and sends this feedback signal to the					
	AC motor drive for speed or position control.					
	Setting 0: disat	ole PG 1	function.			
	Setting 1: for speed/position control but can't distinguish motor rotation direction.					
	Setting 2: both for speed control and distinguish motor rotation direction. A phase leads B					
	phase as shown in the following diagram and motor is forward running.					
	Setting 3: both	for spe	ed control and distinguish motor rotation direction. B phase leads A			
	phase as show	n in the	following diagram and motor is reverse running.			
	Related param	eter: Pr	.13.01(PG Pulse Range)			



When receiving a forward command, motorwill rotate in counterclockwise direction (see from output side).



When receiving a reverse command, motor will rotate in clockwise direction (see from output side).



When encoder rotates in clockwise direction (see from input side). At this moment, A phase leads B phase.

13.01	PG Pulse Ra	ange	Unit: 1
	Settings	1 to 20000	Factory Setting: 600

- A Pulse Generator (PG) is used as a sensor that provides a feedback signal of the motor speed. This parameter defines the number of pulses for each cycle of the PG control.
- This parameter setting is the resolution of encoder. With the higher resolution, the speed control will be more precise.

13.02	Motor Pole	Number (Motor 0)	Unit: 1
	Settings	2 to 10	Factory Setting: 4

The pole number should be even (can't be odd).

13.03	<b>⊮</b> Proportio	onal Gain (P)	Unit: 0.01
	Settings	0.0 to 10.0	Factory Setting: 1.0

- This parameter is used to set the gain (P) when using PG for the closed-loop speed control.
- The proportional gain is mainly used to eliminate the error. The large proportional gain(P) will get the faster response to decrease the error. Too large proportional gain will cause large overshoot and oscillation and decrease the stable.

#### Chapter 4 Parameters | Variation

 $\Box$ 

This parameter can be used to set the proportional gain (P) to decide the response speed.

With large proportional gain, it will get faster response. Too large proportional gain may cause system oscillation. With small proportional gain, it will get slower response.

13.04	✓ Integral (	Gain ( I )	Unit: 0.01
	Settings	0.00 to 100.00 sec	Factory Setting: 1.00
		0.00 Disable	

- The integral controller is used to eliminate the error during stable system. The integral control doesn't stop working until error is 0. The integral is acted by the integral time. The smaller integral time is set, the stronger integral action will be. It is helpful to reduce overshoot and oscillation to make a stable system. At this moment, the decreasing error will be slow. The integral control is often used with other two controls to become PI controller or PID controller.
- This parameter is used to set the integral time of I controller. When the integral time is long, it will have small gain of I controller, the slower response and bad external control. When the integral time is short, it will have large gain of I controller, the faster response and rapid external control.
- When the integral time is too small, it may cause system oscillation.
- When it is set to 0.0, the integral function is disabled.

13.05	✓ Speed C	Control Output Frequency Limit	Unit: 0.01
	Settings	0.00 to 100.00Hz	Factory Setting: 10.00

- This parameter is used to limit the max. output frequency.
- From the following PG speed diagram, output frequency (H) = frequency command (F) + speed detection value via PG feedback. With the speed change of motor load, the speed change will be sent to drive via PG card to change the output frequency. So this parameter can be used to decrease the speed change of motor load.

13.06	✓ Speed F	eedback Display Filter	Unit: 1
	Settings	0 to 9999 (*2ms)	Factory Setting: 500


When Pr.0.04 is set to 14, its display will be updated regularly. This update time is set by Pr 13 06



- With the large setting in Pr.13.06, it can slow the response speed to prevent the blinking of digital number on the digital keypad. Too large setting may cause the delay of RPM value via PG card.
- Ш Related parameter: Pr.00.04(Content of Multi-function Display)

13.09	✓ Speed Fee	edback Filter	Unit: 1
	Settings	0 to 9999 (*2ms)	Factory Setting: 16

 $\square$ This parameter is the filter time from the speed feedback to the PG card. Too large setting may cause slow feedback response.



PG feedback speed control

13.07				Unit: 0.1
	Settings	0.1 to 10.0 sec		Factory Setting: 1.0
		0.0	Disabled	

- $\Box$ This parameter defines the time during which the PID feedback must be abnormal before a warning (see Pr.13.08) is given. It also can be modified according to the system feedback signal time.
- ш If this parameter is set to 0.0, the system would not detect any abnormality signal.
- $\Box$ Related parameter: Pr.13.08(Treatment of the Feedback Signal Fault)



13.	<b>⊘</b> Treatme	nt of the	e Feedback Signal Fault	
			Factory Setting:	: 1
	Settings	0	Warn and RAMP to stop	
		1	Warn and COAST to stop	
		2	Warn and keep operating	
Ш	AC motor drive	action	when the feedback signals (analog PID feedback or PG (encoder)	
	feedback) are	abnorm	al.	
Ш	Setting Pr.13.0	8 to 0:	When the feedback signal fault occurs, it will display "PGEr" on the	
	digital keypad	and the	stop to 0Hz by Pr.01.10/Pr.01.12 setting.	
Ш	Setting Pr.13.0	8 to 1:	When the feedback signal fault occurs, it will display "PGEr" on the	
	digital keypad	and the	motor will free run to stop.	
	Setting Pr.13.0	8 to 2:	When the feedback signal fault occurs, it will display "PGEr" on the	
	digital keypad	and the	motor will keep running.	



The digital keypad is optional. Please refer to Appendix B for details. When using without this optional keypad, the FAULT LED will be ON once there is error messages or warning messages from the external terminals.

It needs to press "RESET" to clear the warning message "PGEr" displayed on the keypad.

13.10	Source of the High-speed Counter (NOT for VFD*E*C models)					
				Factory Display: 0 (Read only)		
	Settings	0	PG card			
		1	PLC			

Ш This parameter reads the high-speed counter of the drive to use on PG card or PLC.



#### 4.4 Different Parameters for VFD\*E\*C Models

The content of this instruction sheet may be revised without prior notice. Please consult our distributors or download the most updated version at

http://www.delta.com.tw/industrialautomation

Software version for VFD\*E\*C is power board: V1.00 and control board: V2.00.

★: The parameter can be set during operation.

Group 0 User Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
		0: Parameter can be read/written		
		1: All parameters are read only		
00.00		6: Clear PLC program (NOT for VFD*E*C models)		
00.02	Parameter Reset	9: All parameters are reset to factory settings (50Hz, 230V/400V or 220V/380V depends on Pr.00.12)	0	
		10: All parameters are reset to factory settings (60Hz, 220V/440V)		
		0: Display the frequency command value (Fxxx)		
	Start-up Display Selection	1: Display the actual output frequency (Hxxx)		
<b>₩</b> 00.03		2: Display the content of user-defined unit (Uxxx)	0	
		3: Multifunction display, see Pr.00.04		
		4: FWD/REV command		
		5: PLCx (PLC selections: PLC0/PLC1/PLC2) (NOT for VFD*E*C models)		
<b>₩</b> 00.04	Content of Multi- function Display	0: Display the content of user-defined unit (Uxxx)	0	
		1: Display the counter value (c)		
		2: Display PLC D1043 value (C) (NOT for VFD*E*C models)		
		3: Display DC-BUS voltage (u)		
		4: Display output voltage (E)		

Parameters	VED-E

Parameter	Explanation	Settings	Factory Setting	Customer
		5: Display PID analog feedback signal value (b) (%)		
		6: Output power factor angle (n)		
		7: Display output power (P)		
		8: Display the estimated value of torque as it relates to current (t)		
		9: Display AVI (I) (V)		
		10: Display ACI / AVI2 (i) (mA/V)		
		11: Display the temperature of IGBT (h) (°C)		
		12: Display AVI3/ACI2 level (I.)		
		13: Display AVI4/ACI3 level (i.)		
		14: Display PG speed in RPM (G)		
		15: Display motor number (M)		

#### Group 1 Basic Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
<b>⊮</b> 01.11	Accel Time 2	0.1 to 600.0 / 0.01 to 600.0 sec	1.0	
<b>⊮</b> 01.12	Decel Time 2	0.1 to 600.0 / 0.01 to 600.0 sec	1.0	

## Group 2 Operation Method Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
		Digital keypad UP/DOWN keys or Multi- function Inputs UP/DOWN. Last used frequency saved.		
400.00	Source of First	1: 0 to +10V from AVI	_	
<b>₩</b> 02.00	Master Frequency Command	2: 4 to 20mA from ACI or 0 to +10V from AVI2	5	
		3: RS-485 (RJ-45)/USB communication		
		4: Digital keypad potentiometer		
		5: CANopen communication		

Chapter 4 Para	meters	VED-E
	Factory Setting	Customer

Parameter	Explanation	Settings	Factory Setting	Customer
		Digital keypad     External terminals. Keypad STOP/RESET enabled.		
	Source of First	2: External terminals. Keypad STOP/RESET disabled.		
<b>№</b> 02.01	Operation Command	3: RS-485 (RJ-45)/USB communication. Keypad STOP/RESET enabled.	5	
		4: RS-485 (RJ-45)/USB communication. Keypad STOP/RESET disabled.		
		5: CANopen communication. Keypad STOP/RESET disabled.		
<b>%</b> 02.09	Source of Second Frequency Command	O: Digital keypad UP/DOWN keys or Multi-function Inputs UP/DOWN. Last used frequency saved.  1: 0 to +10V from AVI  2: 4 to 20mA from ACI or 0 to +10V from AVI2  3: RS-485 (RJ-45)/USB communication  4: Digital keypad potentiometer  5: CANopen communication	0	
02.16	Display the Master Freq Command Source	Read Only Bit0=1: by First Freq Source (Pr.02.00) Bit1=1: by Second Freq Source (Pr.02.09) Bit2=1: by Multi-input function Bit3=1: by PLC Freq command (NOT for VFD*E*C models)	##	
02.17	Display the Operation Command Source	Read Only Bit0=1: by Digital Keypad Bit1=1: by RS485 communication Bit2=1: by External Terminal 2/3 wire mode Bit3=1: by Multi-input function Bit5=1: by CANopen communication	##	

## Group 3 Output Function Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
03.09	Reserved			
03.10	Reserved			

# Group 4 Input Function Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
04.05	Multi-function Input	0: No function	1	
	Terminal (MI3)	1: Multi-Step speed command 1		
		2: Multi-Step speed command 2		
04.06	Multi-function Input	3: Multi-Step speed command 3	2	
	Terminal (MI4)	4: Multi-Step speed command 4		
		5: External reset		
04.07	Multi-function Input	6: Accel/Decel inhibit	3	
	Terminal (MI5)	7: Accel/Decel time selection command		
		8: Jog Operation		
04.08	Multi-function Input	9: External base block	23	
	Terminal (MI6)	10: Up: Increment master frequency		
		11: Down: Decrement master frequency		
		12: Counter Trigger Signal		
		13: Counter reset		
		14: E.F. External Fault Input		
		15: PID function disabled		
		16: Output shutoff stop		
		17: Parameter lock enable		
		18: Operation command selection (external terminals)		
		19: Operation command selection(keypad)		
		20: Operation command selection (communication)		
		21: FWD/REV command		
		22: Source of second frequency command		
		23: Quick Stop (Only for VFD*E*C models)		
		24: Download/execute/monitor PLC Program (PLC2) (NOT for VFD*E*C models)		
		25: Simple position function		
		26: OOB (Out of Balance Detection)		

	_	Chapter 4 Para	meters	17 - 22 - E
Parameter	Explanation	Settings	Factory Setting	Customer
		27: Motor selection (bit 0)		
		28: Motor selection (bit 1)		
04.24	Reserved			
04.25	Reserved			

#### Group 7 Motor Parameters

Parameter	Explanation	Settings	Factory Setting	Customer
07.08	Torque Compensation Time Constant	0.01 ~10.00 Sec	0.30	

#### **Group 9 Communication Parameters**

Parameter	Explanation	Settings	Factory Setting	Customer
09.12~ 09.19	Reserved			
09.20	CANopen Communication Address	0: disable 1: 1 to 127	1	
09.21	CANbus Baud Rate	0: 1M 1: 500K 2: 250K 3: 125K 4: 100K 5: 50K	0	
09.22	Gain of CANbus Frequency	0.00~2.00	1.00	
09.23	CANbus Warning	bit 0 : CANopen Guarding Time out bit 1 : CANopen Heartbeat Time out bit 2 : CANopen SYNC Time out bit 3 : CANopen SDO Time out bit 4 : CANopen SDO buffer overflow bit 5 : CANbus Off bit 6 : Error protocol of CANopen bit 7 : CANopen boot up fault	Read- only	



Parameter	Explanation	Settings	Factory Setting	Customer
09.24	I DS402 Protocol	0: Disable (By Delta rule) 1: Enable (By DS402)	1	

#### Group 11 Parameters for Extension Card

Parameter	Explanation	Settings	Factory Setting	Customer
		0: No function	0	
11.06	Multi-function Input Terminal (MI7)	1: Multi-Step speed command 1		
	,	2: Multi-Step speed command 2		
		3: Multi-Step speed command 3	0	
11.07	Multi-function Input Terminal (MI8)	4: Multi-Step speed command 4		
	· · · · · · · · · · · · · · · · · · ·	5: External reset		
		6: Accel/Decel inhibit	0	
11.08	Multi-function Input Terminal (MI9)	7: Accel/Decel time selection command		
	· · · · · · · · · · · · · · · · · · ·	8: Jog Operation		
	Multi-function Input Terminal (MI10)	9: External base block	0	
11.09		10: Up: Increment master frequency		
		11: Down: Decrement master frequency		
		12: Counter Trigger Signal	0	
44.40	Multi-function Input	13: Counter reset		
11.10	Terminal (MI11)	14: E.F. External Fault Input		
		15: PID function disabled		
11.11	Multi-function Input	16: Output shutoff stop	0	
	Terminal (MI12)	17: Parameter lock enable		
		18: Operation command selection (external terminals)		
		19: Operation command selection (keypad)		
		20: Operation command selection (communication)		
		21: FWD/REV command		
		22: Source of second frequency command		
		23: Quick Stop (Only for VFD*E*C models)		

		Chapter 4 Para	meters	V/
Parameter	Explanation	Settings	Factory Setting	Customer
		24: Download/execute/monitor PLC Program (PLC2) (NOT for VFD*E*C models)		
		25: Simple position function		
		26: OOB (Out of Balance Detection)		
		27: Motor selection (bit 0)		
		28: Motor selection (bit 1)		

#### Group 13: PG function Parameters for Extension Card


Parameter	Explanation	Settings	Factory Setting Customer
13.10	Reserved		



This page intentionally left blank


# Chapter 5 Troubleshooting

### 5.1 Over Current (OC)






#### 5.2 Ground Fault




#### 5.3 Over Voltage (OV)






#### 5.4 Low Voltage (Lv)






### 5.5 Over Heat (OH)




#### 5.6 Overload






#### 5.7 Keypad Display is Abnormal




#### 5.8 Phase Loss (PHL)






#### 5.9 Motor cannot Run






#### 5.10 Motor Speed cannot be Changed

For VFD\*E\*C models, no PLC function is supported. Please follow the dashed line to skip the PLC parts.






#### 5.11 Motor Stalls during Acceleration



#### 5.12 The Motor does not Run as Expected





#### 5.13 Electromagnetic/Induction Noise

Many sources of noise surround AC motor drives and penetrate it by radiation or conduction. It may cause malfunctioning of the control circuits and even damage the AC motor drive. Of course, there are solutions to increase the noise tolerance of an AC motor drive. But this has its limits. Therefore, solving it from the outside as follows will be the best.

- Add surge suppressor on the relays and contacts to suppress switching surges.
- 2. Shorten the wiring length of the control circuit or serial communication and keep them separated from the power circuit wiring.
- 3. Comply with the wiring regulations by using shielded wires and isolation amplifiers for long length.
- 4. The grounding terminal should comply with the local regulations and be grounded independently, i.e. not to have common ground with electric welding machines and other power equipment.
- 5. Connect a noise filter at the mains input terminal of the AC motor drive to filter noise from the power circuit.

In short, solutions for electromagnetic noise exist of "no product" (disconnect disturbing equipment), "no spread"(limit emission for disturbing equipment) and "no receive" (enhance immunity).

#### 5.14 Environmental Condition

Since the AC motor drive is an electronic device, you should comply with the environmental conditions. Here are some remedial measures if necessary.

- 1. To prevent vibration, the use of anti-vibration dampers is the last choice. Vibrations must be within the specification. Vibration causes mechanical stress and it should not occur frequently, continuously or repeatedly to prevent damage to the AC motor drive.
- 2. Store the AC motor drive in a clean and dry location, free from corrosive fumes/dust to prevent corrosion and poor contacts. Poor insulation in a humid location can cause shortcircuits. If necessary, install the AC motor drive in a dust-proof and painted enclosure and in particular situations, use a completely sealed enclosure.
- 3. The ambient temperature should be within the specification. Too high or too low temperature will affect the lifetime and reliability. For semiconductor components, damage will occur once any specification is out of range. Therefore, it is necessary to periodically check air quality and the cooling fan and provide extra cooling of necessary. In addition, the microcomputer may not work in extremely low temperatures, making cabinet heating necessary.


### Chapter 5 Troubleshooting | Wazzall

Store within a relative humidity range of 0% to 90% and non-condensing environment.
 Use an air conditioner and/or exsiccator.

## 5.15 Affecting Other Machines

An AC motor drive may affect the operation of other machines due to many reasons. Some solutions are:

- High Harmonics at Power Side
   High harmonics at power side during running can be improved by:
- 1. Separate the power system: use a transformer for AC motor drive.
- 2. Use a reactor at the power input terminal of the AC motor drive.
- If phase lead capacitors are used (never on the AC motor drive output!!), use serial reactors to prevent damage to the capacitors damage from high harmonics.



#### Motor Temperature Rises

When the motor is a standard induction motor with fan, the cooling will be bad at low speeds, causing the motor to overheat. Besides, high harmonics at the output increases copper and core losses. The following measures should be used depending on load and operation range.

- Use a motor with independent ventilation (forced external cooling) or increase the motor rated power.
- Use a special inverter duty motor.
- 3. Do NOT run at low speeds for long time.

# Chapter 6 Fault Code Information and Maintenance

#### 6.1 Fault Code Information

The AC motor drive has a comprehensive fault diagnostic system that includes several different alarms and fault messages. Once a fault is detected, the corresponding protective functions will be activated. The following faults are displayed as shown on the AC motor drive digital keypad display. The five most recent faults can be read from the digital keypad or communication.



Wait 5 seconds after a fault has been cleared before performing reset via keypad of input terminal.

#### 6.1.1 Common Problems and Solutions

Fault Name	Fault Descriptions	Corrective Actions
οc	Over current Abnormal increase in current.	Check if motor power corresponds with the AC motor drive output power.     Check the wiring connections to U/T1, V/T2, W/T3 for possible short circuits.     Check the wiring connections between the AC motor drive and motor for possible short circuits, also to ground.     Check for loose contacts between AC motor drive and motor.     Increase the Acceleration Time.     Check for possible excessive loading conditions at the motor.     If there are still any abnormal conditions when operating the AC motor drive after a short-circuit is removed and the other points above are checked, it should be sent back to manufacturer.
ου	Over voltage The DC bus voltage has exceeded its maximum allowable value.	Check if the input voltage falls within the rated AC motor drive input voltage range.     Check for possible voltage transients.     DC-bus over-voltage may also be caused by motor regeneration. Either increase the Decel. Time or add an optional brake resistor (and brake unit).     Check whether the required brake power is within the specified limits.

Fault Name	Fault Descriptions	Corrective Actions
0 X C	Overheating Heat sink temperature too high	Ensure that the ambient temperature falls within the specified temperature range.     Make sure that the ventilation holes are not obstructed.     Remove any foreign objects from the heatsinks and check for possible dirty heat sink fins.     Check the fan and clean it.     Provide enough spacing for adequate ventilation. (See chapter 1)
٤٥	Low voltage The AC motor drive detects that the DC bus voltage has fallen below its minimum value.	Check whether the input voltage falls within the AC motor drive rated input voltage range.     Check for abnormal load in motor.     Check for correct wiring of input power to R-S-T (for 3-phase models) without phase loss.
٥٤	Overload The AC motor drive detects excessive drive output current. NOTE: The AC motor drive can withstand up to 150% of the rated current for a maximum of 60 seconds.	Check whether the motor is overloaded.     Reduce torque compensation setting in Pr.07.02.     Use the next higher power AC motor drive model.
٥٢ :	Overload 1 Internal electronic overload trip	Check for possible motor overload.     Check electronic thermal overload setting.     Use a higher power motor.     Reduce the current level so that the drive output current does not exceed the value set by the Motor Rated Current Pr.07.00.
013	Overload 2 Motor overload.	Reduce the motor load.     Adjust the over-torque detection setting to an appropriate setting (Pr.06.03 to Pr.06.05).
HPF:	CC (current clamp)	
HPF2	OV hardware error	Return to the factory.
XPF3	GFF hardware error	
жрғч	OC hardware error	
<b>გ</b> გ	External Base Block. (Refer to Pr. 08.07)	When the external input terminal (B.B) is active, the AC motor drive output will be turned off.     Deactivate the external input terminal (B.B) to operate the AC motor drive again.

	Chapter 6 Fault Code Information and Maintenance			
Fault Name	Fault Descriptions	Corrective Actions		
oc R	Over-current during acceleration	Short-circuit at motor output: Check for possible poor insulation at the output lines.     Torque boost too high: Decrease the torque compensation setting in Pr.07.02.     Acceleration Time too short: Increase the Acceleration Time.     AC motor drive output power is too small: Replace the AC motor drive with the next higher power model.		
ocd	Over-current during deceleration	Short-circuit at motor output: Check for possible poor insulation at the output line.     Deceleration Time too short: Increase the Deceleration Time.     AC motor drive output power is too small: Replace the AC motor drive with the next higher power model.		
000	Over-current during constant speed operation	Short-circuit at motor output: Check for possible poor insulation at the output line.     Sudden increase in motor loading: Check for possible motor stall.     AC motor drive output power is too small: Replace the AC motor drive with the next higher power model.		
£ F	External Fault	When multi-function input terminals (MI3-MI9) are set to external fault, the AC motor drive stops output U, V and W.     Give RESET command after fault has been cleared.		
cF (0	Internal EEPROM can not be programmed.	Return to the factory.		
c F 1, 1	Internal EEPROM can not be programmed.	Return to the factory.		
c F 2.0	Internal EEPROM can not be read.	Press RESET key to set all parameters to factory setting.     Return to the factory.		
c 8 8.1	Internal EEPROM can not be read.	Press RESET key to set all parameters to factory setting.     Return to the factory.		
c F 3.0	U-phase error			
c F 3. 1	V-phase error			
<u>c F 3.2</u>		Return to the factory.		
<u>c F 3.3</u>	OV or LV			
c F 3.4 c F 3.5	Temperature sensor error			



Fault Name	Fault Descriptions	Corrective Actions
GFF	Ground fault	When (one of) the output terminal(s) is grounded, short circuit current is more than 50% of AC motor drive rated current, the AC motor drive power module may be damaged.  NOTE: The short circuit protection is provided for AC motor drive protection, not for protection of the user.  1. Check whether the IGBT power module is damaged.  2. Check for possible poor insulation at the output line.
c F R	Auto accel/decel failure	Check if the motor is suitable for operation by AC motor drive.     Check if the regenerative energy is too large.     Load may have changed suddenly.
c E	Communication Error	Check the RS485 connection between the AC motor drive and RS485 master for loose wires and wiring to correct pins.     Check if the communication protocol, address, transmission speed, etc. are properly set.     Use the correct checksum calculation.     Please refer to group 9 in the chapter 5 for detail information.
codE	Software protection failure	Return to the factory.
8800	Analog signal error	Check the wiring of ACI
888	PID feedback signal error	Check parameter settings (Pr.10.01) and AVI/ACI wiring.     Check for possible fault between system response time and the PID feedback signal detection time (Pr.10.08)
ያጸኒ	Phase Loss	Check input phase wiring for loose contacts.
808	Auto Tuning Error	Check cabling between drive and motor     Retry again
EP 10	Communication time-out error on the control board or power board	Press RESET key to set all parameters to factory setting.     Return to the factory.
PEC 1	Motor overheat protection	Check if the motor is overheat     Check Pr.07.12 to Pr.07.17 settings
P68r	PG signal error	Check the wiring of PG card     Try another PG card
6688	CANopen Guarding Time out ( Only for VFDxxxExxC )	Connect to CAN bus again and reset CAN bus

## Chapter 6 Fault Code Information and Maintenance

Fault Name	Fault Descriptions	Corrective Actions
5868	CANopen Heartbeat Time out (Only for VFDxxxExxC)	Connect to CAN bus again and reset CAN bus
€536	CANopen SYNC Time out (Only for VFDxxxExxC)	Check if CANopen synchronous message is abnormal
8500	CANopen SDO Time out (Only for VFDxxxExxC)	Check if command channels are full
8568	CANopen SDO buffer overflow ( Only for VFDxxxExxC )	Too short time between commands, please check SDO message sent from the master     Reset CAN bus
8656	CAN bus off (Only for VFDxxxExxC)	Check if it connects to terminal resistor     Check if the signal is abnormal     Check if the master is connected
8888	CAN Boot up fault ( Only for VFDxxxExxC )	Check if the master is connected     Reset CAN bus
[Pbo	Error communication protocol of CANopen (Only for VFDxxxExxC)	Check if the communication protocol is correct
486	It will be displayed during deceleration when Pr.08-24 is not set to 0 and unexpected power off occurs, such as momentary power loss.	Set Pr.08-24 to 0     Check if the input power is stable
Act	Abnormal Communication Loop	Check if the communication wiring is correct     Return to the factory



#### 6.1.2 Reset

There are three methods to reset the AC motor drive after solving the fault:

- key on keypad. 1.
- Set external terminal to "RESET" (set one of Pr.04.05~Pr.04.08 to 05) and then set to be 2. ON.
- 3. Send "RESET" command by communication.



Make sure that RUN command or signal is OFF before executing RESET to prevent damage or personal injury due to immediate operation.

## 6.2 Maintenance and Inspections

Modern AC motor drives are based on solid-state electronics technology. Preventive maintenance is required to keep the AC motor drive in its optimal condition, and to ensure a long life. It is recommended to have a qualified technician perform a check-up of the AC motor drive regularly.

#### Daily Inspection:

Basic check-up items to detect if there were any abnormalities during operation are:

- 1. Whether the motors are operating as expected.
- 2. Whether the installation environment is abnormal.
- 3. Whether the cooling system is operating as expected.
- 4. Whether any irregular vibration or sound occurred during operation.
- 5. Whether the motors are overheating during operation.
- 6. Always check the input voltage of the AC drive with a Voltmeter.

#### Periodic Inspection:

Before the check-up, always turn off the AC input power and remove the cover. Wait at least 10 minutes after all display lamps have gone out, and then confirm that the capacitors have fully discharged by measuring the voltage between  $\oplus \sim \bigcirc$ . It should be less than 25VDC.





- Disconnect AC power before processing!
- 2. Only qualified personnel can install, wire and maintain AC motor drives. Please take off any metal objects, such as watches and rings, before operation. And only insulated tools are allowed.
- 3. Never reassemble internal components or wiring.
- 4. Prevent static electricity.

Periodical Maintenance

#### Ambient environment

Check Items	Methods and Criterion	Maintenance Period		
Check Items Methods and Cri	Methods and Officeron	Daily	Half Year	One Year
Check the ambient temperature, humidity, vibration and see if there are any dust, gas, oil or water drops	Visual inspection and measurement with equipment with standard specification	0		
Check if there are any dangerous objects in the environment	Visual inspection	0		

## Voltage

Check Items	Methods and Criterion		Maintenance Period		
			Half Year	One Year	
Check if the voltage of main circuit and control circuit is correct	Measure with multimeter with standard specification	0			



# Keypad

Charle Marrie	Methods and Criterion		Maintenance Period		
Check Items			Half Year	One Year	
Is the display clear for reading?	Visual inspection	0			
Any missing characters?	Visual inspection	0			

## Mechanical parts

Check Items	Methods and Criterion		Maintenance Period		
Check items			Half Year	One Year	
If there is any abnormal sound or vibration	Visual and aural inspection		0		
If there are any loose screws	Tighten the screws		0		
If any part is deformed or damaged	Visual inspection		0		
If there is any color change by overheating	Visual inspection		0		
If there is any dust or dirt	Visual inspection		0		

### Main circuit

Check Items	Methods and Criterion		Maintenance Period		
	Daily	Half Year	One Year		
If there are any loose or missing screws	Tighten or replace the screw	0			
If machine or insulator is deformed, cracked, damaged or with changed color change due to overheating or ageing	Visual inspection  NOTE: Please ignore the color change of copper plate		0		
If there is any dust or dirt	Visual inspection		0		



## Terminals and wiring of main circuit

Charle Harris	Methods and Criterion		Maintenance Period		
Check Items			Half Year	One Year	
If the wiring shows change of color change or deformation due to overheat	Visual inspection		0		
If the insulation of wiring is damaged or the color has changed	Visual inspection		0		
If there is any damage	Visual inspection		0		

## DC capacity of main circuit

Charle Harra	Methods and Criterion	Maintenance Period				
Check Items	Methods and Criterion	Daily	Half Year	One Year		
If there is any leakage of liquid, change of color, cracks or deformation	Visual inspection	0				
Measure static capacity when required	Static capacity ≥ initial value X 0.85		0			

## Resistor of main circuit

Charle Marris	Mathada and Critarian		intenar Period	
Check Items	Methods and Criterion	Daily		One Year
If there is any peculiar smell or insulator cracks due to overheating	Visual inspection, smell		0	
If there is any disconnection	Visual inspection or measure with multimeter after removing wiring between +/B1 ~ -		0	
	Resistor value should be within $^\pm$ 10%			



## Transformer and reactor of main circuit

Object to the	ems Methods and Criterion	_	intenar Period	ice
Check Items		Daily	Half Year	One Year
If there is any abnormal vibration or peculiar smell	Visual, aural inspection and smell	0		

## Magnetic contactor and relay of main circuit

Check Items		_	intenar Period	
	Methods and Criterion	Daily	Half Year	One Year
If there are any loose screws	Visual and aural inspection. Tighten screw if necessary.	0		
If the contact works correctly	Visual inspection	0		

#### Printed circuit board and connector of main circuit

<u> </u>		Maintenance Period				
Check Items	Methods and Criterion	Daily	Half Year	One Year		
If there are any loose screws and connectors	Tighten the screws and press the connectors firmly in place.		0			
If there is any peculiar smell and color change	Visual inspection and smell		0			
If there is any crack, damage, deformation or corrosion	Visual inspection		0			
If there is any leaked liquid or deformation in capacitors	Visual inspection		0			



Cooling fan of cooling system

Object to me	M. d. d. a. d. O. d. d. d.		intenar Period	
Check Items	Methods and Criterion	Daily	Half Year	One Year
If there is any abnormal sound or vibration	Visual, aural inspection and turn the fan with hand (turn off the power before operation) to see if it rotates smoothly			0
If there is any loose screw	Tighten the screw			0
If there is any change of color due to overheating	Change fan			0

## Ventilation channel of cooling system

Charle Harris	Mathada and Oritoria		intenar Period	
Check Items	Methods and Criterion		Half Year	One Year
If there is any obstruction in the heat sink, air intake or air outlet	Visual inspection		0	

# Chapter 6 Fault Code Information and Maintenance |

This page intentionally left blank

# Appendix A Specifications

There are 115V, 230V and 460V models in the VFD-E series. For 115V models, it is 1-phase models. For 0.25 to 3HP of the 230V models, there are 1-phase/3-phase models. Refer to following specifications for details.

	Voltage Class		115V Class				
	Model Number VFD-XXXE	002	004	007			
Max	. Applicable Motor Output (kW)	0.2	0.4	0.75			
Max	. Applicable Motor Output (hp)	0.25	0.5	1.0			
	Rated Output Capacity (kVA)	0.6	1.0	1.6			
ij.	Rated Output Current (A)	1.6	2.5	4.2			
r R	Maximum Output Voltage (V)	3-Phase F	Proportional to Twice the Inp	ut Voltage			
Output Rating	Output Frequency (Hz)	0.1~600 Hz					
Ō	Carrier Frequency (kHz)	1-15					
-	Rated Input Current (A)	Single-phase					
ting	Rated input Current (A)	6	9	18			
Input Rating	Rated Voltage/Frequency	Single phase, 100-120V, 50/60Hz					
ndu	Voltage Tolerance	± 10%(90~132 V)					
_	Frequency Tolerance	± 5%(47~63 Hz)					
Coc	oling Method	Natural	Fan Cooling				
Wei	ight (kg)	1.2	1.2	1.2			

	Voltage Class					230V	Class				
	Model Number VFD-XXXE	002	004	007	015	022	037	055	075	110	150
Ma (kV	x. Applicable Motor Output /)	0.2	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15
Ма	x. Applicable Motor Output (hp)	0.25	0.5	1.0	2.0	3.0	5.0	7.5	10	15	20
б	Rated Output Capacity (kVA)	0.6	1.0	1.6	2.9	4.2	6.5	9.5	12.5	17.1	25
Rating	Rated Output Current (A)		2.5	4.2	7.5	11.0	17	25	33	45	65
t R	Maximum Output Voltage (V)			3-	Phase P	roportion	nal to Inp	ut Volta	ge		
Output	Output Frequency (Hz)					0.1~6	00 Hz				
	Carrier Frequency (kHz)					1-	15				
	Rated Input Current (A)	Single/3-phase 3-phase									
ing	Nated Input Current (A)	4.9/1.9	6.5/2.7	9.5/5.1	15.7/9	24/15	20.6	26	34	48	70
ut Rating	Rated Voltage/Frequency	Single/3-phase 3-phase 200-240 V, 50/60Hz 200-240V, 50/60Hz									
Input	Voltage Tolerance	<u>+</u> 10%(180~264 V)									
	Frequency Tolerance	± 5%(47~63 Hz)									
Co	ooling Method	Natural Cooling Fan Cooling									
W	eight (kg)	1.1	1.1	1.1	*1.2/1.9	1.9	1.9	3.5	3.5	3.57	6.6

\*NOTE: the weight for VFD015E23P is 1.2kg.



	Voltage Class		_			46	0V Cla	ss				
N	Model Number VFD-XXXE	004	007	015	022	037	055	075	110	150	185	220
Max. A	Applicable Motor Output (kW)	0.4	0.75	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22
Max. A	Applicable Motor Output (hp)	0.5	1.0	2.0	3.0	5.0	7.5	10	15	20	25	30
БL	Rated Output Capacity (kVA)	1.2	2.0	3.3	4.4	6.8	9.9	13.7	18.3	24	29	34
Output Rating	Rated Output Current (A)	1.5	2.5	4.2	5.5	8.2	13	18	24	32	38	45
tput	Maximum Output Voltage (V)				3-Phase	Propo	rtional t	o Input	Voltage	9		
õ	Output Frequency (Hz)					0.1~600 Hz						
	Carrier Frequency (kHz)						1-15					
						3	3-phase	;				
ting	Rated Input Current (A)	1.9	3.2	4.3	7.1	11.2	14	19	26	35	41	49
nput Rating	Rated Voltage/Frequency				3-pl	hase, 3	80-480	V, 50/60	OHz			
ᅄ	Voltage Tolerance	± 10%(342~528V)										
	Frequency Tolerance					± 59	%(47~6	3Hz)				
Coolir	ng Method		ural				Fa	n Cooli	ng			
Weigh	nt (ka)	1.2 1.2 1.2 1.9 1.9 4.2 4.2 4.2 7.47 7.47 7.					7.47					

			General Specifications				
	Control Sys	tem	SPWM(Sinusoidal Pulse Width Modulation) control (V/f or sensorless vector control)				
	Frequency Setting Resolution		0.01Hz				
	Output Freq	juency Resolution	0.01Hz				
Control Characteristics	Torque Cha	racteristics	Including the auto-torque/auto-slip compensation; starting torque can be 150% at 3.0Hz				
cter	Overload Er	ndurance	150% of rated current for 1 minute				
ara	Skip Frequency		Three zones, setting range 0.1-600Hz				
5	Accel/Decel Time		0.1 to 600 seconds (2 Independent settings for Accel/Decel time)				
ntro	Stall Prevention Level		Setting 20 to 250% of rated current				
Ö	DC Brake		Operation frequency 0.1-600.0Hz, output 0-100% rated current Start time 0-60 seconds, stop time 0-60 seconds				
	Regenerate	d Brake Torque	Approx. 20% (up to 125% possible with optional brake resistor or external mounted brake unit, 1-15hp (0.75-11kW) models have brake chopper built-				
	V/f Pattern		4-point adjustable V/f pattern				
	Frequency	Keypad	Setting by 🕒 🔻				
Operating Characteristics	Setting	External Signal	Potentiometer-5k $\Omega$ /0.5W, 0 to +10VDC, 4 to 20mA, RS-485 interface; Multi-function Inputs 3 to 9 (15 steps, Jog, up/down)				
Jara	Operation	Keypad	Set by RUN and STOP				
ing C	Setting Signal	External Signal	2 wires/3 wires (MI1, MI2, MI3), JOG operation, RS-485 serial interface (MODBUS), programmable logic controller				
Operal	Multi-functio	on Input Signal	Multi-step selection 0 to 15, Jog, accel/decel inhibit, 2 accel/decel switches, counter, external Base Block, ACI/AVI selections, driver reset, UP/DOWN key settings, NPN/PNP input selection				

		General Specifications			
	Multi-function Output Indication	AC drive operating, frequency attained, zero speed, Base Block, fault indication, overheat alarm, emergency stop and status selections of input terminals			
	Analog Output Signal	AC drive operating, frequency attained, zero speed, Base Block, fault indication, overheat alarm, emergency stop and status selections of inp terminals  Output frequency/current  Contact will be On when drive malfunctions (1 Form C/change-over con and 1 open collector output) for standard type)  Built-in PLC(NOT for CANopen models), AVR, accel/decel S-Curve, ow voltage/over-current stall prevention, 5 fault records, reverse inhibition, momentary power loss restart, DC brake, auto torque/slip compensation auto tuning, adjustable carrier frequency, output frequency limits, paran lock/reset, vector control, PID control, external counter, MODBUS communication, abnormal reset, abnormal re-start, power-saving, fan of sleep/wake frequency, 1st/2nd frequency source selections, 1st/2nd frequency source combination, NPN/PNP selection, parameters for mot to motor 3, DEB and OOB (Out Of Balance Detection)(for washing mac Over voltage, ever current, under voltage, external fault, overload, groufault, overheating, electronic thermal, IGBT short circuit, PTC  6-key, 7-segment LED with 4-digit, 5 status LEDs, master frequency, output current, custom units, parameter values for setup and faults, RUN, STOP, RESET, FWD/REV, PLC  VFD002E11T/21T/23T, VFD004E11T/21T1/23T/43T, VFD007E21T/23T/VFD015E23A/23C/43A/43C, VFD035E23A/23C/43A/43C,			
	Alarm Output Contact	Contact will be On when drive malfunctions (1 Form C/change-over contact and 1 open collector output) for standard type)			
	Operation Functions	momentary power loss restart, DC brake, auto torque/slip compensation, auto tuning, adjustable carrier frequency, output frequency limits, parameter lock/reset, vector control, PID control, external counter, MODBUS communication, abnormal reset, abnormal re-start, power-saving, fan control,			
	Protection Functions				
Display Keypad (optional) frequency, output cur		6-key, 7-segment LED with 4-digit, 5 status LEDs, master frequency, output frequency, output current, custom units, parameter values for setup and lock, faults, RUN, STOP, RESET, FWD/REV, PLC			
	Built-in Brake Chopper	VFD022E21A/21C/23A/23C/43A/43C, VFD037E23A/23C/43A/43C, VFD055E23A/23C/43A/43C, VFD075E23A/23C/43A/43C, VFD110E23A/23C/43A/43C, VFD150E23A/23C/43A/43C,			
	Built-in EMI Filter	For 230V 1-phase and 460V 3-phase models.			
	Enclosure Rating	IP20			
ons	Pollution Degree	2			
onditi	Installation Location	Altitude 1,000 m or lower, keep from corrosive gasses, liquid and dust			
Environmental Conditions	Ambient Temperature	-10°C to 50°C (40°C for side-by-side mounting) Non-Condensing and not frozen			
ironme	Storage/ Transportation Temperature	-20 °C to 60 °C			
Ē	Ambient Humidity	Below 90% RH (non-condensing)			
	Vibration	9.80665m/s <sup>2</sup> (1G) less than 20Hz, 5.88m/s <sup>2</sup> (0.6G) at 20 to 50Hz			
Арр	rovals	( E c ll us C			



This page intentionally left blank

# Appendix B Accessories


## **B.1 All Brake Resistors & Brake Units Used in AC Motor Drives**

Note: Please only use DELTA resistors and recommended values. Other resistors and values will void Delta's warranty. Please contact your nearest Delta representative for use of special resistors. The brake unit should be at least 10 cm away from AC motor drive to avoid possible interference. Refer to the "Brake unit Module User Manual" for further details.

Voltage	Applicable Motor		AC Drive Part No.	Full Load	Equivalent Resistor Value	Brake Unit P No. and	art	Brake Resisto		Brake Torque	Min. Equivalent Resistor Value
lοΛ	hp	kW		KG-M	Torque (recommended) Quantit			Quantity		10%ED	for each AC Motor Drive
	0.25	0.2	VFD002E11A/11C/11P	0.110	200W 250Ω	BUE-20015	1	BR200W250	1	320	200Ω
Series	0.23	0.2	VFD002E11T	0.110	200W 250Ω			BR200W250	1	320	200Ω
/ Se	0.5	0.4	VFD004E11A/11C/11P	0.040	200W 250Ω	BUE-20015	1	BR200W250	1	170	100Ω
115V	0.5	0.4	VFD004E11T	0.216	200W 250Ω			BR200W250	1	170	100Ω
,	1	0.75	VFD007E11A/11C/11P	0.427	200W 150Ω			BR200W150	1	140	80Ω
	0.25	0.2	VFD002E21A/21C/21P/23A 23C/23P	0.110	200W 250 Ω	BUE-20015	1	BR200W250	1	320	200Ω
			VFD002E21T/23T		200W 250Ω			BR200W250	1	320	200Ω
	0.5	0.4	VFD004E21A/21C/21P/23A /23C/23P	0.216	200W 250 Ω	BUE-20015	1	BR200W250	1	170	100Ω
			VFD004E21T/23T		200W 250Ω			BR200W250	1	170	100Ω
S	1	0.75	VFD007E21A/21C/21P/23A /23C/23P	0.427	200W 150Ω	BUE-20015	1	BR200W150	1	140	80Ω
Series			VFD007E21T/23T		200W 150Ω			BR200W150	1	140	80Ω
s >			VFD015E21A/21C		300W 85Ω			-		125	40Ω
230V	2	1.5	VFD015E23T	0.849	300W 85Ω			-		125	80Ω
2			VFD015E23A/23C/23P		300W 85Ω	BUE-20015	1	-		125	80Ω
	3	2.2	VFD022E21A/21C/23A/23C	1.262	600W 50Ω			-		120	40Ω
	5	3.7	VFD037E23A/23C	2.080	600W 50Ω			-		107	40Ω
	7.5	5.5	VFD055E23A/23C	3.111	800W 37.5Ω			-		85	<b>34</b> Ω
	10	7.5	VFD075E23A/23C	4.148	1200W 25Ω			-		90	<b>24</b> Ω
	15	11	VFD110E23A/23C	6.186	1200W 8Ω			BR1K2W008	2	100	8Ω
	20	15	VFD150E23A/23C	8.248	3000W 10Ω			BR1K5W005	2	119	10Ω
	0.5	0.4	VFD004E43A/43C/43P	0.216	300W 400Ω	BUE-40015	1	BR300W400	1	400	400Ω
	0.5	0.4	VFD004E43T	0.210	300W 400Ω			BR300W400	1	400	400Ω
	1	0.75	VFD007E43A/43C/43P	0.427	300W 400Ω	BUE-40015	1	BR300W400	1	200	200Ω
	'	0.75	VFD007E43T	0.427	300W 400Ω			BR300W400	1	200	200Ω
	•	4.5	VFD015E43A/43C/43P	0.040	400W 300Ω	BUE-40015	1	BR200W150	2	140	160Ω
Series	2	1.5	VFD015E43T	0.849	400W 300Ω			BR200W150	2	140	160Ω
Seri	3	2.2	VFD022E43A/43C	1.262	600W 200Ω			BR300W400	2	140	140Ω
>	5	3.7	VFD037E43A/43C	2.080	750W 140Ω			-		125	96Ω
460V	7.5	5.5	VFD055E43A/43C	3.111	1100W 96Ω			-		120	96Ω
	10	7.5	VFD075E43A/43C	4.148	1500W 69Ω			-		125	69Ω
	15	11	VFD110E43A/43C	6.186	2000W 53Ω			-		108	53Ω
	20	15	VFD150E43A/43C	8.248	4800W 32Ω			BR1K2W008	4	151	31Ω
	25	18.5	VFD185E43A/43C	10.281	4800W 32Ω			BR1K2W008	4	121	31Ω
	30	22	VFD220E43A/43C	12.338	4800W 32Ω			BR1K2W008	4	100	31Ω




- Please select the brake unit and/or brake resistor according to the table. "-" means no Delta product. Please use the brake unit according to the Equivalent Resistor Value.
- If damage to the drive or other equipment is due to the fact that the brake resistors and the brake modules in use are not provided by Delta, the warranty will be void.
- 3. Take into consideration the safety of the environment when installing the brake resistors.
- If the minimum resistance value is to be utilized, consult local dealers for the calculation of the power in Watt.
- Please select thermal relay trip contact to prevent resistor over load. Use the contact to switch power off to the AC motor drive!
- 6. When using more than 2 brake units, equivalent resistor value of parallel brake unit can't be less than the value in the column "Minimum Equivalent Resistor Value for Each AC Drive" (the right-most column in the table).
- Please read the wiring information in the user manual of the brake unit thoroughly prior to installation and operation.
- When using with the brake resistor or brake unit, it needs to disable over-voltage stall
  prevention function (set Pr.06.00 to 0). It is recommended to disable AVR (auto voltage
  regulation) function (set Pr.08.18 to 1).
- 9. Definition for Brake Usage ED%
  - Explanation: The definition of the barking usage ED(%) is for assurance of enough time for the brake unit and brake resistor to dissipate away heat generated by braking. When the brake resistor heats up, the resistance would increase with temperature, and brake torque would decrease accordingly. Suggested cycle time is one minute



10. For safety reasons, install a thermal overload relay between brake unit and brake resistor. Together with the magnetic contactor (MC) in the mains supply circuit to the drive it offers protection in case of any malfunctioning. The purpose of installing the thermal overload relay is to protect the brake resistor against damage due to frequent brake or in case the brake unit is continuously on due to unusual high input voltage. Under these circumstances the thermal overload relay switches off the power to the drive. Never let the thermal overload relay switch off only the brake resistor as this will cause serious damage to the AC Motor Drive.






Note1: When using the AC drive with DC reactor, please refer to wiring diagram in the AC drive user manual for the wiring of terminal +(P) of Brake unit.

Note2: **Do NOT** wire terminal -(N) to the neutral point of power system.

## **B.1.1 Dimensions and Weights for Brake Resistors**


(Dimensions are in millimeter)

Order P/N: BR080W200, BR080W750, BR300W100, BR300W250, BR300W400, BR400W150, BR400W040




Model no.	L1	L2	Н	D	W	Max. Weight (g)
BR080W200	140	125	20	5.3	60	160
BR080W750	140	120	20	0.0	00	100
BR300W100						
BR300W250	215	200	30	5.3	60	750
BR300W400						
BR400W150	005	050	00		00	000
BR400W040	265	250	30	5.3	60	930

## Order P/N: BR500W030, BR500W100, BR1KW020, BR1KW075




Model no.	L1	L2	Н	D	W	Max. Weight (g)
BR500W030						
BR500W100	335	320	30	5.3	60	1100
BR1KW020						
BR1KW075	400	385	50	5.3	100	2800


### Order P/N: BR1K0W050



## Order P/N: BR1K0W050, BR1K2W008, BR1K2W6P8, BR1K5W005, BR1K5W040



## Order P/N: BR200W150, BR200W250



Model no.	L1±2	L2±2	L3±2	W±1	H±1
BR200W150					
BR200W250	165	150	110	30	60


# **B.1.2 Specifications for Brake Unit**


		230V	Series	460V Series		
1	Model Name BUE-XXXXX	20015	20037	40015	40037	
	Max. Motor Power (kW)	1.5	3.7	30	45	
Output Rating	Max. Peak Discharge Current (A) 10%ED	3.6	3.7	1.5	3.7	
Q %	Brake Start-up Voltage (DC)	328/345/362	/380/400±3V	656/690/725	/760/800±6V	
Power	DC Voltage	200~400VDC		400~800VDC		
ction	Heat Sink Overheat	Temperature	e over +100°C (	212°F)		
Protection	Power Charge Display	Blackout unt	til bus (P~N) vol	tage is below 5	0VDC	
#	Installation Location	Indoor (no corrosive gases, metallic dust)				
Environment	Operating Temperature	-10°C ~ +50°C (14°F to 122°F)				
Storage Temperature		-20°C ~ +60°C (-4°F to 140°F)				
N	Humidity	90% Non-condensing				
Vibration 9.8m/s <sup>2</sup> (1G) under 20Hz, 2m/s <sup>2</sup> (				m/s² (0.2G) at 2	0~50Hz	
W	all-mounted Enclosed Type	IP20				





# **B.1.3 Dimensions for Brake Unit**

(Dimensions are in millimeter[inch])













## **B.1.4 DIN Rail Installation**





## **B.2 No-fuse Circuit Breaker Chart**

For 1-phase/3-phase drives, the current rating of the breaker shall be within 2-4 times rated input current.

1-phase	•	3-phase			
Model	Recommended no-fuse breaker (A)	Model	Recommended no-fuse breaker (A)		
VFD002E11A/11T/11C/ 11P	15	VFD002E23A/23C/23T/ 23P	5		
VFD002E21A/21T/21C/ 21P	10	VFD004E23A/23C/23T/ 23P	5		
VFD004E11A/11C/11T/ 11P	20	VFD004E43A/43C/43T/ 43P	5		
VFD004E21A/21C/21T/ 21P	15	VFD007E23A/23C/23T/ 23P	10		
VFD007E11A/11C	30	VFD007E43A/43C/43T/ 43P	5		
VFD007E21A/21C/21T/ 21P	20	VFD015E23A/23C/23T/ 23P	20		
VFD015E21A/21C	30	VFD015E43A/43C/43T/ 43P	10		
VFD022E21A/21C	50	VFD022E23A/23C	30		
		VFD022E43A/43C	15		
		VFD037E23A/23C	40		
		VFD037E43A/43C	20		
		VFD055E23A/23C	50		
		VFD055E43A/43C	30		
		VFD075E23A/23C	60		
		VFD075E43A/43C	40		
		VFD110E23A/23C	100		
		VFD110E43A/43C	50		
		VFD150E23A/23C	150		
		VFD150E43A/43C	70		
		VFD185E43A/43C	80		
		VFD220E43A/43C	100		

# **B.3 Fuse Specification Chart**

Smaller fuses than those shown in the table are permitted.

Model	I (A)	I (A)	Line Fuse			
Model	Input	Output	I (A)	Bussmann P/N		
VFD002E11A/11T/11C/ 11P	6	1.6	15	JJN-15		
VFD002E21A/21T/21C /21P	4.9	1.6	10	JJN-10		
VFD002E23A/23C/23T /23P	1.9	1.6	5	JJN-6		
VFD004E11A/11C/11T/ 11P	9	2.5	20	JJN-20		
VFD004E21A/21C/21T /21P	6.5	2.5	15	JJN-15		
VFD004E23A/23C/23T /23P	2.7	2.5	5	JJN-6		
VFD004E43A/43C/43T /43P	1.9	1.5	5	JJS-6		
VFD007E11A/11C	18	4.2	30	JJN-30		
VFD007E21A/21C/21T /21P	9.7	4.2	20	JJN-20		
VFD007E23A/23C/23T /23P	5.1	4.2	10	JJN-10		
VFD007E43A/43C/43T /43P	3.2	2.5	5	JJS-6		
VFD015E21A/21C	15.7	7.5	30	JJN-30		
VFD015E23A/23C/23T /23P	9	7.5	20	JJN-20		
VFD015E43A/43C/43T /43P	4.3	4.2	10	JJS-10		
VFD022E21A/21C	24	11	50	JJN-50		
VFD022E23A/23C	15	11	30	JJN-30		
VFD022E43A/43C	7.1	5.5	15	JJS-15		
VFD037E23A/23C	20.6	17	40	JJN-40		
VFD037E43A/43C	11.2	8.2	20	JJS-20		
VFD055E23A/23C	26	25	50	JJN-50		

## Appendix B Accessories | Warner

Model	I (A)	I (A)	Line Fuse		
iviodei	Input	Output	I (A)	Bussmann P/N	
VFD055E43A/43C	14	13	30	JJS-30	
VFD075E23A/23C	34	33	60	JJN-60	
VFD075E43A/43C	19	18	40	JJS-40	
VFD110E23A/23C	48	45	100	JJN-100	
VFD110E43A/43C	26	24	50	JJS-50	
VFD150E23A/23C	70	65	150	JJN-150	
VFD150E43A/43C	35	32	70	JJN-70	
VFD185E43A/43C	41	38	80	JJN-80	
VFD220E43A/43C	49	45	100	JJN-100	

### **B.4 AC Reactor**

# **B.4.1 AC Input Reactor Recommended Value**

230V, 50/60Hz, 1-Phase

1-10/	HP	Fundamental Amps	Max. continuous	Inductance (mH)
kW			Amps	3~5% impedance
0.2	1/4	4	6	6.5
0.4	1/2	5	7.5	3
0.75	1	8	12	1.5
1.5	2	12	18	1.25
2.2	3	18	27	0.8

230V, 50/60Hz, 3-Phase

		Fundamental	Max. continuous	Inductance (mH)		
kW	HP	Amps	Amps	3% impedance	5% impedance	
0.2	1/4	2	3	9	20	
0.4	1/2	2	3	6.5	12	
0.75	1	4	6	3	6.5	
1.5	2	8	12	1.5	3	

		Fundamental	Max. continuous	Inductance (mH)	
kW HP		Amps	Amps	3% impedance	5% impedance
2.2	3	12	18	1.25	2.5
3.7	5	18	27	0.8	1.5
5.5	7.5	25	37.5	0.5	1.2
7.5	10	35	52.5	0.4	8.0
11	15	45	67.5	0.3	0.5

460V, 50/60Hz, 3-Phase

kW HP		ID Fundamental	Max.	Inductance (mH)		
KVV	ПР	Amps	continuous Amps	3% impedance	5% impedance	
0.4	1/2	2	3	20	32	
0.75	1	4	6	9	12	
1.5	2	4	6	6.5	9	
2.2	3	8	12	5	7.5	
3.7	5	8	12	3	5	
5.5	7.5	12	18	2.5	4.2	
7.5	10	18	27	1.5	2.5	
11	15	25	37.5	1.2	2	
15	20	35	52.5	0.8	1.2	
18.5	25	35	52.5	0.8	1.2	
22	30	45	67.5	0.7	1.2	

# **B.4.2 AC Output Reactor Recommended Value**

115V/230V, 50/60Hz, 3-Phase

kW	HP	Fundamental	Max. continuous Amps	Inductance (mH)		
KVV	пР	Amps		3% impedance	5% impedance	
0.2	1/4	4	4	9	12	
0.4	1/2	6	6	6.5	9	
0.75	1	8	12	3	5	
1.5	2	8	12	1.5	3	
2.2	3	12	18	1.25	2.5	
3.7	5	18	27	0.8	1.5	

#### Appendix

B Accessories	VED-E
---------------	-------

kW HP		HP Fundamental Amps	Max. continuous Amps	Inductance (mH)		
KVV   HP	3% impedance			5% impedance		
5.5	7.5	25	37.5	0.5	1.2	
7.5	10	35	52.5	0.4	0.8	
11	15	55	82.5	0.25	0.5	
15	20	80	120	0.2	0.4	

## 460V, 50/60Hz, 3-Phase


114/	LID	Fundamental	Max.	Inductance (mH)	
kW	HP	Amps	continuous Amps	3% impedance	5% impedance
0.4	1/2	2	3	20	32
0.75	1	4	6	9	12
1.5	2	4	6	6.5	9
2.2	3	8	12	5	7.5
3.7	5	12	18	2.5	4.2
5.5	7.5	18	27	1.5	2.5
7.5	10	18	27	1.5	2.5
11	15	25	37.5	1.2	2
15	20	35	52.5	0.8	1.2
18.5	25	45	67.5	0.7	1.2
22	30	45	67.5	0.7	1.2

# **B.4.3 Applications**

Connected in input circuit


Application 1	Question
When more than one AC motor drive is connected to the same mains power, and one of them is ON during operation.	When applying power to one of the AC motor drive, the charge current of the capacitors may cause voltage dip. The AC motor drive may be damaged when over current occurs during operation.





Application 2	Question
	Switching spikes will be generated when the silicon rectifier switches on/off. These spikes may damage the mains circuit.

## Correct wiring






Application 3	Question
Used to improve the input power factor, to reduce harmonics and provide protection from AC line disturbances, (surges, switching spikes, short interruptions, etc.). The AC line reactor should be installed when the power supply capacity is 500kVA or more and exceeds 6 times the inverter capacity, or the mains wiring distance ≤ 10m.	When the mains power capacity is too large, line impedance will be small and the charge current will be too high. This may damage AC motor drive due to higher rectifier temperature.

Correct wiring			
large-capacity power	reactor	small-capacity AC motor drive	_
			—(motor)




## B.5 Zero Phase Reactor (RF220X00A)

#### Dimensions are in millimeter and (inch)








Cable type	Reco	mmend Size	Qty.	Wiring	
(Note)	AWG	mm²	Nominal (mm²)	Qiy.	Method
Single- core	≦10	≦5.3	≦5.5	1	Diagram A
	≦2	≦33.6	≦38	4	Diagram B
Three- core	≦12	≦3.3	≦3.5	1	Diagram A
	≦1	≦42.4	≦50	4	Diagram B

Note: 600V Insulated unshielded Cable.


#### Diagram A

Please wind each wire 4 times around the core. The reactor must be put at inverter output as close as possible.



### Diagram B

Please put all wires through 4 cores in series without winding.




Note 1: The table above gives approximate wire size for the zero phase reactors but the selection is ultimately governed by the type and diameter of cable fitted i.e. the cable must fit through the center hole of zero phase reactors.

Note 2: Only the phase conductors should pass through, not the earth core or screen.

Note 3: When long motor output cables are used an output zero phase reactor may be required to reduce radiated emissions from the cable.

## **B.6 Remote Controller RC-01**

### Dimensions are in millimeter



VFD-E Programming:

Pr.02.00 set to 2

Pr.02.01 set to 1 (external controls)


Pr.04.04 set to 1 (setting Run/Stop and Fwd/Rev controls)

Pr.04.07 (MI5) set to 5 (External reset)

Pr.04.08 (MI6) set to 8 (JOG operation)

#### **B.7 PU06**

# **B.7.1 Description of the Digital Keypad VFD-PU06**



## **B.7.2 Explanation of Display Message**


<u> </u>	Descriptions
Display Message	Descriptions
<sup>*</sup> 8000	The AC motor drive Master Frequency Command.
* 5888	The Actual Operation Frequency present at terminals U, V, and W.
. 180.00	The custom unit (u)
8 5.0	The output current present at terminals U, V, and W.
r88d0	Press to change the mode to READ. Press PROG/DATA for about 2 sec or until it's flashing, read the parameters of AC drive to the digital keypad PU06. It can read 4 groups of parameters to PU06. (read 0 – read 3)
58 <sub>0</sub> 8 -	Press to change the mode to SAVE. Press PROG/DATA for about 2 sec or until it's flashing, then write the parameters from the digital keypad PU06 to AC drive. If it has saved, it will show the type of AC motor drive.



Display Message	Descriptions			
88-88	The specified parameter setting.			
10	The actual value stored in the specified parameter.			
8.8.	External Fault			
-End-	"End" displays for approximately 1 second if the entered input data have been accepted. After a parameter value has been set, the new value is automatically stored in memory. To modify an entry, use the or keys.			
-6	"Err" displays if the input is invalid.			
81-33	Communication Error. Please check the AC motor drive user manual (Chapter 5, Group 9 Communication Parameter) for more details.			

# **B.7.3 Operation Flow Chart**

### VFD-PU06 Operation Flow Chart



#### **B.8 KPE-LE02**

# B.8.1 Description of the Digital Keypad KPE-LE02



- Status Display Display the driver's current status.
- LED Display Indicates frequency, voltage, current, user defined units and etc.
- Potentiometer For master Frequency setting.
- Q RUN Key Start AC drive operation.

O UP and DOWN Key

Set the parameter number and changes the numerical data, such as Master Frequency.

- O MODE Change between different display mode.
- STOP/RESET Stops AC drive operation and reset the drive after fault occurred.
- O ENTER Used to enter/modify programming parameters

Display Message	Descriptions			
RUN• FWD• REV•	Displays the AC drive Master Frequency.			
RUN• FWD• REV•	Displays the actual output frequency at terminals U/T1, V/T2, and W/T3.			
RUN• FWD• REV•	User defined unit (where U = F x Pr.00.05)			
RUN• FWD• REV•	Displays the output current at terminals U/T1, V/T2, and W/T3.			
RUN• FWD• REV•	Displays the AC motor drive forward run status.			
RUN• FWD• REV•	Displays the AC motor drive reverse run status.			
RUN• FWD• REV•	The counter value (C).			
RUN- FWD- REV-	Displays the selected parameter.			

### Appendix B Accessories


Display Message	Descriptions		
RUN• FWD• REV•	Displays the actual stored value of the selected parameter.		
RUN• FWD• REV•	External Fault.		
RUN- FWO: End .	Display "End" for approximately 1 second if input has been accepted by pressing Key. After a parameter value has been set, the new value is automatically stored in memory. To modify an entry, use the keys.		
RUN• FW0• REV•	Display "Err", if the input is invalid.		



When the setting exceeds 99.99 for those numbers with 2 decimals (i.e. unit is 0.01), it will only display 1 decimal due to 4-digital display.



### B.8.2 How to Operate the Digital Keypad




# **B.8.3 Reference Table for the 7-segment LED Display of the Digital Keypad**

Digit	0	1	2	3	4	5	6	7	8	9
LED Display	0	;	2	3	낙	5	8	7	8	3
English alphabet	Α	а	В	С	С	D	d	Е	е	F
LED Display	ß	_	_	E	c	_	ď	ε	_	F
English alphabet	f	G	g	Н	h	ı	i	J	j	K
LED Display	-	G	_	X	ሖ	1	-	J	-	۲
English alphabet	k	L	1	М	m	N	n	0	0	Р
LED Display	_	L	_	<i>:</i> :	_	_	n	0	0	ρ
English alphabet	р	Q	q	R	r	S	s	Т	t	U
LED Display	_	_	9	_	<i></i>	5	_	7	E	U
English alphabet	u	V	v	W	w	Х	x	Υ	у	Z
LED Display	_	_	U	_	_	_	_	3	_	=
English alphabet	Z									
LED Display	_									

# **B.8.4 Keypad Dimensions**

(Dimensions are in millimeter[inch])






### **B.9 Extension Card**

For details, please refer to the separate instruction shipped with these optional cards or download from our website http://www.delta.com.tw/industrialautomation/.

Installation method




# **B.9.1 Relay Card**





# **B.9.2 Digital I/O Card**


#### EME-D33A





# B.9.3 Analog I/O Card

### EME-A22A





# **B.9.4 Communication Card**


### CME-USB01







# **B.9.5 Speed Feedback Card**




### **B.10 Fieldbus Modules**

# **B.10.1 DeviceNet Communication Module (CME-DN01)**




# **B.10.1.1 Panel Appearance and Dimensions**

1. For RS-485 connection to VFD-E 2. Communication port for connecting DeviceNet network 3. Address selector 4. Baud rate selector 5. Three LED status indicators for monitor. (Refer to the figure below)




### **B.10.1.2 Wiring and Settings**

Refer to following diagram for details.



# **B.10.1.3 Mounting Method**

Step1 and step2 show how to mount this communication module onto VFD-E. The dimension on the left hand side is for your reference.



# **B.10.1.4 Power Supply**

No external power is needed. Power is supplied via RS-485 port that is connected to VFD-E. An 8 pins RJ-45 cable, which is packed together with this communication module, is used to connect the RS-485 port between VFD-E and this communication module for power. This communication module will perform the function once it is connected. Refer to the following paragraph for LED indications.

# B.10.1.5 LEDs Display

- 1. **SP:** Green LED means in normal condition, Red LED means abnormal condition.
- Module: Green blinking LED means no I/O data transmission, Green steady LED means
   I/O data transmission OK
  - Red LED blinking or steady LED means module communication is abnormal.
- Network: Green LED means DeviceNet communication is normal, Red LED means abnormal



Refer to user manual for detail information-- Chapter 5 Troubleshooting.



### **B.10.2 LonWorks Communication Module (CME-LW01)**




#### B.10.2.1 Introduction

Device CME-LW01 is used for communication interface between Modbus and LonTalk. CME-LW01 needs be configured via LonWorks network tool first, so that it can perform the

function on LonWorks network. No need to set CME-LW01 address.

This manual provides instructions for the installation and setup for CME-LW01 that is used to communicate with Delta VFD-E (firmware version of VFD-E should conform with CME-LW01 according to the table below) via LonWorks Network.

#### B.10.2.2 Dimensions



# **B.10.2.3 Specifications**

Power supply: 16-30VDC, 750mW


Communication: Modbus in ASCII format, protocol: 9600, 7, N, 2

I onTalk: free topology with FTT-10A 78 Kbps.

LonTalk terminal: 4-pin terminals, wire gauge: 28-12 AWG, wire strip length: 7-8mm

RS-485 port: 8 pins with RJ-45

# **B.10.2.4 Wiring**



### Terminal definition for LonTalk system

Terminal	Symbol	Function
2	$\infty$	These are twisted pair cables to connect to LonTalk system. Terminals 1 and 2 should be used as one group, and the
3	$\infty$	same for terminals 3 and 4.

### **B.10.2.5 LED Indications**


There are three LEDs in front panel of CME-LW01. If the communication is normal, power LED, SP LED should be green (red LED means abnormal communication) and service LED should be OFF. If LEDs display do not match, refer to user manual for details.


# **B.10.3 Profibus Communication Module (CME-PD01)**





# **B.10.3.1 Panel Appearance**






- 1. SP LED: Indicating the connection status between VFD-E and CME-PD01.
- 2. NET LED: Indicating the connection status between CME-PD01 and PROFIBUS-DP.
- 3. Address Switches: Setting the address of CME-PD01 on PROFIBUS- DP network.
- RS-485 Interface (RJ45): Connecting to VFD-E, and supply power to CME-PD01. 4.
- 5 PROFIBUS-DP Interface (DB9): 9-PIN connector that connects to PROFIBUS-DP network
- Extended Socket: 4-PIN socket that connects to PROFIBUS-DP network. 6.



#### **B.10.3.2 Dimensions**



### **B.10.3.3 Parameters Settings in VFD-E**

	VFD-E
Baud Rate 9600	Pr.09.01=1
RTU 8, N, 2	Pr.09.04=3
Freq. Source	Pr.02.00=4
Command Source	Pr.02.01=3

# **B.10.3.4 Power Supply**

The power of CME-PD01 is supplied from VFD-E. Please connect VFD-E to CME-PD01 by using 8 pins RJ-45 cable, which is packed together with CME-PD01. After connection is completed, CME-PD01 is powered whenever power is applied to VFD-E.

### **B.10.3.5 PROFIBUS Address**



CME-PD01 has two rotary switches for the user to select the PROFIBUS address. The set value via 2 address switches, ADDH and ADDL, is in HEX format. ADDH sets the upper 4 bits, and ADDL sets the lower 4 bits of the PROFIBUS address.




Address	Meaning
10x7D	Valid PROFIBUS address
0 or 0x7E0xFE	Invalid PROFIBUS address

# B.10.4 CME-COP01 (CANopen)

CME-COP01 CANopen communication module is specifically for connecting to CANopen communication module of Delta VFD-E AC motor drive.



# **B.10.4.1 Product Profile**



①	COM port
2	CANopen connection port
3	RUN indicator
4	ERROR indicator
(5)	SP (Scan Port) indicator
6	Baud rate switch
7	Address switch

# **B.10.4.2 Specifications**

### **CANopen Connection**

Interface	Pluggable connector (5.08mm)		
Transmission method	CAN		
Transmission cable	2-wire twisted shielded cable		
Electrical isolation	500V DC		

#### Communication

Message type	Process Data Objects (PDO) Service Data Object (SDO) Synchronization (SYNC) Emergency (EMCY) Network Management (NMT)	Baud rate	10 Kbps 20 Kbps 50 Kbps 125 Kbps 250 Kbps 500 Kbps 500 Kbps 1 Mbps
Product code	Delta VFD-E AC motor drive 22		
Device type	402		
Vendor ID	477		

#### Environmental Specifications


Environment	Environmental Specifications				
Noise Immunity	ESD(IEC 61131-2, IEC 61000-4-2): 8KV Air Discharge EFT(IEC 61131-2, IEC 61000-4-4): Power Line: 2KV, Digital I/O: 1KV, Analog & Communication I/O: 1KV Damped-Oscillatory Wave: Power Line: 1KV, Digital I/O: 1KV RS(IEC 61131-2, IEC 61000-4-3): 26MHz ~ 1GHz, 10V/m				
Environment	Operation: 0°C ~ 55°C (Temperature), 50 ~ 95% (Humidity), Pollution degree 2; Storage: -40°C ~ 70°C (Temperature), 5 ~ 95% (Humidity)				
Vibration / Shock Resistance	Standard: IEC1131-2, IEC 68-2-6 (TEST Fc/IEC1131-2 & IEC 68-2-27 (TEST Ea)				
Certifications	Standard: IEC 61131-2,UL508				

# **B.10.4.3 Components**

#### Pin Definition on CANopen Connection Port

To connect with CANopen, use the connector enclosed with CME-COP01 or any connectors you can buy in the store for wiring.

Pin	Signal	Content
1	CAN_GND	Ground / 0 V / V-
2	CAN_L	Signal-
3	SHIELD	Shield
4	CAN_H	Signal+
5	-	Reserved



Baud Rate Setting

Rotary switch (BR) sets up the communication speed on CANopen network in hex. Setup range: 0 ~ 7 (8 ~F are forbidden)





Example: If you need to set up the communication speed of CME-COP01 as 500K, simply switch BR to "5"

BR Value	Baud rate	BR Value	Baud rate	
0	10K	4	250K	
1	20K	5	500K	
2	50K	6	800K	
3	125K	7	1M	

#### MAC ID Setting

Rotary switches (ID L and ID H) set up the Node-ID on CANopen network in hex. Setup range: 00 ~ 7F (80 ~FF are forbidden)





Example: If you need to set up the communication address of CME-COP01 as 26(1AH), simply switch ID\_H to "1" and ID\_L to "A".

Switch Setting	Content	
0 7F	Valid CANopen MAC ID setting	
Other	Invalid CANopen MAC ID setting	

# B.10.4.4 LED Indicator Explanation & Troubleshooting

There are 3 LED indicators, RUN, ERROR and SP, on CME-COP01 to indicate the communication status of CME-COP01.

#### **RUN LED**

LED Status	State	Indication
OFF	No power	No power on CME-COP01 card
Single Flash (Green)	STOPPED	CME-COP01 is in STOPPED state
Blinking (Green)	PRE-OPERATIONAL	CME-COP01 is in the PRE- OPERATIONAL state
Green ON	OPERATIONAL	CME-COP01 is in the OPERATIONAL state
Red ON	Configuration error	Node-ID or Baud rate setting error

### ERROR LED

LED Status	State	Indication
OFF	No error	CME-COP01 is working condition
Single Flash (Red)	Warning limit reached	At least one of error counter of the CANopen controller has reached or exceeded the warning level (too many error frames)
Double Flash (Red)	Error control event	A guard event or heartbeat event has occurred
Red ON	Bus-off	The CANopen controller is bus-off

### SP LED

LED Status	State	Indication
OFF	No Power	No power on CME-COP01 card
LED Blinking (Red)	CRC check error	Check your communication setting in VFD-E drives (19200,<8,N,2>,RTU)
Red ON	Connection failure/No connection	Check the connection between VFD-E drive and CME-COP01 card is correct     Re-wire the VFD-E connection and ensure that the wire specification is correct
LED Blinking (Green)	CME-COP01 returns error code	Check the PLC program, ensure the index and sub-index is correct
Green ON	Normal	Communication is normal


# LED Descriptions


State	Description		
LED ON	Constantly on		
LED OFF	Constantly off		
LED blinking	Flash, on for 0.2s and off for 0.2s		
LED single flash	On for 0.2s and off for 1s		
LED double flash	On for 0.2s off for 0.2s, on for 0.2s and off for 1s		




# **B.11 DIN Rail**


# **B.11.1 MKE-DRA**






### B.11.2 MKE-DRB







### **B.11.3 MKE-EP**

EMC earthing plate for Shielding Cable









# Appendix C How to Select the Right AC Motor Drive

The choice of the right AC motor drive for the application is very important and has great influence on its lifetime. If the capacity of AC motor drive is too large, it cannot offer complete protection to the motor and motor maybe damaged. If the capacity of AC motor drive is too small, it cannot offer the required performance and the AC motor drive maybe damaged due to overloading.

But by simply selecting the AC motor drive of the same capacity as the motor, user application requirements cannot be met completely. Therefore, a designer should consider all the conditions, including load type, load speed, load characteristic, operation method, rated output, rated speed, power and the change of load capacity. The following table lists the factors you need to consider, depending on your requirements.

Item		Related Specification					
		Speed and torque characteristics	Time ratings	Overload capacity	Starting torque		
Load type	Friction load and weight load Liquid (viscous) load Inertia load Load with power transmission	•			•		
Load speed and torque characteristics	Constant torque Constant output Decreasing torque Decreasing output	•	•				
Load Shock load Shock load Repetitive load High starting torque Low starting torque		•	•	•	•		
	tion, Short-time operation on at medium/low speeds		•	•			
	Maximum output current (instantaneous) Constant output current (continuous)			•			
Maximum frequer	ncy, Base frequency	•					
Power supply transformer capacity or percentage impedance Voltage fluctuations and unbalance Number of phases, single phase protection Frequency				•	•		
Mechanical friction	Mechanical friction, losses in wiring			•	•		
Duty cycle modific		•					



# C.1 Capacity Formulas

#### 1. When one AC motor drive operates one motor

The starting capacity should be less than 1.5x rated capacity of AC motor drive The starting capacity=

$$\frac{k \times N}{973 \times \eta \times \cos \varphi} \left( T_L + \frac{GD^2}{375} \times \frac{N}{t_A} \right) \le 1.5 \times the \_capacity \_of \_AC \_motor \_drive(kVA)$$

#### 2. When one AC motor drive operates more than one motor

- 2.1 The starting capacity should be less than the rated capacity of AC motor drive
- Acceleration time ≤60 seconds

The starting capacity=

$$\frac{k \times N}{\eta \times \cos \varphi} \left[ n_r + n_s(k_{s-1}) \right] = P_{\text{Cl}} \left[ 1 + \frac{n_s}{n_r} \left( k_{s-1} \right) \right] \le 1.5 \times the\_capacity\_of\_AC\_motor\_drive(kVA)$$

Acceleration time ≥60 seconds

The starting capacity=

$$\frac{k \times N}{n \times \cos \varphi} \left[ n_r + n_s(k_{s-1}) \right] = P_{CI} \left[ 1 + \frac{n_s}{n_T} \left( k_{s-1} \right) \right] \le the\_capacity\_of\_AC\_motor\_drive(kVA)$$

- 2.2 The current should be less than the rated current of AC motor drive(A)
- Acceleration time ≤60 seconds

$$n_T + I_M \left[ 1 + \frac{n_S}{n_T} (k_S - 1) \right] \le 1.5 \times the\_rated\_current\_of\_AC\_motor\_drive(A)$$

Acceleration time ≥60 seconds

$$n_{\tau} + I_{M} \left[ 1 + \frac{n_{s}}{n_{\tau}} (k_{s} - 1) \right] \le the \_rated \_current \_of \_AC \_motor \_drive(A)$$



2.3 When it is running continuously

The requirement of load capacity should be less than the capacity of AC motor drive(kVA) The requirement of load capacity=

$$\frac{k \times P_M}{\eta \times \cos \varphi} \le the \_capacity\_of \_AC\_motor\_drive(kVA)$$

The motor capacity should be less than the capacity of AC motor drive

$$k \times \sqrt{3} \times V_M \times I_M \times 10^{-3} \le the \ capacity \ of \ AC \ motor \ drive(kVA)$$

The current should be less than the rated current of AC motor drive(A)

$$k \times I_M \le the\_rated\_current\_of\_AC\_motor\_drive(A)$$

#### Symbol explanation

 $P_{M}$ : Motor shaft output for load (kW)

: Motor efficiency (normally, approx. 0.85) η

 $\cos \varphi$ : Motor power factor (normally, approx. 0.75)

 $V_M$ : Motor rated voltage(V)

: Motor rated current(A), for commercial power  $I_M$ 

: Correction factor calculated from current distortion factor (1.05-1.1, depending on k

PWM method)

: Continuous motor capacity (kVA)  $P_{C1}$ 

: Starting current/rated current of motor  $k_{\rm S}$ 

: Number of motors in parallel  $n_T$ 

: Number of simultaneously started motors  $n_s$ 

: Total inertia (GD<sup>2</sup>) calculated back to motor shaft (kg m<sup>2</sup>)  $GD^2$ 

 $T_L$ : Load torque

: Motor acceleration time  $t_A$ 

Ν : Motor speed



#### C.2 General Precaution

#### Selection Note

- 1. When the AC Motor Drive is connected directly to a large-capacity power transformer (600kVA or above) or when a phase lead capacitor is switched, excess peak currents may occur in the power input circuit and the converter section may be damaged. To avoid this, use an AC input reactor (optional) before AC Motor Drive mains input to reduce the current and improve the input power efficiency.
- 2 When a special motor is used or more than one motor is driven in parallel with a single AC Motor Drive, select the AC Motor Drive current ≥1.25x(Sum of the motor rated currents).
- 3 The starting and accel./decel. characteristics of a motor are limited by the rated current and the overload protection of the AC Motor Drive. Compared to running the motor D.O.L. (Direct On-Line), a lower starting torque output with AC Motor Drive can be expected. If higher starting torque is required (such as for elevators, mixers, tooling machines, etc.) use an AC Motor Drive of higher capacity or increase the capacities for both the motor and the AC Motor Drive.
- 4 When an error occurs on the drive, a protective circuit will be activated and the AC Motor Drive output is turned off. Then the motor will coast to stop. For an emergency stop, an external mechanical brake is needed to quickly stop the motor.

#### **Parameter Settings Note**

- 1 The AC Motor Drive can be driven at an output frequency up to 400Hz (less for some models) with the digital keypad. Setting errors may create a dangerous situation. For safety, the use of the upper limit frequency function is strongly recommended.
- 2 High DC brake operating voltages and long operation time (at low frequencies) may cause overheating of the motor. In that case, forced external motor cooling is recommended.
- 3 Motor accel./decel. time is determined by motor rated torque, load torque, and load inertia.
- If the stall prevention function is activated, the accel./decel. time is automatically extended 4. to a length that the AC Motor Drive can handle. If the motor needs to decelerate within a certain time with high load inertia that can't be handled by the AC Motor Drive in the




required time, either use an external brake resistor and/or brake unit, depending on the model, (to shorten deceleration time only) or increase the capacity for both the motor and the AC Motor Drive.

#### C.3 How to Choose a Suitable Motor

#### Standard motor

When using the AC Motor Drive to operate a standard 3-phase induction motor, take the following precautions:

- 1. The energy loss is greater than for an inverter duty motor.
- 2. Avoid running motor at low speed for a long time. Under this condition, the motor temperature may rise above the motor rating due to limited airflow produced by the motor's fan. Consider external forced motor cooling.
- 3 When the standard motor operates at low speed for long time, the output load must be decreased
- 4. The load tolerance of a standard motor is as follows:



- 5. If 100% continuous torque is required at low speed, it may be necessary to use a special inverter duty motor.
- 6. Motor dynamic balance and rotor endurance should be considered once the operating speed exceeds the rated speed (60Hz) of a standard motor.

### Appendix C How to Select the Right AC Motor Drive |

- Motor torque characteristics vary when an AC Motor Drive instead of commercial power supply drives the motor. Check the load torque characteristics of the machine to be connected.
- 8. Because of the high carrier frequency PWM control of the VFD series, pay attention to the following motor vibration problems:
- Resonant mechanical vibration: anti-vibration (damping) rubbers should be used to mount equipment that runs at varying speed.
- Motor imbalance: special care is required for operation at 50 or 60 Hz and higher frequency.
- To avoid resonances, use the Skip frequencies.
- 9. The motor fan will be very noisy when the motor speed exceeds 50 or 60Hz.

#### Special motors:

1. Pole-changing (Dahlander) motor:

The rated current is differs from that of a standard motor. Please check before operation and select the capacity of the AC motor drive carefully. When changing the pole number the motor needs to be stopped first. If over current occurs during operation or regenerative voltage is too high, please let the motor free run to stop (coast).

2. Submersible motor:

The rated current is higher than that of a standard motor. Please check before operation and choose the capacity of the AC motor drive carefully. With long motor cable between AC motor drive and motor, available motor torque is reduced.

3. Explosion-proof (Ex) motor:

Needs to be installed in a safe place and the wiring should comply with the (Ex) requirements. Delta AC Motor Drives are not suitable for (Ex) areas with special precautions.

4. Gear reduction motor:

The lubricating method of reduction gearbox and speed range for continuous operation will be different and depending on brand. The lubricating function for operating long time at low speed and for high-speed operation needs to be considered carefully.

Synchronous motor:

The rated current and starting current are higher than for standard motors. Please check before operation and choose the capacity of the AC motor drive carefully. When the AC



motor drive operates more than one motor, please pay attention to starting and changing the motor


### **Power Transmission Mechanism**


Pay attention to reduced lubrication when operating gear reduction motors, gearboxes, belts and chains, etc. over longer periods at low speeds. At high speeds of 50/60Hz and above, lifetime reducing noises and vibrations may occur.


#### Motor torque


The torque characteristics of a motor operated by an AC motor drive and commercial mains power are different.

Below you'll find the torque-speed characteristics of a standard motor (4-pole, 15kW):









Appendix C How to Select the Right AC Motor Drive

This page intentionally left blank.

# Appendix D How to Use PLC Function

\* This function is NOT for VFD\*E\*C models.

#### **D.1 PLC Overview**

#### D.1.1 Introduction

The PLC function built in the VFD-E provides following commands: WPLSoft, basic commands and application commands. The operation methods are the same as Delta DVP-PLC series.

### D.1.2 Ladder Diagram Editor – WPLSoft

WPLSoft is a program editor of Delta DVP-PLC series and VFD-E series for WINDOWS. Besides general PLC program planning and general WINDOWS editing functions, such as cut, paste, copy, multi-windows, WPLSoft also provides various Chinese/English comment editing and other special functions (e.g. register editing, settings, the data readout, the file saving, and contacts monitor and set, etc.).

Following is the system requirement for WPLSoft:

Item	System Requirement
Operation System	Windows 95/98/2000/NT/ME/XP
CPU	Pentium 90 and above
Memory	16MB and above (32MB and above is recommended)
Hard Disk	Capacity: 50MB and above CD-ROM (for installing WPLSoft)
Monitor	Resolution: 640x480, 16 colors and above, It is recommended to set display setting of Windows to 800x600.
Mouse	General mouse or the device compatible with Windows
Printer	Printer with Windows driver
RS-232 port	At least one of COM1 to COM8 can be connected to PLC
Applicable Models	All Delta DVP-PLC series and VFD-E series



# D.2 Start-up

### D.2.1 The Steps for PLC Execution

Please operate PLC function by the following five steps.

- 1. Switch the mode to PLC2 for program download/upload:
  - A. Go to "PLC0" page by pressing the MODE key
  - B. Change to "PLC2" by pressing the "UP" key and then press the "ENTER" key after confirmation
  - C. If succeeded, "END" is displayed and back to "PLC2" after one or two seconds.







Read/write PLC program into AC drives



You don't need to care about the PLC warning, such as PLod, PLSv and PldA, before downloading a program to VFD-E.

2 Connection: Please connect RJ-45 of AC motor drive to computer via RS485-to-RS232 converter.



3. Run the program. The PLC status will always be PLC2, even if the AC motor drive is switched off.

There are three ways to operate PLC:

A. In "PLC1" page: execute PLC program.

- B. In "PLC2" page: execute/stop PLC program by using WPL software.
- C. After setting multi-function input terminals (MI3 to MI9) to 23 (RUN/STOP PLC), it will display "PLC1" for executing PLC when the terminal is ON. It will display "PLC0" to stop PLC program when terminals are OFF.



When external terminals are set to 23 and the terminal is ON, it cannot use keypad to change PLC mode. Moreover, when it is PLC2, you cannot execute PLC program by external terminals.





When power on after power off, the PLC status will be in "PLC1".



4. When you are in "PLC2", please remember to change to "PLC1" when finished to prevent anyone modifying PLC program.



When output/input terminals (MI1~MI9, Relay1~Relay 4, MO1~MO4) are used in PLC program, they cannot be used in other places. For example, When Y0 in PLC program is activated, the corresponding output terminals Relay (RA/RB/RC) will be used. At this moment, parameter 03.00 setting will be invalid. Because the terminal has been used by PLC.



The PLC corresponding input points for MI1 to MI6 are X0 to X5. When extension card are added, the extension input points will be numbered from X06 and output points will start from Y2 as shown in chapter D.2.2.

#### D.2.2 Device Reference Table

Device	X								
ID	0	1	2	3	4	5	6	7	10
Terminals of AC Drives	MI1	MI2	MI3	MI4	MI5	MI6			
3IN/3OUT Card (EME-D33A)	-						MI7	MI8	MI9


Device	Υ							
ID	0	1	2	3	4			
Terminals of AC Drives	RY	MO1						
Relay Card-2C (EME-DR2CA)			RY2	RY3				
Relay Card-3A (EME-R3AA)			RY2	RY3	RY4			
3IN/3OUT Card			MO2	MO3	MO4			

#### **D.2.3 WPLSoft Installation**


(EME-D33A)

Download PLC program to AC drive: Refer to D.3 to D.7 for writing program and download the editor (WPLSoft V2.09) at DELTA website

http://www.delta.com.tw/product/em/plc/plc software.asp.



# **D.2.4 Program Input**



### **D.2.5 Program Download**

Please do following s program download.

Step 1. Press button for compiler after inputting program in WPLSoft.

Step 2. After finishing compiler, choose the item "Write to PLC" in the communication items.

After finishing Step 2, the program will be downloaded from WPLSoft to the AC motor drive by the communication format.

# **D.2.6 Program Monitor**

If you execute "start monitor" in the communication item during executing PLC, the ladder diagram will be shown as follows.



### D.2.7 The Limit of PLC

- 1. The protocol of PLC is 7,E,1
- 2. Make sure that the AC drive is stop and stop PLC before program upload/download.
- 3. The priority of commands WPR and FREQ is FREQ > WPR.
- 4. When setting P 00.04 to 2, the display will be the value in PLC register D1043.
  - A. 0 ~ 999 display:



B. 1000 ~ 9999 display: It will only display the first 3 digits. The LED at the bottom-right corner will light to indicate 10 times of the display value. For example, the actual value for the following figure is 100X10=1000.



C. 10000~65535 display: It will only display the first 3 digits. The LED at the bottom-right corner and the single decimal point between the middle and the right-most numbers will light to indicate 100 times of the display value. For example, the actual value for the following figure is 100X100=10000.




- 5. When it is changed to "PLC2", RS-485 will be used by PLC.
- When it is in PLC1 and PLC2 mode, the function to reset all parameters to factory setting is disabled (i.e. Pr.00.02 can't be set to 9 or 10).



### D.3 Ladder Diagram

### D.3.1 Program Scan Chart of the PLC Ladder Diagram

Calculate the result by ladder diagram algorithm (it doesn't sent to the outer output point but the inner equipment will output immediately.)



Execute in cycles

### **D.3.2 Introduction**

Ladder diagram is a diagram language that applied on the automatic control and it is also a diagram that made up of the symbols of electric control circuit. PLC procedures are finished after ladder diagram editor edits the ladder diagram. It is easy to understand the control flow that indicated with diagram and also accept by technical staff of electric control circuit. Many basic symbols and motions of ladder diagram are the same as mechanical and electrical equipments of traditional automatic power panel, such as button, switch, relay, timer, counter and etc.

The kinds and amounts of PLC internal equipment will be different with brands. Although internal equipment has the name of traditional electric control circuit, such as relay, coil and contact. It doesn't have the real components in it. In PLC, it just has a basic unit of internal memory. If this bit is 1, it means the coil is ON and if this bit is 0, it means the coil is OFF. You should read the corresponding value of that bit when using contact (Normally Open, NO or contact a). Otherwise, you should read the opposite sate of corresponding value of that bit when using contact (Normally Closed, NC or contact b). Many relays will need many bits, such as 8-bits makes up a byte. 2 bytes can make up a word. 2 words makes up double word. When using many relays to do calculation, such as add/subtraction or shift, you could

use byte, word or double word. Furthermore, the two equipments, timer and counter, in PLC not only have coil but also value of counting time and times.

In conclusion, each internal storage unit occupies fixed storage unit. When using these equipments, the corresponding content will be read by bit, byte or word.

Basic intro	Basic introduction of the inner equipment of PLC:			
Input relay	Input relay is the basic storage unit of internal memory that corresponds to external input point (it is the terminal that used to connect to external input switch and receive external input signal). Input signal from external will decide it to display 0 or 1. You couldn't change the state of input relay by program design or forced ON/OFF via WPLSoft. The contacts (contact a, b) can be used unlimitedly. If there is no input signal, the corresponding input relay could be empty and can't be used with other functions.			
	<ul> <li>Equipment indication method: X0, X1,X7, X10, X11, The symbol of equipment is X and the number uses octal.</li> </ul>			
Output relay	Output relay is the basic storage unit of internal memory that corresponds to external output point (it is used to connect to external load). It can be driven by input relay contact, the contact of other internal equipment and itself contact. It uses a normally open contact to connect to external load and other contacts can be used unlimitedly as input contacts. It doesn't have the corresponding output relay, if need, it can be used as internal relay.  Equipment indication: Y0, Y1,Y7, Y10, Y11, The symbol of			
	equipment is Y and the number uses octal.			
Internal relay	The internal relay doesn't connect directly to outside. It is an auxiliary relay in PLC. Its function is the same as the auxiliary relay in electric control circuit. Each auxiliary relay has the corresponding basic unit. It can be driven by the contact of input relay, output relay or other internal equipment. Its contacts can be used unlimitedly. Internal auxiliary relay can't output directly, it should output with output point.  Equipment indication: M0, M1,, M4, M159. The symbol of equipment is M and the number uses decimal number system.			
Timer	Timer is used to control time. There are coil, contact and timer storage. When coil is ON, its contact will act (contact a is close, contact b is open) when attaining desired time. The time value of timer is set by settings and each timer has its regular period. User sets the timer value and each timer has its timing period. Once the coil is OFF, the contact won't act (contact a is open and contact b is close) and the timer will be set to zero.  Equipment indication: T0, T1,,T15. The symbol of equipment is T and the number uses decimal system. The different number range corresponds with the different timing period.			
Counter	Counter is used to count. It needs to set counter before using counter (i.e. the pulse of counter). There are coil, contacts and storage unit of counter in counter. When coil is from OFF to ON, that means input a pulse in counter and the counter should add 1. There are 16-bit, 32-bit and high-speed counter for user to use.  Equipment indication: C0, C1,,C7. The symbol of equipment is C and the number uses decimal.			
Data register	PLC needs to handle data and operation when controlling each order, timer value and counter value. The data register is used to store data or parameters. It stores			

16-bit binary number, i.e. a word, in each register. It uses two continuous number of data register to store double words.

Equipment indication: D0, D1,...,D29. The symbol of equipment is D and the number uses decimal.

The structure and explanation of ladder diagram:

Ladder Diagram Structure	Explanation	Command	Equipment
⊣⊢	Normally open, contact a	LD	X, Y, M, T, C
<del></del>	Normally closed, contact b	LDI	X, Y, M, T, C
<b>⊢⊢⊣⊢</b>	Serial normally open	AND	X, Y, M, T, C
	Parallel normally open	OR	X, Y, M, T, C
	Parallel normally closed	ORI	X, Y, M, T, C
<b>├</b> - <b>1</b> ↑ <b>1</b>	Rising-edge trigger switch	LDP	X, Y, M, T, C
<b> -++-</b>	Falling-edge trigger switch	LDF	X, Y, M, T, C
<b>├</b> - <b>  </b>	Rising-edge trigger in serial	ANDP	X, Y, M, T, C
<del> </del>	Falling-edge trigger in serial	ANDF	X, Y, M, T, C
	Rising-edge trigger in parallel	ORP	X, Y, M, T, C
	Falling-edge trigger in parallel	ORF	X, Y, M, T, C
	Block in serial	ANB	none
	Block in parallel	ORB	none

Appendix D How to Use PLC Function   1/20-E					
Ladder Diagram Structure	Explanation	Command	Equipment		
	Multiple output	MPS MRD MPP	none		
-	Output command of coil drive	OUT	Y, M, S		
	Basic command, Application command	Application command	Please refer to basic command and application command		


# D.3.3 The Edition of PLC Ladder Diagram

Inverse logic

The program edited method is from left power line to right power line. (the right power line will be omitted during the edited of WPLSoft.) After editing a row, go to editing the next row. The maximum contacts in a row are 11 contacts. If you need more than 11 contacts, you could have the new row and start with continuous line to continue more input devices. The continuous number will be produced automatically and the same input point can be used repeatedly. The drawing is shown as follows.


INV

none



The operation of ladder diagram is to scan from left upper corner to right lower corner. The output handling, including the operation frame of coil and application command, at the most right side in ladder diagram.

Take the following diagram for example; we analyze the process step by step. The number at the right corner is the explanation order.




The explanation of command order:

1	LD	X0
2	OR	MO
3	AND	X1
4	LD	X3
	AND	M1
	ORB	
5	LD	Y1
	AND	X4
6	LD	T0
	AND	M3
	ORB	
7	ANB	
8	OUT	Y1
	TMR	T0 K10

The detail explanation of basic structure of ladder diagram

LD (LDI) command: give the command LD or LDI in the start of a block.



The structures of command LDP and LDF are similar to the command LD. The difference is that command LDP and LDF will act in the rising-edge or falling-edge when contact is ON as shown in the following.




AND (ANI) command: single device connects to a device or a block in series. AND command



#### Appendix D How to Use PLC Function | 1


The structures of ANDP and ANDF are the same but the action is in rising-edge or falling-edge.

3. OR (ORI) command: single device connects to a device or a block.




The structures of ORP and ORF are the same but the action is in rising-edge or falling-edge.

4. ANB command: a block connects to a device or a block in series.



5. ORB command: a block connects to a device or a block in parallel.



If there are several blocks when operate ANB or ORB, they should be combined to blocks or network from up to down or from left to right.


- MPS, MRD, MPP commands: Divergent memory of multi-output. It can produce many various outputs.
- 7. The command MPS is the start of divergent point. The divergent point means the connection place between horizontal line and vertical line. We should determine to have contact memory command or not according to the contacts status in the same vertical line. Basically, each contact could have memory command but in some places of ladder diagram conversion will be omitted due to the PLC operation convenience and capacity limit. MPS command can be used for 8 continuous times and you can recognize this command by the symbol "T".
- MRD command is used to read memory of divergent point. Because the logical status is the same in the same horizontal line, it needs to read the status of original contact to keep

on analyzing other ladder diagram. You can recognize the command MRD by the symbol " <del>|</del>".

9 MPP command is used to read the start status of the top level and pop it out from stack. Because it is the last item of the horizontal line, it means the status of this horizontal line is endina.

You can recognize this command by the symbol

" L". Basically, that is all right to use the above method to analyze but sometimes compiler will omit the same outputs as shown at the right.




# D.3.4 The Example for Designing Basic Program

Start, Stop and Latching

In the same occasions, it needs transient close button and transient open button to be start and stop switch. Therefore, if you want to keep the action, you should design latching circuit. There are several latching circuits in the following:


#### Example 1: the latching circuit for priority of stop

When start normally open contact X1=On, stop normally contact X2=Off, and Y1=On are set at the same time, if X2=On, the coil Y1 will stop acting. Therefore, it calls priority of stop.



#### Example 2: the latching circuit for priority of start

When start normally open contact X1=On, stop normally contact X2=Off and Y1=On (coil Y1 will be active and latching) are valid at the same time, if X2=On, coil Y1 will be active due to latched contact. Therefore, it calls priority of start.



#### Example 3: the latching circuit of SET and RST commands

The figure at the right side is latching circuit that made up of RST and SET command.

It is top priority of stop when RST command is set behind SET command. When executing PLC from up to down. The coil Y1 is ON and coil Y1 will be OFF

when X1 and X2 act at the same time, therefore it calls Top priority of start priority of stop.


It is top priority of start when SET command is set after RST command. When X1 and X2 act at the same time. Y1 is ON so it calls top priority of start.






The common control circuit

#### Example 4: condition control







X1 and X3 can start/stop Y1 separately, X2 and X4 can start/stop Y2 separately and they are all self latched circuit. Y1 is an element for Y2 to do AND function due to the normally open contact connects to Y2 in series. Therefore, Y1 is the input of Y2 and Y2 is also the input of Y1.




#### Example 5: Interlock control





The figure above is the circuit of interlock control. Y1 and Y2 will act according to the start contact X1 and X2. Y1 and Y2 will act not at the same time, once one of them acts and the other won't act. (This is called interlock.) Even if X1 and X2 are valid at the same time. Y1 and Y2 won't act at the same time due to up-to-down scan of ladder diagram. For this ladder diagram. Y1 has higher priority than Y2.

Example 6: Sequential Control




If add normally close contact Y2 into Y1 circuit to be an input for Y1 to do AND function. (as shown in the left side) Y1 is an input of Y2 and Y2 can stop Y1 after acting. In this way. Y1 and Y2 can execute in sequential.

#### Example 7: Oscillating Circuit

The period of oscillating circuit is  $\Delta T + \Delta T$ 






The figure above is a very simple ladder step diagram. When starting to scan Y1 normally close contact, Y1 normally close contact is close due to the coil Y1 is OFF. Then it will scan Y1 and the coil Y1 will be ON and output 1. In the next scan period to scan normally close contact Y1, Y1 normally close contact will be open due to Y1 is ON. Finally, coil Y1 will be OFF. The result of repeated scan, coil Y will output the vibrating pulse with cycle time  $\Delta$  $T(On)+\Delta T(Off)$ .

#### Appendix D How to Use PLC Function | Warden

The vibrating circuitry of cycle time  $\Delta T(On) + \Delta T(Off)$ :



The figure above uses timer T0 to control coil Y1 to be ON. After Y1 is ON, timer T0 will be closed at the next scan period and output Y1. The oscillating circuit will be shown as above. (n is the setting of timer and it is decimal number. T is the base of timer. (clock period))

#### Example 8: Blinking Circuit



The figure above is common used oscillating circuit for indication light blinks or buzzer alarms. It uses two timers to control On/OFF time of Y1 coil. If figure, n1 and n2 are timer setting of T1 and T2. T is the base of timer (clock period)


#### Example 9: Triggered Circuit




In figure above, the rising-edge differential command of X0 will make coil M0 to have a single pulse of  $\Delta T$  (a scan time). Y1 will be ON during this scan time. In the next scan time, coil M0 will be OFF, normally close M0 and normally close Y1 are all closed. However, coil Y1 will keep on being ON and it will make coil Y1 to be OFF once a rising-edge comes after input X0 and coil M0 is ON for a scan time. The timing chart is as shown above. This circuit usually executes alternate two actions with an input. From above timing: when input X0 is a square wave of a period T, output coil Y1 is square wave of a period 2T.



#### Example 10: Delay Circuit





TB = 0.1 sec




When input X0 is ON, output coil Y1 will be ON at the same time due to the corresponding normally close contact OFF makes timer T10 to be OFF. Output coil Y1 will be OFF after delaying 100 seconds (K1000\*0.1 seconds = 100 seconds) once input X0 is OFF and T10 is ON. Please refer to timing chart above.

Example 11: Output delay circuit, in the following example, the circuit is made up of two timers. No matter input X0 is ON or OFF, output Y4 will be delay.






#### Example12: Extend Timer Circuit



In this circuit, the total delay time from input X0 is close and output Y1 is ON= (n1+n2)\* T. where T is clock period.





# **D.4 PLC Devices**

# **D.4.1 Summary of DVP-PLC Device Number**

Items			Specifications		Remarks					
Cont	Control Method			Stored program, cyclic scan system						
I/O F	roce	essing Me	ethod		Batch processing (who instruction is executed		I/O refresh instruction is available			
Exec	utio	n Speed			Basic commands (mir 0.24 us)	imum	Application commands (10 ~ hundreds us)			
Prog	ram	Languag	je		Instruction, Ladder Lo	gic, SFC	Including the Step commands			
Prog	ram	Capacity	1		500 STEPS		SRAM + Battery			
Com	mar	nds			45 commands		28 basic commands 17 application commands			
Input	t/Ou	tput Cont	act		Input (X): 6, output (Y	): 2				
	Х	External	Input Rela	ау	X0~X17, 16 points, octal number system	Total is	Correspond to external input point			
	Υ	External	Output Re	elay	Y0~Y17, 16 points, octal number system	32 points	Correspond to external output point			
	М	Auxiliary	For gener	al	M0~M159, 160 points	Total is	Contacts can switch to On/Off in program			
	IVI	, taxillal y	For specia	al	M1000~M1031, 32 points	192 points				
Relay bit mode	Т	Timer	100ms tin	ner	T0~T15, 16 points	Total is 16 points	When the timer indicated by TMR command attains the setting, the T contact with the same number will be On.			
			16-bit cou general	nt up for	C0~C7, 8 points	Total is 8 points	When the counter			
	C Counter		32-bit	1-phase input			indicated by CNT command attains the			
		up/do high- spee	С	С	Counter	count up/down high-	1-phase 2 inputs	C235, 1 point (need to use with PG card)	Total is	setting, the C contact with the same number will be On.
			speed counter 2-phase 2 inputs		, p	Will DO OII.				

	Appendix D How to Use PLC Function					Jse PLC Function
	Items			Specifications		Remarks
	T Present value of timer		T0~T15, 16 points		When timer attains, the contact of timer will be On.	
data	C Present value of counter C0~C7, 8-bit counter, 8 points		When timer attains, the contact of timer will be On.			
ORD			For latched	D0~D9, 10 points		
er Wo	D	Data	For general	D10~D29, 20 points		It can be memory area for storing data.
Register WORD data		register	For special	D1000~D1044, 45 points		
ant	K	Decimal		K-32,768 ~ K32,767 (	16-bit ope	eration)
H Hexadecimal H0000 ~ HFF			H0000 ~ HFFFF (16-b	it operati	on)	
Communication port (for read/write program)		RS485 (slave)				
Analog input/output		Built-in 2 analog inputs and 1 analog output		nalog output		
Function extension module (optional)		Digital input/output card (A/D, D/A card)				

#### **D.4.2 Devices Functions**


#### ■ The Function of Input/output Contacts

The function of input contact X: input contact X reads input signal and enter PLC by connecting with input equipment. It is unlimited usage times for A contact or B contact of each input contact X in program. The On/Off of input contact X can be changed with the On/Off of input equipment but can't be changed by using peripheral equipment (WPLSoft).

#### The Function of Output Contact Y

The mission of output contact Y is to drive the load that connects to output contact Y by sending On/Off signal. There are two kinds of output contact: one is relay and the other is transistor. It is unlimited usage times for A or B contact of each output contact Y in program. But there is number for output coil Y and it is recommended to use one time in program. Otherwise, the output result will be decided by the circuit of last output Y with PLC program scan method

#### Appendix D How to Use PLC Function | Verilla |



The output of Y0 will be decided by circuit (2), i.e. decided by On/Off of X10.

# D.4.3 Value, Constant [K] / [H]

Constant	К	Decimal	K-32,768 ~ K32,767 (16-bit operation)
Constant	Н	Hexadecimal	H0000 ~ HFFFF (16-bit operation)

There are five value types for DVP-PLC to use by the different control destination. The following is the explanation of value types.

#### 1 Binary Number (BIN)

It uses binary system for the PLC internal operation or storage. The relative information of binary system is in the following.

Bit is the basic unit of binary system, the status are 1 or 0. Bit

Nibble It is made up of continuous 4 bits, such as b3~b0. It can be used to represent

number 0~9 of decimal or 0~F of hexadecimal.

It is made up of continuous 2 nibbles, i.e. 8 bits, b7~b0. It can used to represent Byte

00~FF of hexadecimal system.


Word It is made up of continuous 2 bytes, i.e. 16 bits, b15~b0. It can used to represent

0000~FFFF of hexadecimal system.

Double It is made up of continuous 2 words, i.e. 32 bits, b31~b0. It can used to

represent 00000000~FFFFFFF of hexadecimal system.

The relations among bit, nibble, byte, word, and double word of binary number are shown as follows.



#### 2. Octal Number (OCT)

The numbers of external input and output terminal of DVP-PLC use octal number.

#### Example:

Word

External input: X0~X7, X10~X17···(device number)



External output: Y0~Y7, Y10~Y17...(device number)

3 Decimal Number (DEC)

The suitable time for decimal number to use in DVP-PLC system.

- To be the setting value of timer T or counter C, such as TMR C0 K50, (K constant)
- To be the device number of M. T. C and D. For example: M10. T30. (device number)
- To be operand in application command, such as MOV K123 D0. (K constant)
- 4 BCD (Binary Code Decimal, BCD)

It shows a decimal number by a unit number or four bits so continuous 16 bits can use to represent the four numbers of decimal number. BCD code is usually used to read the input value of DIP switch or output value to 7-segment display to be display.

Hexadecimal Number (HEX)

The suitable time for hexadecimal number to use in DVP-PLC system.

To be operand in application command, For example: MOV H1A2B D0, (constant H) Constant K:

In PLC, it is usually have K before constant to mean decimal number. For example, K100 means 100 in decimal number.

#### Exception:

The value that is made up of K and bit equipment X, Y, M, S will be bit, byte, word or double word. For example, K2Y10, K4M100, K1 means a 4-bit data and K2~K4 can be 8, 12 and 16-bit data separately.

#### Constant H:

In PLC, it is usually have H before constant to mean hexadecimal number. For example, H100 means 100 in hexadecimal number.

# D.4.4 The Function of Auxiliary Relay

There are output coil and A. B contacts in auxiliary relay M and output relay Y. It is unlimited usage times in program. User can control loop by using auxiliary relay, but can't drive external load directly. There are two types divided by its characteristics.

- 1. Auxiliary relay for general: It will reset to Off when power loss during running. Its state will be Off when power on after power loss.
- 2. Auxiliary relay for special: Each special auxiliary relay has its special function. Please don't use undefined auxiliary relay.

#### D.4.5 The Function of Timer

The unit of timer is 1ms, 10ms and 100ms. The count method is count up. The output coil will be On when the present value of timer equals to the settings. The setting is K in decimal number. Data register D can be also used as settings.

The real setting time of timer = unit of timer \* settings



#### D.4.6 The Features and Functions of Counter

#### Features:

Item	16 bits counters	32 bits counters		
Туре	General	General	High speed	
Count direction	Count up	Count up/down		
Settings	0~32,767	-2,147,483,648~-	+2,147,483,647	
Designate for constant	Constant K or data register D	Constant K or data register D (2 for designated)		
Present value change	Counter will stop when attaining settings	Counter will keep on counting when attaining settings		
Output contact	When count attains settings, contact will be On and latched.	When count up attains settings, contact will be On and latched.  When count down attains settings, contact will reset to Off.		
Reset action	The present value will reset to will reset to Off.	o 0 when RST command is executed and contact		
Present register	16 bits	32 bits		
Contact action	After scanning, act together.	After scanning, act together.	Act immediately when count attains. It has no relation with scan period.	

#### Functions:

When pulse input signal of counter is from Off to On, the present value of counter equals to settings and output coil is On. Settings are decimal system and data register D can also be used as settings. 16-bit counters C0~C7:

- 1. Setting range of 16-bit counter is K0~K32,767. (K0 is the same as K1. output contact will be On immediately at the first count.
- 2. General counter will be clear when PLC is power loss. If counter is latched, it will remember the value before power loss and keep on counting when power on after power loss.
- 3. If using MOV command, WPLSoft to send a value, which is large than setting to C0, register, at the next time that X1 is from Off to On, C0 counter contact will be On and present value will be set to the same as settings.
- 4. The setting of counter can use constant K or register D (not includes special data register D1000~D1044) to be indirect setting.
- If using constant K to be setting, it can only be positive number but if setting is data 5. register D, it can be positive/negative number. The next number that counter counts up from 32,767 is -32,768.

#### Example:

LD X0 RST C<sub>0</sub>


ΙD X1


CNT C0 K5

LD C<sub>0</sub>

OUT ٧n

- 1. When X0=On, RST command is executed. C0 reset to 0 and output contact reset to Off.
- 2. When X1 is from Off to On, counter will count up (add 1).
- 3. When counter C0 attains settings K5. C0 contact is On and C0 = setting =K5. C0 won't accept X1 trigger signal and C0 remains K5.





32-bit high-speed addition/subtraction counter C235:

- 1 Setting range of 32-bit high-speed addition/subtraction counter is: K-2.147.483.648~K2.147.483.647.
- 2 The settings can be positive / negative numbers by using constant K or data register D (special data register D1000~D1044 is not included). If using data register D, the setting will occupy two continuous data register.

The total band width of high-speed counter that VFD-E supports is up to 30kHz and 500kHz for pulse input.

# **D.4.7 Register Types**

There are two types of register which sorts by characters in the following:

1. General : The data in register will be cleared to 0 when PLC switches from RUN register to STOP or power is off.

2 : Each special register has the special definition and purpose. It is used Special register to save system status, error messages, monitor state.

# D.4.8 Special Auxiliary Relays

Special M	Function	Read(R)/ Write(W)
M1000	Normally open contact (a contact). This contact is On when running and it is On when the status is set to RUN.	R
M1001	Normally closed contact (b contact). This contact is Off in running and it is Off when the status is set to RUN.	R
M1002	On only for 1 scan after RUN. Initial pulse is contact a. It will get positive pulse in the RUN moment. Pulse width=scan period.	R
M1003	Off only for 1 scan after RUN. Initial pulse is contact a. It will get negative pulse in the RUN moment. Pulse width=scan period.	R
M1004	Reserved	
M1005	Fault indication of the AC motor drives	R
M1006	Output frequency is 0	R
M1007	The operation direction of AC motor drives (FWD: 0, REV: 1)	R
M1008	Reserved	
M1009	Reserved	
M1010	Reserved	
M1011	10ms clock pulse, 5ms On/5ms Off	R
M1012	100ms clock pulse, 50ms On / 50ms Off	R
M1013	1s clock pulse, 0.5s On / 0.5s Off	R
M1014	1min clock pulse, 30s On / 30s Off	R
M1015	Frequency attained	R
M1016	Parameter read/write error	R
M1017	Succeed to write parameter	R
M1018	Enable high-speed counter function (When M1028=On)	R
M1019	Reserved	R
M1020	Zero flag	R
M1021	Borrow flag	R
M1022	Carry flag	R
M1023	Divisor is 0	R
M1024	Reserved	
M1025	RUN(ON) / STOP(OFF) the AC motor drive	R/W

	Appendix D How to Use PLC Function	n VFD-E
Special M	Function	Read(R)/ Write(W)
M1026	The operation direction of the AC motor drive (FWD: OFF, REV: ON)	R/W
M1027	Reserved	
M1028	Enable(ON)/disable(OFF) high-speed counter function	R/W
M1029	Clear the value of high-speed counter	R/W
M1030	Decide to count up(OFF)/count down(ON)	R/W
M1031	Reserved	

# **D.4.9 Special Registers**

Special D	Function	Read(R)/ Write(W)
D1000	Reserved	
D1001	PLC firmware version	R
D1002	Program capacity	R
D1003	Checksum	R
D1004- D1009	Reserved	
D1010	Present scan time (Unit: 0.1ms)	R
D1011	Minimum scan time (Unit: 0.1ms)	R
D1012	Maximum scan time (Unit: 0.1ms)	R
D1013- D1019	Reserved	
D1020	Output frequency	R
D1021	Output current	R
D1022	The ID of the extension card: 02 USB Card 03 12-Bit A/D (2CH) 12-Bit D/A (2CH) 04 Relay Card-2C 05 Relay Card-3A 06 3IN/3OUT Card 07 PG Card	R
D1023- D1024	Reserved	

Special D	How to Use PLC Function   Function	Read(R)/ Write(W)
Opecial D	i unction	rteau(it)/ vviite(vv)
D1025	The present value of the high-speed counter C235 (low byte)	R
D1026	The present value of the high-speed counter C235 (high byte)	R
D1027	Frequency command of the PID control	R
D1028	The value of AVI (analog voltage input) 0-10V corresponds to 0-1023	R
D1029	The value of ACI (analog current input) 4-20mA corresponds to 0-1023 or the value of AVI2 (analog voltage input) 0-10V corresponds to 0-1023	R
D1030	The value of V.R digital keypad 0-10V corresponds to 0-1023	R
D1031- D1035	Reserved	
D1036	PLC error code	R
D1037- D1039	Reserved	
D1040	Analog output value	R/W
D1041- D1042	Reserved	
D1043	User defined (when Pr.00.04 is set to 2, the register data will be displayed as C xxx)	R/W
D1044	High-speed counter mode	R/W

# D.4.10 Communication Addresses for Devices (only for PLC2 mode)

Device	Range	Туре	Address (Hex)
Х	00-17 (octal)	Bit	0400-040F
Υ	00-17 (octal)	Bit	0500-050F
Т	00-15	Bit/word	0600-060F
М	000-159	Bit	0800-089F
М	1000-1031	Bit	0BE8-0C07
С	0-7	Bit/word	0E00-0E07
D	00-63	Word	1000-101D
D	1000-1044	Word	13E8-1414



NOTE: when it is in PLC1 mode, the communication address will correspond to the parameter NOT the device. For example, address 0400H will correspond to Pr.04.00 NOT X0.

# D.4.11 Function Code (only for PLC2 mode)

Function Code	Description	Supported Devices
01	Read coil status	Y, M, T, C
02	Read input status	X, Y, M, T, C
03	Read one data	T, C, D
05	Force changing one coil status	Y, M, T, C
06	Write in one data	T, C, D
0F	Force changing multiple coil status	Y, M, T, C
10	Write in multiple data	T, C, D

## **D.5 Commands**

# **D.5.1 Basic Commands**

Commands	Function	Operands
LD	Load contact A	X, Y, M, T, C
LDI	Load contact B	X, Y, M, T, C
AND	Series connection with A contact	X, Y, M, T, C
ANI	Series connection with B contact	X, Y, M, T, C
OR	Parallel connection with A contact	X, Y, M, T, C
ORI	Parallel connection with B contact	X, Y, M, T, C
ANB	Series connects the circuit block	
ORB	Parallel connects the circuit block	
MPS	Save the operation result	
MRD	Read the operation result (the pointer not moving)	1
MPP	Read the result	
INV	Inverter the result	-



# **D.5.2 Output Commands**

Commands	Function	Operands
OUT	Drive coil	Y, M
SET	Action latched (ON)	Y, M
RST	Clear the contacts or the registers	Y, M, T, C, D

# **D.5.3 Timer and Counters**

Commands	Function	Operands
TMR	16-bit timer	T-K or T-D
CNT	16-bit counter	C-K or C-D

# **D.5.4 Main Control Commands**

Commands	Function	Operands
MC	Connect the common series connection contacts	N0~N7
MCR	Disconnect the common series connection contacts	N0~N7

# D.5.5 Rising-edge/falling-edge Detection Commands of Contact

Commands	Function	Operands
LDP	Rising-edge detection operation starts	X, Y, M, T, C
LDF	Falling-edge detection operation starts	X, Y, M, T, C
ANDP	Rising-edge detection series connection	X, Y, M, T, C
ANDF	Falling-edge detection series connection	X, Y, M, T, C
ORP	Rising-edge detection parallel connection	X, Y, M, T, C
ORF	Falling-edge detection parallel connection	X, Y, M, T, C

# D.5.6 Rising-edge/falling-edge Output Commands

Commands	Function	Operands
PLS	Rising-edge output	Y, M
PLF	Falling-edge output	Y, M

#### D.5.7 End Command

Command	Function	Operands
END	Program end	none

# **D.5.8 Explanation for the Commands**

Mnemonic	Function					
LD		Load A contact				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
Operand	✓	✓	✓	✓	✓	

#### Explanations:

The LD command is used on the A contact that has its start from the left BUS or the A contact that is the start of a contact circuit. Function of the command is to save present contents, and at the same time, save the acquired contact status into the accumulative register.

#### Program Example:

Ladder diagram	Command code		Operation	
X0 X1	LD	X0	Load contact A of X0	
HH-H-Y1	AND	X1	Connect to contact A of X1 in series	
	OUT	Y1	Drive Y1 coil	

Mnemonic	Function					
LDI		Load B contact				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
Operand	✓	✓	✓	✓	✓	


#### Appendix D How to Use PLC Function | 1



#### Explanations:

The LDI command is used on the B contact that has its start from the left BUS or the B contact that is the start of a contact circuit. Function of the command is to save present contents, and at the same time, save the acquired contact status into the accumulative register.

#### Program Example:



Mnemonic	Function					
AND		Series connection- A contact				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
Operand	✓	✓	✓	✓	✓	

#### Explanations:

The AND command is used in the series connection of A contact. The function of the command is to readout the status of present specific series connection contacts first, and then to perform the "AND" calculation with the logic calculation result before the contacts, thereafter, saving the result into the accumulative register.

#### Program Example:

Ladder diagram:



Command code:	Operation:
Communa codo.	Operation.

LDI X1 Load contact B of X1 AND X0 Connect to contact A of X0 in series


OUT Y1 Drive Y1 coil

Mnemonic	Function					
ANI		Series connection- B contact				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
Operand	✓	✓	✓	✓	✓	-

#### Explanations:

The ANI command is used in the series connection of B contact. The function of the command is to readout the status of present specific series connection contacts first, and then to perform the "AND" calculation with the logic calculation result before the contacts, thereafter, saving the result into the accumulative register.

#### Program Example:




Mnemonic	Function					
OR		Parallel connection- A contact				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
Operand	✓	✓	✓	✓	✓	

#### Explanations:

The OR command is used in the parallel connection of A contact. The function of the command is to readout the status of present specific series connection contacts, and then to perform the "OR" calculation with the logic calculation result before the contacts, thereafter, saving the result into the accumulative register.

#### Appendix D How to Use PLC Function | 1

#### Program Example:




Mnemonic	Function					
ORI		Parallel connection- B contact				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
Operanu	✓	✓	✓	✓	✓	

#### Explanations:

The ORI command is used in the parallel connection of B contact. The function of the command is to readout the status of present specific series connection contacts, and then to perform the "OR" calculation with the logic calculation result before the contacts, thereafter, saving the result into the accumulative register.

#### Program Example:




Mnemonic	Function		
ANB	Series connection (Multiple Circuits)		
Operand	None		

#### Explanations:

To perform the "ANB" calculation between the previous reserved logic results and contents of the accumulative register.

#### Program Example:




Mnemonic	Function
ORB	Parallel connection (Multiple circuits)
Operand	None

#### Explanations:

To perform the "OR" calculation between the previous reserved logic results and contents of the accumulative register.

#### Program Example:



Mnemonic	Function
MPS	Store the current result of the internal PLC operations
Operand	None

#### Appendix D How to Use PLC Function | 1



#### Explanations:

To save contents of the accumulative register into the operation result. (the result operation pointer pluses 1)

Mnemonic	Function	
MRD	Reads the current result of the internal PLC operations	
Operand	None	

#### Explanations:

Reading content of the operation result to the accumulative register. (the pointer of operation result doesn't move)


Mnemonic	Function
MPP	Reads the current result of the internal PLC operations
Operand	None

#### Explanations:

Reading content of the operation result to the accumulative register. (the stack pointer will decrease 1)

#### Program Example:

#### Ladder diagram:



#### Command code: Operation:


LD	X0	Load contact A of X0
MPS		Save in stack
AND	X1	Connect to contact A of X1 in series
OUT	Y1	Drive Y1 coil
MRD		Read from the stack (without moving pointer)
AND	X2	Connect to contact A of X2 in series
OUT	M0	Drive M0 coil
MPP		Read from the stack
OUT	Y2	Drive Y2 coil
END		End program

Mnemonic	Function		
INV	Inverting Operation		
Operand	None		

#### Explanations:

Inverting the operation result and use the new data as an operation result.

## Program Example:



Mnemonic	Function					
OUT		Output coil				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
		✓	✓	-		

#### Explanations:

Output the logic calculation result before the OUT command to specific device.

#### Motion of coil contact

	OUT command			
Operation	Coil	C	Contact	
resuit	COII	A contact (normally open)	B contact (normally closed)	
FALSE	OFF	Non-continuity	Continuity	
TRUE	ON	Continuity	Non-continuity	

#### Appendix D How to Use PLC Function | 1/22/15

Program Example:

Ladder diagram: Command code: Operation:




OUT Y1 Drive Y1 coil

Mnemonic	Function					
SET		Latch (ON)				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
Operand		✓	✓	-		

#### Explanations:

When the SET command is driven, its specific device is set to be "ON," which will keep "ON" whether the SET command is still driven. You can use the RST command to set the device to "OFF".

## Program Example:



Mnemonic	Function					
RST		Clear the contacts or the registers				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
		✓	✓	✓	✓	

#### Explanations:

When the RST command is driven, motion of its specific device is as follows:

Device	Status
Y, M	Coil and contact will be set to "OFF".
T, C	Present values of the timer or counter will be set to 0, and the coil and contact will be set to "OFF."
D	The content value will be set to 0.

#### Program Example:



Mnemonic	Function		
TMR	16-bit timer		
Operand	T-K	T0~T15, K0~K32,767	
Operand	T-D	T0~T15, D0~D29	

#### Explanations:

When TMR command is executed, the specific coil of timer is ON and timer will start to count. When the setting value of timer is attained (counting value >= setting value), the contact will be as following:

NO(Normally Open) contact	Open collector
NC(Normally Closed) contact	Close collector

#### Program Example:



Mnemonic	Function		
CNT	16-bit counter		
Operand	C-K	C0~C7, K0~K32,767	
Operand	C-D	C0~C7, D0~D29	

#### Explanations:

When the CNT command is executed from OFF→ON, which means that the counter coil
is driven, and 1 should thus be added to the counter's value; when the counter achieved
specific set value (value of counter = the setting value), motion of the contact is as follows:

NO(Normally Open) contact	Continuity	
NC(Normally Closed) contact	Non-continuity	

If there is counting pulse input after counting is attained, the contacts and the counting values will be unchanged. To re-count or to conduct the CLEAR motion, please use the RST command.

## Program Example:



Mnemonic	Function	
MC / MCR	Master control Start/Reset	
Operand	N0~N7	

#### Explanations:


MC is the main-control start command. When the MC command is executed, the
execution of commands between MC and MCR will not be interrupted. When MC
command is OFF, the motion of the commands that between MC and MCR is described
as follows:

Timer	The counting value is set back to zero, the coil and the contact are both turned OFF
Accumulative timer	The coil is OFF, and the timer value and the contact stay at their present condition
Subroutine timer	The counting value is back to zero. Both coil and contact are turned OFF.

	Appendix D How to use PLC Function
Counter	The coil is OFF, and the counting value and the contact stay at their present condition
Coils driven up by the OUT command	All turned OFF
Devices driven up by the SET and RST commands	Stay at present condition
Application commands	All of them are not acted , but the nest loop FOR-NEXT command will still be executed for times defined by users even though the MC-MCR commands is OFF.

- MCR is the main-control ending command that is placed at the end of the main-control program and there should not be any contact commands prior to the MCR command.
- Commands of the MC-MCR main-control program supports the nest program structure, with 8 layers as its greatest. Please use the commands in order from N0~ N7, and refer to the following:

#### Program Example:





OUT Y10 Drive Y10 coil

:

MCR N0 Disable N0 common series connection contact


Mnemonic	Function					
LDP		Rising-edge detection operation				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
	✓	✓	✓	✓	✓	

#### Explanations:

Usage of the LDP command is the same as the LD command, but the motion is different. It is used to reserve present contents and at the same time, saving the detection status of the acquired contact rising-edge into the accumulative register.

#### Program Example:

#### Ladder diagram:



## Command code: Operation:

LDP	X0	Start X0 rising-edge detection
AND	X1	Series connection A contact of X1
OUT	Y1	Drive Y1 coil


Mnemonic	Function						
LDF		Falling-edge detection operation					
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29	
	✓	✓	✓	✓	✓		

#### Explanations:

Usage of the LDF command is the same as the LD command, but the motion is different. It is used to reserve present contents and at the same time, saving the detection status of the acquired contact falling-edge into the accumulative register.

#### Program Example:

#### Appendix D How to Use PLC Function





Mnemonic	Function					
ANDP		Rising-edge series connection				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
	✓	✓	✓	✓	✓	

#### Explanations:

ANDP command is used in the series connection of the contacts' rising-edge detection.

#### Program Example:

Ladder diagram: Command code: Operation:



Mnemonic	Function					
ANDF		Falling-edge series connection				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
	<b>√</b>	✓	<b>√</b>	✓	<b>√</b>	-

#### Explanations:

ANDF command is used in the series connection of the contacts' falling-edge detection.

#### Program Example:

Ladder diagram: Command code: Operation:



#### Appendix D How to Use PLC Function

Mnemonic	Function					
ORP		Rising-edge parallel connection				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
	✓	✓	✓	✓	✓	

#### Explanations:

The ORP commands are used in the parallel connection of the contact's rising-edge detection.

#### Program Example:

Ladder diagram: Command code: Operation:




Mnemonic	Function					
ORF		Falling-edge parallel connection				
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
Operanu	✓	✓	✓	✓	✓	

#### Explanations:

The ORP commands are used in the parallel connection of the contact's falling-edge detection.

#### Program Example:

#### Ladder diagram:



#### Command code: Operation:

LD	XU	Load A contact of XU
ORF	X1	X1 falling-edge detection in parallel connection
OUT	Y1	Drive Y1 coil

# Appendix D How to Use PLC Function Mnemonic Function PLS Rising-edge output Operand X0~X17 Y0~Y17 M0~M159 T0~15 C0~C7 D0~D29 -- ✓ -- -- -- --

#### Explanations:

When X0=OFF→ON (rising-edge trigger), PLS command will be executed and M0 will send the pulse of one time which the length is a scan time.

Program Example:





SET

ΥN

Command code: Operation:

LD	X0	Load A contact of X0
PLS	МО	M0 rising-edge output
LD	M0	Load the contact A of M0
SET	Y0	Y0 latched (ON)

Timing Diagram:

M0

H٢



Mnemonic	Function					
PLF	Falling-edge output					
Operand	X0~X17	Y0~Y17	M0~M159	T0~15	C0~C7	D0~D29
		✓	✓	-		-


#### Explanations:

When X0= ON—OFF (falling-edge trigger), PLF command will be executed and M0 will send the pulse of one time which the length is the time for scan one time.



## Program Example:


Ladder diagram:



Command code: Operation:

LD	X0	Load A contact of X0
PLF	МО	M0 falling-edge output
LD	M0	Load the contact A of M0
SET	Y0	Y0 latched (ON)

Timing Diagram:



Mnemonic	Function
END	Program End
Operand	None

### Explanations:

It needs to add the END command at the end of ladder diagram program or command program. PLC will scan from address o to END command, after executing it will return to address 0 to scan again.

# **D.5.9 Description of the Application Commands**

	API	_	monic odes	P Command	Function	Steps		
		16 bits	32 bits	Command		16-bit	32-bit	
	10	CMP		✓	Compare	7		
Transmission	11	ZCP		✓	Zone compare	9		
Comparison	12	MOV		✓	Data Move	5		
	15	BMOV		✓	Block move	7		
Four Fundamental	20	ADD		<b>✓</b>	Perform the addition of BIN data	7		
Operations of Arithmetic	21	SUB		<b>√</b>	Perform the subtraction of BIN data	7		

Appendix D How to Use PLC Function | Variable Mnemonic Steps Р Codes API **Function** Command 16 bits 32 bits 16-bit 32-bit Perform the 7 MUL 22 multiplication of BIN data Perform the division of 7 DIV 23 BIN data Perform the addition of 3 24 INC Perform the subtraction 3 25 DEC ROR Rotate to the right 30 5 Rotation and Displacement 31 ROL / Rotate to the left 5 High speed counter 13 DHSCS Х 53 enable Control PID parameters 5 139 FPID Special of inverter command for AC motor Control frequency of 5 FRFO 140 drive inverter RPR 9 141 Read the parameter 142 WPR Write the parameter 7

# **D.5.10 Explanation for the Application Commands**

API	Mnemon	ic	Operands	Function
10	CMP	Р	S <sub>1</sub> , S <sub>2</sub> , D	Compare

Туре	Bit Devices			Word devices							Program Steps	
ОР	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	CMP, CMPP: 7 steps
S <sub>1</sub>				*	*	*	*	*	*	*	*	
S <sub>2</sub>				*	*	*	*	*	*	*	*	
D		*	*									

Operands:

S1: Comparison Value 1 S2: Comparison Value 2 D: Comparison result


## Appendix D How to Use PLC Function | 1

### Explanations:


- 1. Operand D occupies 3 consecutive devices.
- 2. See the specifications of each model for their range of use.
- 3. The contents in S1 and S2 are compared and the result will be stored in D.
- 4. The two comparison values are compared algebraically and the two values are signed binary values. When b15 = 1 in 16-bit instruction, the comparison will regard the value as negative binary values.

### Program Example:

- 1. Designate device Y0, and operand D automatically occupies Y0, Y1, and Y2.
- When X10 = On, CMP instruction will be executed and one of Y0, Y1, and Y2 will be On.
   When X10 = Off, CMP instruction will not be executed and Y0, Y1, and Y2 remain their status before X10 = Off.
- If the user need to obtain a comparison result with ≥ ≤, and ≠, make a series parallel connection between Y0 ~ Y2.



4. To clear the comparison result, use RST or ZRST instruction.



API	Mnemon	ic	Operands	Function
11	ZCP	Р	S <sub>1</sub> , S <sub>2</sub> , S, D	Zone Compare

	Type	Bit Devices					W	ord de	vices				Program Steps
OF	, /	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	ZCP, ZCPP: 9 steps
	S <sub>1</sub>				*	*	*	*	*	*	*	*	
	S <sub>2</sub>				*	*	*	*	*	*	*	*	
	S				*	*	*	*	*	*	*	*	
	D		*	*									

S1: Lower bound of zone comparison S2: Upper bound of zone comparison S: Comparison value D: Comparison result

## Explanations:


- 1. The content in S1 should be smaller than the content in S2.
- 2. Operand D occupies 3 consecutive devices.
- 3. See the specifications of each model for their range of use.
- 4. S is compared with its S1 S2 and the result is stored in D.
- 5 When S1 > S2, the instruction performs comparison by using S1 as the lower/upper bound
- 6. The two comparison values are compared algebraically and the two values are signed binary values. When b15 = 1 in 16-bit instruction or b31 = 1 in 32-bit instruction, the comparison will regard the value as negative binary values.

- Designate device M0, and operand D automatically occupies M0, M1 and M2.
- 2. When X0 = On, ZCP instruction will be executed and one of M0, M1, and M2 will be On. When X10 = Off, ZCP instruction will not be executed and M0, M1, and M2 remain their status before X0 = Off.

H2 If C10 ≥ C10 ≤ K100, M1 = On

M2 If C10 > K100, M2 = On

3. To clear the comparison result, use RST or ZRST instruction.



API	Mnemon	ic	Operands	Function
12	MOV	Р	S, D	Move

Туре	Bit Devices			Word devices								Program Steps
ОР	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	MOV, MOVP: 5 steps
S				*	*	*	*	*	*	*	*	
D							*	*	*	*	*	

### Operands:

S: Source of data D: Destination of data


### Explanations:

- 1. See the specifications of each model for their range of use.
- When this instruction is executed, the content of S will be moved directly to D. When this instruction is not executed, the content of D remains unchanged.

### Program Example:

MOV instruction has to be adopted in the moving of 16-bit data.

- When X0 = Off, the content in D10 will remain unchanged. If X0 = On, the value K10 will be moved to D10 data register.
- When X1 = Off, the content in D10 will remain unchanged. If X1 = On, the present value T0 will be moved to D10 data register.



API	Mnemon	ic	Operands	Function
15	BMOV	Р	S, D, n	Block Move

Type	Bit Devices				Word devices							Program Steps
ОР	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	BMOV, BMOVP: 7 steps
S						*	*	*	*	*	*	
D							*	*	*	*	*	
n				*	*				*	*	*	

S: Start of source devices D: Start of destination devices n: Number of data to be moved Explanations:

- 1. Range of **n**: 1 ~ 512
- 2. See the specifications of each model for their range of use.
- The contents in n registers starting from the device designated by S will be moved to n
  registers starting from the device designated by D. If n exceeds the actual number of
  available source devices, only the devices that fall within the valid range will be used.


### Program Example 1:

When X10 = On, the contents in registers D0 ~ D3 will be moved to the 4 registers D20 ~ D23.



### Program Example 2:

Assume the bit devices KnX, KnY, KnM and KnS are designated for moving, the number of digits of S and D has to be the same. i.e. their n has to be the same.



### Program Example 3:

To avoid coincidence of the device numbers to be moved designated by the two operands and cause confusion, please be aware of the arrangement on the designated device numbers.

When S > D, the BMOV command is processed in the order as  $\bigcirc \rightarrow \bigcirc \rightarrow \bigcirc$ 



When S < D, the BMOV command is processed in the order as  $3\rightarrow2\rightarrow0$ 



API	Mnemon	ic	Operands	Function
20	ADD	Р	S <sub>1</sub> , S <sub>2</sub> , D	Addition

Type	Bit Devices					W	ord de	vices				Program Steps
ОР	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	ADD, ADDP: 7 steps
S <sub>1</sub>				*	*	*	*	*	*	*	*	
S <sub>2</sub>				*	*	*	*	*	*	*	*	
D							*	*	*	*	*	

### Operands:

S1: Summand S2: Addend D: Sum

### Explanations:

- 1 See the specifications of each model for their range of use.
- 2 This instruction adds S1 and S2 in BIN format and store the result in D.
- 3 The highest bit is symbolic bit 0 (+) and 1 (-), which is suitable for algebraic addition, e.g. 3 + (-9) = -6.
- 4. Flag changes in binary addition


### 16-bit command:

- A. If the operation result = 0, zero flag M1020 = 0n.
- B. If the operation result < -32,768, borrow flag M1021 = On.
- C. If the operation result > 32,767, carry flag M1022 = On.

### Program Example 1:


### 16-bit command:


When X0 = On, the content in D0 will plus the content in D10 and the sum will be stored in D20.



### Remarks:

Flags and the positive/negative sign of the values:







API	Mnemon	ic	Operands	Function						
21	SUB	Р	S <sub>1</sub> , S <sub>2</sub> , D	Subtraction						

Туре	Bit	Devi	es			W	ord de	vices				Program Steps
ОР	Х	Υ	М	K	Н	KnX	KnY	KnM	T	С	D	SUB, SUBP: 7 steps
S <sub>1</sub>				*	*	*	*	*	*	*	*	DSUB, DSUBP: 13 steps
S <sub>2</sub>				*	*	*	*	*	*	*	*	
D							*	*	*	*	*	

S1: Minuend S2: Subtrahend D: Remainder

## Explanations:

- 1. This instruction subtracts S1 and S2 in BIN format and stores the result in D.
- 2 The highest bit is symbolic bit 0 (+) and 1 (-), which is suitable for algebraic subtraction.
- 3 Flag changes in binary subtraction


In 16-bit instruction:

- A. If the operation result = 0, zero flag M1020 = 0n.
- B. If the operation result < -32,768, borrow flag M1021 = On.
- C. If the operation result > 32,767, carry flag M1022 = On.

## Program Example:

In 16-bit BIN subtraction:

When X0 = On, the content in D0 will minus the content in D10 and the remainder will be stored in D20.




API	Mnemon	ic	Operands	Function
22	MUL	Р	S <sub>1</sub> , S <sub>2</sub> , D	Multiplication

Type	Bit	Devi	es			W	ord de	vices				Program Steps
ОР	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	MUL, DMULP: 7 steps
S <sub>1</sub>				*	*	*	*	*	*	*	*	
S <sub>2</sub>				*	*	*	*	*	*	*	*	
D							*	*	*	*	*	

S1: Multiplicand S2: Multiplicator D: Product

### Explanations:

- 1. In 16-bit instruction, D occupies 2 consecutive devices.
- 2. This instruction multiplies S1 by S2 in BIN format and stores the result in D. Be careful with the positive/negative signs of S1, S2 and D when doing 16-bit and 32-bit operations.




Symbol bit = 0 refers to a positive value. Symbol bit = 1 refers to a negative value.

When D serves as a bit device, it can designate K1 ~ K4 and construct a 16-bit result, occupying consecutive 2 groups of 16-bit data.

### Program Example:

The 16-bit D0 is multiplied by the 16-bit D10 and brings forth a 32-bit product. The higher 16 bits are stored in D21 and the lower 16-bit are stored in D20. On/Off of the most left bit indicates the positive/negative status of the result value.



Appendix D How to Use PLC Function

AF	1	M	Inemon	ic	Operands	Function					
23	3		DIV	Р	S <sub>1</sub> , S <sub>2</sub> , D	Division					


Туре	Bit	Devi	ces			W	ord de	vices				Program Steps
ОР	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	DIV, DIVP: 7 steps
S <sub>1</sub>				*	*	*	*	*	*	*	*	
S <sub>2</sub>				*	*	*	*	*	*	*	*	
D							*	*	*	*	*	

### Operands:

S<sub>1</sub>: Dividend S<sub>2</sub>: Divisor D: Quotient and remainder


### Explanations:

- 1. In 16-bit instruction, **D** occupies 2 consecutive devices.
- This instruction divides S<sub>1</sub> and S<sub>2</sub> in BIN format and stores the result in D. Be careful with the positive/negative signs of S<sub>1</sub>, S<sub>2</sub> and D when doing 16-bit and 32-bit operations.
   16-bit instruction:



### Program Example:

When X0 = On, D0 will be divided by D10 and the quotient will be stored in D20 and remainder in D21. On/Off of the highest bit indicates the positive/negative status of the result value.



API	Mnemon	ic	Operands	Function
24	INC	Р	D	Increment

ĺ	Туре	Bit Devices					W	ord de	vices	Program Steps			
	OP \	Х	Υ	М	Κ	Н	KnX	KnY	KnM	Τ	О	D	INC, INCP: 3 steps
ĺ	D							*	*	*	*	*	



### D: Destination device

### Explanations:

- 1. If the instruction is not a pulse execution one, the content in the designated device D will plus "1" in every scan period whenever the instruction is executed.
- 2. This instruction adopts pulse execution instructions (INCP).
- 3 In 16-bit operation, 32,767 pluses 1 and obtains -32,768. In 32-bit operation, 2,147,483,647 pluses 1 and obtains -2,147,483,648.

### Program Example:

When X0 goes from Off to On, the content in D0 pluses 1 automatically.

API	Mnemon	ic	Operands	Function
25	DEC	Р	D	Decrement

Type	Bit	Devi	ces			W	ord de	vices				Program Steps
ОР	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	O	D	DEC, DECP: 3 steps
D							*	*	*	*	*	

### Operands:

#### D: Destination

### Explanations:

- 1. If the instruction is not a pulse execution one, the content in the designated device D will minus "1" in every scan period whenever the instruction is executed.
- 2. This instruction adopts pulse execution instructions (DECP).
- 3. In 16-bit operation, -32,768 minuses 1 and obtains 32,767. In 32-bit operation, -2,147,483,648 minuses 1 and obtains 2,147,483,647.

### Program Example:

When X0 goes from Off to On, the content in D0 minuses 1 automatically.



Appendix D How to Use PLC Function

API	Mnemon	ic	Operands	Function
30	ROR	Р	D, n	Rotate to the Right

Туре	Bit Devices					W	ord de	vices	Program Steps			
ОР	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	ROR, RORP: 5 steps
D							*	*	*	*	*	
n				*	*							

### Operands:


D: Device to be rotated n: Number of bits to be rotated in 1 rotation

### Explanations:

- 1. This instruction rotates the device content designated by  $\bf D$  to the right for  $\bf n$  bits.
- 2. This instruction adopts pulse execution instructions (RORP).

### Program Example:

When X0 goes from Off to On, the 16 bits (4 bits as a group) in D10 will rotate to the right, as shown in the figure below. The bit marked with  $\frac{1}{2}$  will be sent to carry flag M1022.



API	Mnemon	ic	Operands	Function					
31	ROL	Р	D, n	Rotate to the Left					

Туре	Bit Devices					W	ord de	vices	Program Steps			
OP \	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	ROL, ROLP: 5 steps
D							*	*	*	*	*	
n				*	*							




D: Device to be rotated n: Number of bits to be rotated in 1 rotation

### Explanations:

- 1. This instruction rotates the device content designated by  $\mathbf{D}$  to the left for  $\mathbf{n}$  bits.
- 2 This instruction adopts pulse execution instructions (ROLP).

### Program Example:

When X0 goes from Off to On, the 16 bits (4 bits as a group) in D10 will rotate to the left, as shown in the figure below. The bit marked with \* will be sent to carry flag M1022.



## D.5.11 Special Application Commands for the AC Motor Drive

API		М	nemoni	С	Operands	Function						
53	Ī	D	DHSCS		S1, S2, D	Compare (for high-speed counter)						

Туре	pe Bit Devices					w	ord de	vices				Program Steps
ОР	Χ	Υ	М	K	Ι	KnX	KnY	KnM	Т	O	О	DHSCS: 13 steps
S1				*	*						*	
S2										*		
D		*	*						*	*	*	

### Operands:


S1: Comparison Value S2: High-speed counter C235 D: Comparison result

### Explanations:

- 1. It needs optional PG card to receive external input pulse.
- 2. To count automatically, please set the target value by using DHSCS command and set M1028=On. The counter C235 will be ON when the count number = target value. If you want to clear C235, please set M1029=ON.


## Appendix D How to Use PLC Function | Warner

- Please use rising-edge/falling-edge command, such as LDP/LDF, for the contact condition. Please notice that error may occur when using contact A/B for the contact condition.
- 4. There are three input modes for high-speed counter in the following can be set by D1044.
- A-B phase mode(4 times frequency )(D1044=0): user can input the A and B pulse for counting. Make sure that  $\overline{A}$ ,  $\overline{B}$  and GND are grounding.



- Pulse + signal mode(D1044=1): user can count by pulse input or signal. A is for pulse and B is for signal. Make sure that  $\overline{A}$ ,  $\overline{B}$  and GND are grounding.
- Pulse + flag mode(D1044=2): user can count by M1030. Only A is needed for this mode and make sure that  $\overline{A}$ , and GND are grounding.

- Assume that when M100=ON, it is set to A-B phase mode. When M101=ON, it is set to pulse+signal mode. When M102=ON, it is set to pulse+flag mode.
- 2. M1030 is used to set to count up (OFF) and count down (ON).
- If M0 goes from OFF to ON, DHSCS command starts to execute the comparison of highspeed counter. When C235 goes from H'2 to H'3 or from H'4 to H'3, M3 will be always be ON.
- If M1 goes from OFF to ON, DHSCS command starts to execute the comparison of highspeed counter. When C235 goes from H'1004F to H'10050 or from H'10051 to H'10050, M2 will be always be ON.
- M1028: it is used to enable(ON)/disable(OFF) the high-speed counter function. M1029: it
  is used to clear the high-speed counter. M1018: it is used to start high-speed counter
  function. (when M1028 is ON).
- D1025: the low word of high-speed counter C235. D1026: the high word of high-speed counter C235.



API	Mnemon	ic	Operands	Function						
139	RPR	Р	S1, S2	Read the AC motor drive's parameters						

Туре	Bit	Bit Devices				w	ord de	vices	Program Steps			
ОР	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	RPR, RPRP: 5 steps
S1				*	*						*	
S2											*	

## Appendix D How to Use PLC Function | 1



Operands:

S1: Data address for reading S2: Register that saves the read data


Al	PI	Mnemon	ic	Operands	Function
14	10	WPR	Р	S1, S2	Write the AC motor drive's parameters

Туре	Bit Devices					W	ord de	vices	Program Steps			
ОР	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	WPR, WPRP: 5 steps
S1				*	*						*	
S2				*	*						*	

### Operands:

S1: Data address for writing S2: Register that saves the written data

- 1. Assume that it will write the data in address H2100 of the VFD-E into D0 and H2101 into D1.
- 2. When M0=ON, it will write the data in D10 to the address H2001 of the VFD-E.
- 3. When M1=ON, it will write the data in H2 to the address H2000 of the VFD-E, i.e. start the AC motor drive.
- When M2=ON, it will write the data in H1 to the address H2000 of the VFD-E, i.e. stop the 4. AC motor drive.
- When data is written successfully, M1017 will be ON. 5.



				Appendix D How to Use PLC Function
API	Mnemon	ic	Operands	Function
141	FPID	Р	S1, S2, S3, S4	PID control for the AC motor drive

Type	Type Bit Devices					W	ord de	vices				Program Steps
ОР	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	FPID, FPIDP: 9 steps
S1				*	*						*	
S2				*	*						*	
S3				*	*						*	
S4				*	*						*	


S1: PID Set Point Selection(0-4), S2: Proportional gain P (0-100), S3: Integral Time I (0-10000), S4: Derivative control D (0-100)

### Explanation:

 This command FPID can control the PID parameters of the AC motor drive directly, including Pr.10.00 PID set point selection, Pr.10.02 Proportional gain (P), Pr.10.03 Integral time (I) and Pr.10.04 Derivative control (D)

- Assume that when M0=ON, S1 is set to 0 (PID function is disabled), S2=0, S3=1 (unit: 0.01 seconds) and S4=1 (unit: 0.01 seconds).
- Assume that when M1=ON, S1 is set to 0 (PID function is disabled), S2=1 (unit: 0.01), S3=0 and S4=0.
- Assume that when M2=ON, S1 is set to 1(frequency is inputted by digital keypad), S2=1 (unit: 0.01), S3=0 and S4=0.
- 4. D1027: frequency command controlled by PID.





API	Mnemon	ic	Operands	Function
142	FREQ	Р	S1, S2, S3	Operation control of the AC motor drive

Туре	Bit	Devi	ices Word devices							Program Steps			
ОР	Х	Υ	М	K	Н	KnX	KnY	KnM	Т	С	D	FREQ, FREQP: 7 steps	
S1				*	*						*		
S2				*	*						*		
S3				*	*						*		

S1: frequency command, S2: acceleration time, S3: deceleration time Explanation:

This command can control frequency command, acceleration time and deceleration time
of the AC motor drive. Please use M1025 to RUN(ON)/STOP(OFF) the AC motor drive
and use M1025 to control the operation direction: FWD(ON)/REV(OFF).

- M1025: RUN(ON)/STOP(Off) the AC motor drive. M1026: operation direction of the AC motor drive – FWD(OFF)/REV(ON). M1015: frequency is reached.
- When M10=ON, setting frequency command of the AC motor drive to K300(3.00Hz) and acceleration/deceleration time is 0.
- When M11=ON, setting frequency command of the AC motor drive to K3000(30.00Hz), acceleration time is 50 and deceleration time is 60.

#### Appendix D How to Use PLC Function | Versile M1000 M1025 M11 M1026 M10 M11 FREQP K300 K0 K0 M10 M11 $\dashv\vdash$ **FREQ** K3000 K50 K60

**END** 



# **D.6 Error Code**

Code	ID	Description	Corrective Actions
PLod	20	Data write error	Check if the program is error and download the program again
PLSv	21	Data write error when executing	Power on again and download the program again
PLdA	22	Program upload error	Please upload again.     Return to the factory if it occurs continuously
PLFn	23	Command error when download program	Check if the program is error and download program again
PLor	30	Program capacity exceeds memory capacity	Power on again and download program again
PLFF	31	Command error when executing	
PLSn	32	Check sum error	
PLEd	33	There is no "END" command in the program	
PLCr	34	The command MC is continuous used more than nine times	

# Appendix E CANopen Function

The built-in CANopen function is a kind of remote control. Master can control the AC motor drive by using CANopen protocol. CANopen is a CAN-based higher layer protocol. It provides standardized communication objects, including real-time data (Process Data Objects, PDO), configuration data (Service Data Objects, SDO), and special functions (Time Stamp, Sync message, and Emergency message). And it also has network management data, including Boot-up message, NMT message, and Error Control message. Refer to CiA website <a href="http://www.can-cia.org/">http://www.can-cia.org/</a> for details. The content of this instruction sheet may be revised without prior notice. Please consult our distributors or download the most updated version at <a href="http://www.delta.com.tw/industrialautomation">http://www.delta.com.tw/industrialautomation</a>

### Delta CANopen supports functions:

- Support CAN2.0A Protocol;
- Support CANopen DS301 V4.02;
- Support DSP-402 V2.0.

\_

### Delta CANopen supports services:

- PDO (Process Data Objects): PDO1~ PDO2
- SDO (Service Data Object):

Initiate SDO Download;

Initiate SDO Upload;

Abort SDO:

SDO message can be used to configure the slave node and access the Object Dictionary in every node.

■ SOP (Special Object Protocol):

Support default COB-ID in Predefined Master/Slave Connection Set in DS301 V4.02;

Support SYNC service:

Support Emergency service.

■ NMT (Network Management):

Support NMT module control;

Support NMT Error control;

Support Boot-up.

### Delta CANopen doesn't support service:


■ Time Stamp service



### E.1 Overview

## E.1.1 CANopen Protocol

CANopen is a CAN-based higher layer protocol, and was designed for motion-oriented machine control networks, such as handling systems. Version 4 of CANopen (CiA DS301) is standardized as EN50325-4. The CANopen specifications cover application layer and communication profile (CiA DS301), as well as a framework for programmable devices (CiA 302), recommendations for cables and connectors (CiA 303-1) and SI units and prefix representations (CiA 303-2).





### E.1.2 RJ-45 Pin Definition





PIN	Signal	Description		
1	CAN_H	CAN_H bus line (dominant high)		
2	CAN_L	CAN_L bus line (dominant low)		
3	CAN_GND	Ground / 0V /V-		
4	SG+	485 communication		
5	SG-	485 communication		
7	CAN_GND	Ground / 0V /V-		

## E.1.3 Pre-Defined Connection Set

To reduce configuration effort for simple networks, CANopen define a mandatory default identifier allocation scheme. The 11-bit identifier structure in predefined connection is set as follows:

	COB Identifier (CAN Identifier)									
10	10 9 8 7 6 5 4 3 2 1 0									
Function Code Node Number										

Object	Function Code	Node Number	COB-ID	Object Dictionary Index						
Broadcast messages										
NMT	0000	-	0	-						
SYNC	0001	-	0x80	0x1005, 0x1006, 0x1007						
TIME STAMP	0010	-	0x100	0x1012, 0x1013						
Point-to-point messages										
Emergency	0001	1-127	0x81-0xFF	0x1014, 0x1015						

Object	Function Code	Node Number	COB-ID	Object Dictionary Index
TPDO1	0011	1-127	0x181-0x1FF	0x1800
RPDO1	0100	1-127	0x201-0x27F	0x1400
TPDO2	0101	1-127	0x281-0x2FF	0x1801
RPDO2	0110	1-127	0x301-0x37F	0x1401
TPDO3	0111	1-127	0x381-0x3FF	0x1802
RPDO3	1000	1-127	0x401-0x47F	0x1402
TPDO4	1001	1-127	0x481-0x4FF	0x1803
RPDO4	1010	1-127	0x501-0x57F	0x1403
Default SDO (tx)	1011	1-127	0x581-0x5FF	0x1200
Default SDO (rx)	1100	1-127	0x601-0x67F	0x1200
NMT Error Control	1110	1-127	0x701-0x77F	0x1016, 0x1017

## **E.1.4 CANopen Communication Protocol**


It has services as follows:

- NMT (Network Management Object)
- SDO (Service Data Object)
- PDO (Process Data Object)
- EMCY (Emergency Object)

# E.1.4.1 NMT (Network Management Object)

The Network Management (NMT) follows a Master/Slave structure for executing NMT service. Only one NMT master is in a network, and other nodes are regarded as slaves. All CANopen nodes have a present NMT state, and NMT master can control the state of the slave nodes. The state diagram of a node are shown as follows:

### Appendix D How to Use PLC Function



(1	) After	power i	s applied,	it is a	auto in	initialization	state
----	---------	---------	------------	---------	---------	----------------	-------

- (2) Enter pre-operational state automatically
- (3) (6) Start remote node
- (4) (7) Enter pre-operational state
- (5) (8) Stop remote node
- (9) (10) (11) Reset node
- (12) (13) (14) Reset communication
- (15) Enter reset application state automatically
- (16) Enter reset communication state automatically

A· NMT

B: Node Guard

C: SDO

. OD O


D: Emergency

E: PDO

F: Boot-up

and 2 Chivopen i une	Initializing	Pre-Operational	Operational	Stopped
PDO			0	
SDO		0	0	
SYNC		0	0	
Time Stamp		0	0	
EMERG		0	0	
Boot-up	0			
NMT		0	0	0

NMT Protocol is shown as follows:



Value	Definition
1	Start
2	Stop
128	Enter Pre-Operational
129	Reset Node
130	Reset Communication

# E.1.4.2 SDO (Service Data Object)

SDO is used to access the Object Dictionary in every CANopen node by Client/Server model. One SDO has two COB-ID (request SDO and response SDO) to upload or download data between two nodes. No data limit for SDOs to transfer data. But it needs to transfer by segment when data exceeds 4 bytes with an end signal in the last segment.

The Object Dictionary (OD) is a group of objects in CANopen node. Every node has an OD in the system, and OD contains all parameters describing the device and its network behavior. The access path of OD is the index and sub-index, each object has a unique index in OD, and has sub-index if necessary.

The request and response frame structure of SDO communication is shown as follows:

											Append	dix D Ho	w to Us	e PLC I	Functio	n Va	77/
				D	ata	0				Data	Data	Data	Data	Data	Data	Data	
Tuno										1	2	3	4	5	6	7	
Туре		7	6	5	4	3	2	1	0	Index	Index	Index	Data	Data	Data	Data	
		command						Г	Г	L	Н	Sub	LL	LH	HL	HH	
Initiate Domain	Client	0	0	1	-	١	١	E	S								
Download	Server	0	1	1	-	-	-	T-	-								
Initiate Domain	Client	0	1	0	-	-	-	T-	-								
Upload	Server	0	1	0	-	١	١	E	S								
Abort Domain	Client	1	0	0	-	-	-	T-	-								
Transfer	Server	1	0	0	_	_	-	Τ-	-								

N: Bytes not use E: normal(0)/expedited(1)

S: size indicated

## E.1.4.3 PDO (Process Data Object)

PDO communication can be described by the producer/consumer model. Each node of the network will listen to the messages of the transmission node and distinguish if the message has to be processed or not after receiving the message. PDO can be transmitted from one device to one another device or to many other devices.

Every PDO has two PDO services: a TxPDO and a RxPDO. PDOs are transmitted in a non-confirmed mode.

PDO Transmission type is defined in the PDO communication parameter index (1400h for the 1st RxPDO or 1800h for the 1st TxPDO), and all transmission types are listed in the following table:

Type Number	PDO											
Type Number	Cyclic	Acyclic	Synchronous	Asynchronous	RTR only							
0		0	0									
1-240	0		0									
241-251			Reserve	ed								
252			0		0							
253				0	0							
254				0								
255				0								

Type number 1-240 indicates the number of SYNC message between two PDO transmissions.

Type number 252 indicates the data is updated (but not sent) immediately after receiving SYNC.

Type number 253 indicates the data is updated immediately after receiving RTR.

Type number 254: Delta CANopen doesn't support this transmission format.


## Appendix E CANopen Function | 1/22/15

Type number 255 indicates the data is asynchronous transmission.

All PDO transmission data must be mapped to index via Object Dictionary.

### Example:

## Master transmits PDO data to Slave



PDO1 data value Data 0, Data 1, Data 2, Data 3, Data 4, Data 5, Data 6, Data 7, (0x11, 0x22, 0x33, 0x44, 0x55, 0x66, 0x77, 0x88,

	Index Sub Definition			Value	R/W	Size
	0x1600	0	0. Number	1	R/W	U8
1	0x1600	1	1. Mapped Object	0x604000 <u>10</u>	R/W	U32
PDO1 Map	0x1600	2	2. Mapped Object	0	R/W	U32
	0x1600	3	3 Mapped Object	\ 0	R/W	U32
	0x1600	4	4. Mapped Object	0	R/W\	U32
				\		
0x60400010	0x6040	0	0. Control word	0x2211	R/W	¥U16 (2 Bytes)

### Slave returns message to Master



PDO1 data value Data 0, Data 1, Data 2, Data 3, Data 4, Data 5, Data 6, Data 7, 0xF3, 0x00,

	Index	Sub	Definition	Value	R/W	Size
		oxdot				
	0x1A00	Q	0. Number	1	R/W	U8
	0x1A00	1	1. Mapped Object	0x604100 <u>10</u>	R/W	U32
PDO1 Map	0x1A00	2	2. Mapped Object	0	R/W	U32
	0x1A00	3	3. Mapped Object	0	R/W	U32
	0x1A00	4	4. Mapped Object	0	R/W	U32
_						
	0x6041	0	Status Word	0xF3	R/W	U16



# E.1.4.4 EMCY (Emergency Object)

Emergency objects are triggered when hardware failure occurs for a warning interrupt. The data format of a emergency object is a 8 bytes data as shown in the following:

Byte	0	1	2	3	4	5	6	7
Content		O1 -	Error register (Object 1001H)	Manu	facturer	speci	fic Erro	or Field

## Definition of Emergency Object

Display	Controller Error Code	Description	CANopen Error Code	CANopen Error Register (bit 0~7)
ос	0001H	Over current	7400H	1
00	0002H	Over voltage	7400H	2
oX I	0003H	Overheating	4310H	3
οL	0005H	Overload	2310H	1
ol I	0006H	Overload 1	7120H	1
015	0007H	Overload 2	2310H	1
8.5	0008H	External Fault	9000H	7
oc 8	0009H	Over-current during acceleration	2310H	1
ocd	000AH	Over-current during deceleration	2310H	1
000	000BH	Over-current during constant speed operation	2310H	1
GFF	000CH	Ground fault	2240H	1
Ĺυ	000DH	Lower than standard voltage	3220h	2
PHL	000EH	Phase Loss	3130h	7
55	000FH	External Base Block	9000h	7
codE	0011H	Software protection failure	6320h	7
c F 1.0	0013H	Internal EEPROM can not be programmed	5530h	7
c F 2.0	0014H	Internal EEPROM can not be read	5530h	7
HPF :	0015H	CC (current clamp)	5000h	7
X255	0016H	OV hardware error	5000h	2
XPF3	0017H	GFF hardware error	5000h	2
XPFY	0018H	OC hardware error	5000h	1
c F 3.0	0019H	U-phase error	2300h	1
c F 3. 1	001AH	V-phase error	2300h	1
c 8 3.2	001BH	W-phase error	2300h	1
c £ 3.3	001CH	OV or LV	3210h	2
c F 3.4	001DH	Temperature sensor error	4310h	3
cF !!	001FH	Internal EEPROM can not be programmed	5530h	7

Display	Controller Error Code	Description	CANopen Error Code	CANopen Error Register (bit 0~7)
c 8 2. 1	0020H	Internal EEPROM can not be read	5530h	7
8800	0021H	Analog signal error	FF00h	7
PE[ 1	0023H	Motor overheat protection	7120h	3
P68r	0024H	PG signal error	7300h	7
c P 10	0029H	Communication time-out error on the control board or power board	7500h	4

### Definition of Index

Definition of Index										
Index	Sub	Definition	Factory Setting	R/W	Size	Unit	NOTE			
0x1000	0	Abort connection option code	0x00010192	RO	U32					
0x1001	0	Error register	0	RO	U8					
0x1005	0	COB-ID SYNC message	0x80	RW	U32					
0x1006	0	Communication cycle period	0	RW	U32	us	500us~15000us			
0x1008	0	Manufacturer device name	0	RO	U32					
0x1009	0	Manufacturer hardware version	0	RO	U32					
0x100A	0	Manufacturer software version	0	RO	U32					
0x100C	0	Guarding time	0	RW	U16	ms	0x80 + node 1			
0x100D	0	Guarding factor	0	RW	U8					
0x1014	0	COB-ID emergency	0x0000080 +Node-ID	RO	U32					
0x1015	0	Inhibit time EMCY	0	RW		100us	It is set to be multiple of 10.			
	0	Number	0x1	RO	U8					
0x1016	1	Consumer heartbeat time	0x0	RW	U32	1ms	Heartbeat time can be used when Guarding time is invalid.			
0x1017	0	Producer heartbeat time	0x0		U16	1ms	Heartbeat time can be used when Guarding time is invalid.			
	0	Number	0x3		U8					
	1	Vender ID	0x000001DD	RO	U32					
0x1018	2	Product code	0x00002600 +model	RO	U32					
	3	Revision	0x00010000	RO	U32					
0x1200	0	Server SDO Parameter	2	RO	U8					
	1	COB-ID Client -> Server	0x0000600+ Node-ID	RO	U32					

Appendix D How to Use PLC Function | Variable Factory R/W Size Index Sub Definition Unit NOTE Setting COB-ID Client <-0x0000580+ 2 RO U32 Server Node-ID n Number 2 RO U8 0x00000200 1 COB-ID used by PDO RW U32 +Node-ID 00:Acyclic & 0x1400 Synchronous 2 Transmission Type 5 RW U8 01~240:Cyclic & Synchronous 255: Asynchronous 2 RO U8 Number 0x80000300 RW U32 COB-ID used by PDO 1 +Node-ID 00:Acyclic & 0x1401 Synchronous 01~240:Cyclic & 2 Transmission Type 5 RW 118 Synchronous 255: Asynchronous n Number 2 RW U8 1.Mapped Object 0x60400010 RW U32 0x1600 2.Mapped Object 0x60420020 RW U32 3.Mapped Object 0 RW U32 3 4 4.Mapped Object 0 RW U32 Number 0 RW U8 0 RW U32 1 1.Mapped Object 0x1601 2.Mapped Object 0 RW U32 3.Mapped Object 3 0 RW U32 4.Mapped Object 0 RW U32 4 0 Number 5 RO U8 0x00000180 RW 1 COB-ID used by PDO U32 +Node-ID 00:Acyclic & Synchrouous 01~240:Cvclic & 2 Transmission Type 5 RW U8 Synchrouous 0x1800 253: Remote function 255: Asynchronous It is set to be 3 Inhibit time RW | U16 100us ი multiple of 10. 3 RW Reserved Reserved U8 Event timer 0 RW U16 1ms 0x1801 0 Number 5 RO U8 0x80000280 1 RW U32 COB-ID used by PDO +Node-ID 00:Acvclic & Synchrouous 01~240:Cyclic & 5 RW U8 Synchrouous 2 Transmission Type 253: Remote

function 255: Asynchronous

Index	Sub	Sub Definition Factory Setting R/		R/W	Size	Unit	NOTE
	3	Inhibit time	0	RW	U16	100us	It is set to be multiple of 10.
	4	Reserved	3	RW	U8		
	5	Event timer	0	RW	U16	1ms	
	0	Number	2	RW	U8		
	1	1.Mapped Object	0x60410010	RW	U32		
0x1A00	2	2.Mapped Object	0x60430010	RW	U32		
	3	3.Mapped Object	0	RW	U32		
	4	4.Mapped Object	0	RW	U32		
	0	Number	0	RW	U8		
	1	1.Mapped Object	0	RW	U32		
0x1A01	2	2.Mapped Object	0	RW	U32		
	3	3.Mapped Object	0	RW	U32		
	4	4.Mapped Object	0	RW	U32		

Index	Sub	Definition	Factory Setting	RW	Size	Unit	Мар	NOTE
0x6007	0	Abort connection option code	2	RW	S16		Yes	0: No action 2: Disable Voltage 3: Quick stop
0x603F	0	Error code	0	RO	U16		Yes	·
0x6040	0	Control word	0	RW	U16		Yes	bit 0 ~ 3: switch status bit 4: rfg enable bit 5: rfg unlock bit 6: rfg use ref bit 7: Fault reset
0x6041	0	Status word	0	RO	U16		Yes	Bit0 Ready to switch on Bit1 Switched on Bit2 Operation enabled Bit3 Fault Bit4 Voltage enabled Bit5 Quick stop Bit6 Switch on disabled Bit7 Warning Bit8 Bit9 Remote Bit10 Target reached Bit11 Internal limit active Bit12 - 13 Bit14 - 15
0x6042	0	vl target velocity	0	RW	S16	rpm	Yes	
0x6043	0	vl velocity demand	0	RO	S16	rpm	Yes	
0x604F	0	vl ramp function time	10000	RW	U32	1ms	Yes	If Pr.01.19 is set to 0.1, the unit must be 100ms and can't be set to 0.
0x6050	0	vl slow down time	10000	RW	U32	1ms	Yes	If Pr.01.19 is set to 0.1, the unit must be 100ms and can't be set to 0.
0x6051	0	vl quick stop time	1000	RW	U32	1ms	Yes	If Pr.01.19 is set to 0.1, the unit must be 100ms and can't be set to 0.

					Appendix D How to Use PLC Function			
Index	Sub	Definition	Factory Setting	RW	Size	Unit	Мар	NOTE
0x605A	0	Quick stop option code	2	RW	S16	1ms	Yes	0 : disable drive function 1 :slow down on slow down ramp 2: slow down on quick stop ramp (2th decel. time) 5 slow down on slow down ramp and stay in QUICK STOP 6 slow down on quick stop ramp and stay in QUICK STOP
0x6060	0	Mode of operation	2	RO	U8		Yes	Speed mode
0x6061	0	Mode of operation display	2	RO	U8		Yes	

## E.2 How to Control by CANopen

To control the AC motor drive by CANopen, please set parameters by the following steps:

Step 1. Operation source setting: set Pr.02.01 to 5 (CANopen communication. Keypad STOP/RESET disabled.)

- Step 2. Frequency source setting: set Pr.02.00 to 5 (CANopen communication)
- Step 3. CANopen station setting: set Pr.09.13 (CANopen Communication Address 1-127)
- Step 4. CANopen baud rate setting: set Pr.09.14 (CANBUS Baud Rate)

Step 5. Set multiple input function to quick stop when necessary: Set Pr.04.05 to 04.08 or Pr.11.06 to 11.11 to 23

According to DSP-402 motion control rule, CANopen provides speed control mode. There are many status can be switched during Start to Quick Stop. To get current status, please read "Status Word". Status is switched by the PDO index control word via external terminals.

Control word is a 16-byte in index 0x6040 and each bit has specific definition. The status bits are bit 4 to bit 6 as shown in the following:

Bit 4: ramp function enabled

Bit 5: ramp function disabled

Bit 6: rfg use reference

## Appendix E CANopen Function | Value

Following is the flow chart for status switch:

