
CTR
IN +
CTR
OUT +
N
L
LINE / IN
LINE
ON
LOAD
START / ON
ERROR
EPA
I Leak
RMS
Indicator
Comp
Adj.
CTR
IN –
CTR
OUT –
LOAD / OUT
N
L